

Type 8025 - 8035 - SE35 BATCH

Batch controller Dosiergerät Contrôleur de dosage









Operating Instructions

Bedienungsanleitung Manuel d'utilisation

We reserve the right to make technical changes without notice. Technische Änderungen vorbehalten. Sous réserve de modifications techniques.

© Bürkert SAS, 2013-2023

Operating Instructions 2311/07_EU-ML 00564510 / Original EN



1	ABOUT THESE OPERATING INSTRUCTIONS			9
	1.1	Symbo	ols used	9
	1.2	Definiti	ion of the word "device"	10
	1.3	Validity	of these Operating Instructions	10
2	INTE	NDED U	ISE	10
3	BAS	IC SAFE	TY INFORMATION	10
4	GEN	ERAL IN	FORMATION	12
	4.1	Manufa	acturer's address and international contacts	12
	4.2	Warran	nty conditions	12
	4.3	Informa	ation on the Internet	12
5	DES	CRIPTIO	N	13
	5.1	Area of	f application	13
	5.2	Constr	uction of the device	13
		5.2.1	Construction of the 8025 Batch in compact version	13
		5.2.2	Construction of the 8025 Batch in panel version	14
		5.2.3	Construction of the 8025 Batch in wall-mounted version	14
		5.2.4	Construction of the SE35 Batch	14
		5.2.5	Construction of the 8035 Batch	14
		5.2.6	Construction of the SE35 Batch with sensor-fitting S070 or S077	15
	5.3	Descri	ption of the type label	15
	5.4	Symbo	ols on the device	16
6	TEC	HNICAL	DATA	16
	6.1	Technic	cal data of the dosing controller 8025 Batch in compact version	16
		6.1.1	Conditions of use of a 8025 Batch in compact version	16
		6.1.2	Standards and directives	17
		6.1.3	Fluid data of a 8025 Batch in compact version	18
		6.1.4	Material data of a 8025 Batch in compact version	19
		6.1.5	Dimensions of a 8025 Batch in compact version	19
		6.1.6	Electrical data of a 8025 Batch in compact version	19



6.2	Technic	al data of the dosing controller 8025 Batch in panel version	20			
	6.2.1	Conditions of use of a 8025 Batch in panel version	20			
	6.2.2	Standards and directives	21			
	6.2.3	Material data of a 8025 Batch in panel version	21			
	6.2.4	Dimensions of a 8025 Batch in panel version	21			
	6.2.5	Electrical data of a 8025 Batch in panel version	21			
	6.2.6	Specifications of a remote flow sensor connected to a 8025 Batch in panel vers	ion23			
6.3	Technic	eal data of the dosing controller 8025 Batch in wall-mounted version	23			
	6.3.1	Conditions of use of a 8025 Batch in wall-mounted version	23			
	6.3.2	Standards and directives	24			
	6.3.3	Material data of a 8025 Batch in wall-mounted version	24			
	6.3.4	Dimensions of a 8025 Batch in wall-mounted version	24			
	6.3.5	Electrical data of a 8025 Batch in wall-mounted version	24			
	6.3.6	Specifications of a remote flow sensor connected to a 8025 Batch in wall-mounted version	26			
6.4	Technic	al data of the dosing controller SE35 Batch	26			
	6.4.1	Conditions of use of a SE35 Batch	26			
	6.4.2	Standards and directives	27			
	6.4.3	Material data of a SE35 Batch	27			
	6.4.4	Dimensions of a SE35 Batch	27			
	6.4.5	Electrical data of a SE35 Batch	28			
6.5	Technic	Technical data of the dosing controller 8035 Batch				
	6.5.1	Conditions of use of a 8035 Batch	29			
	6.5.2	Standards and directives	29			
	6.5.3	Fluid data of a 8035 Batch	30			
	6.5.4	Material data of a 8035 Batch	31			
	6.5.5	Dimensions of a 8035 Batch	32			
	6.5.6	Electrical data of a 8035 Batch	32			
6.6	Technic S070 or	eal data of the dosing controller SE35 Batch associated with a sensor-fitting	32			
	6.6.1	Conditions of use of a SE35 Batch with a S070 or a S077	32			
	6.6.2	Standards and directives	32			
	6.6.3	Fluid data of a SE35 Batch with a S070 or a S077	33			
	6.6.4	Material data of a SE35 Batch with a S070 or a S077	34			
	6.6.5	Dimensions of a SE35 Batch with a S070 or a S077	34			
	6.6.6	Electrical data of a SE35 Batch with a S070 or a S077	34			



7	FLUII	FLUID INSTALLATION		
	7.1	Safety instructions		
	7.2	Installation of the dosing controller type 8025 Batch in compact version		
		7.2.1	Install the S020 fitting on the pipes	36
		7.2.2	Install the 8025 Batch in compact version into the S020 fitting	38
		7.2.3	Finalise the installation of the 8025 Batch in compact version	38
	7.3	Installat	tion of the dosing controller 8035 Batch	38
		7.3.1	Install the S030 sensor-fitting on the pipes	38
		7.3.2	Install the dosing controller SE35 Batch on the sensor-fitting S030	39
		7.3.3	Finalise the installation of the 8035 Batch	39
	7.4	Installat	tion of the dosing controller SE35 Batch on the sensor-fitting S070 or S077	39
		7.4.1	Install the sensor-fitting S070 or S077 on the pipes	39
		7.4.2	Install the dosing controller SE35 Batch on the sensor-fitting S070 or S077	40
		7.4.3	Finalise the installation	40
	7.5	Installat	tion of the dosing controller 8025 Batch in panel version	41
	7.6	Installat	tion of the dosing controller 8025 Batch in wall-mounted version	42
8	ELEC	TRICAL	INSTALLATION AND WIRING	43
	8.1	Safety i	nstructions	43
	8.2	Specifications of the connection cables		
		8.2.1	Dosing controller 8025 Batch in compact version, 8035 Batch and SE35 Batch	45
		8.2.2	Dosing controller 8025 Batch in panel version	45
		8.2.3	Dosing controller 8025 Batch in wall-mounting version	45
	8.3	Equipot	tentiality of the installation	46
	8.4	Default	position of the selectors	47
	8.5	Termina	al assignment and use of the selectors	48
	8.6	Wiring t	the 8025 Batch in compact version, the 8035 Batch or the SE35 Batch	52
	8.7	Wiring t	the 8025 Batch in panel version	54
	8.8	Wiring t	the 8025 Batch in wall-mounted version	54
	8.9	Connecting the remote flow sensor to a 8025 Batch in panel-mounted or in wall-mounted version		
	8.10			50
	0.10	Wiring t	the digital inputs DI1 to DI4 and the transistor output DO4	03



	8.12	Wiring th 8025 Ba	ne DO1 transistor output of a version fed with 115/230 V AC for the tch in compact version, for the 8035 Batch or for the SE35 Batch	59
	8.13	Wiring th	ne DO1 transistor output of the 8025 Batch in wall-mounted version, fed	60
	8.14	Wiring th	ne relay outputs DO2 and DO3 of a device	62
9	СОМ	MISSION	ING	63
	9.1	Safety in	nstructions	63
	9.2	Commis	sioning procedure	63
10	OPE	RATING A	ND FUNCTIONS	64
	10.1	Safety in	nstructions	64
	10.2	Operatin	ng levels of the device	64
	10.3	Descript	tion of the navigation keys and the state LEDs	66
	10.4	Using th	e navigation keys	67
	10.5	Principle	e of a dosing and PLC scenarios	68
	10.6	Details o	of the Process level	71
		10.6.1	Doing a dosing in dosing mode "LOC. MANU." or "MEM.+MANU."	72
		10.6.2	Doing a dosing in dosing mode "LOC. MEM." or "MEM.+MANU."	74
		10.6.3	Doing a dosing in dosing mode "EXT. MEM."	76
		10.6.4	Doing a dosing in dosing mode "EXT.+LOC."	80
		10.6.5	Doing a dosing in dosing mode "EXT. [T]"	84
		10.6.6	Doing a dosing in dosing mode "EXT. REP."	87
		10.6.7	Doing a dosing in dosing mode "LOC. REP."	90
	10.7	Details o	of the Parameters menu	92
		10.7.1	Choosing the display language	93
		10.7.2	Choosing the dosing units, the flow rate units, the units and number of decimals of the volume or mass totalizers	93
		10.7.3	Entering the K-factor of the fitting used	95
		10.7.4	Determining the fitting K-factor using a Teach-In procedure	95
		10.7.5	Configuring the dosing mode (general diagram)	98
		10.7.6	Configuring the dosing mode "LOC. MANU."	99
		10.7.7	Configuring the dosing mode "LOC. MEM."	99
		10.7.8	Configuring the dosing mode "MEM+MANU"	99
		10.7.9	Configuring the dosing mode "EXT. MEM."	100
		10.7.10	Configuring the dosing mode "EXT. +LOC"	100



	10.7.11	Configuring the dosing mode "EXT. [T]"	100
	10.7.12	Configuring the dosing mode "EXT. REP"	102
	10.7.13	Configuring the dosing mode "LOC. REP."	104
	10.7.14	Entering the dosing quantities in the device memory	106
	10.7.15	Configuring the overfill correction or deactivating it	106
	10.7.16	Activating / deactivating the generation of alarms for problems occurring during a dosing	108
	10.7.17	Activating / deactivating the generation of alarms for problems occurring at the end of a dosing	109
	10.7.18	Configuring the outputs (general diagram)	110
	10.7.19	Configuring the transistor output DO1 or DO4 or the relay output DO3 to switch when an alarm is generated during or at the end of a dosing	111
	10.7.20	Configuring the transistor output DO1 or DO4 or the relay output DO3 to switch when a warning message is emitted by the device	112
	10.7.21	Configuring the transistor output DO1 or DO4 or the relay output DO3 to signal the end of the dosing	112
	10.7.22	Configuring the transistor output DO1 or DO4 as a pulse output proportional to a volume or a mass	113
	10.7.23	Configuring the transistor output DO1 or DO4 to transmit the rotational frequency of the paddle wheel	114
	10.7.24	Configuring the relay output DO2	115
	10.7.25	Configuring the relay output DO3 to control an auxiliary valve	116
	10.7.26	Configuring the transistor output DO4 to transmit the device state and activating / deactivating the generation of a 10 Hz frequency when an error message is generated by the device	116
	10.7.27	General diagram of the "RESET" sub-menu	118
	10.7.28	Resetting the two volume or mass totalizers	118
	10.7.29	Resetting the two totalizers of the done dosings	119
	10.7.30	Clearing the history table of the done dosings	119
	10.7.31	Setting the brightness of the display and how long it stays ON, or deactivating the backlight	120
10.8	Details o	f the Test menu	121
	10.8.1	Checking the inputs functions	122
	10.8.2	Checking the outputs functions	122
	10.8.3	Checking the paddle-wheel operation	123
	10.8.4	Monitoring the flow rate in the pipe	124
	10.8.5	Monitoring the value of the daily volume or mass totalizer	125
	10.8.6	Monitoring the number of done dosings	125
	10.8.7	Saving the user set configuration	126
	10.8.8	Restoring the saved configuration	126
	10.8.9	Restoring the default configuration	127



	10.9	Details o	f the History menu	128
	10.10	Details o	of the Information menu	128
	10.11	Remote	consultation and confirmation of the warning messages	129
11	MAIN	ITENANCI	E AND TROUBLESHOOTING	132
	11.1	Safety in	structions	132
	11.2	Cleaning	the device	132
	11.3	If you en	counter problems	132
		11.3.1	Resolution of problems when the device state LED is OFF	132
		11.3.2	Resolution of problems related to an error message and the device state LED is red	133
		11.3.3	Resolution of problems related to a warning message and the device state LED is orange	134
		11.3.4	Resolution of a problem occurring during a dosing	135
		11.3.5	Resolution of problems without message generation and the device status LED is green	137
		11.3.6	Resolution of problems linked to warning messages not registered in the Information menu	138
12	SPAF	RE PARTS	AND ACCESSORIES	139
13	PACK	KAGING, T	FRANSPORT	142
14	STOF	RAGE		142
15	DIED	OSAL OF	THE DEVICE	140



1 ABOUT THESE OPERATING INSTRUCTIONS

The Operating Instructions describe the entire life cycle of the product. Please keep the Operating Instructions in a safe place, accessible to all users and any new owners.

These Operating Instructions contains important safety information.

Failure to comply with these instructions can lead to hazardous situations. Pay attention in particular to the chapters 3 Basic safety information and 2 Intended use.

- ► Whatever the version of the device, these Operating Instructions must be read and understood.
- ► When the symbol ∠! is marked inside or outside the device, carefully read the Operating Instructions.

1.1 Symbols used



DANGER

Warns against an imminent danger.

▶ Failure to observe this warning can result in death or in serious injury.



WARNING

Warns against a potentially dangerous situation.

► Failure to observe this warning can result in serious injury or even death.



CAUTION

Warns against a possible risk.

▶ Failure to observe this warning can result in substantial or minor injuries.

NOTICE

Warns against material damage.



Indicates additional information, advice or important recommendations.



Refers to information contained in these Operating Instructions or in other documents.

- Indicates an instruction to be carried out to avoid a danger, a warning or a possible risk.
- → Indicates a procedure to be carried out.
- Indicates the result of a specific instruction.



1.2 Definition of the word "device"

The word "device" used within these Operating Instructions always refers to:

- the dosing controller type 8025 Batch in compact version,
- the dosing controller type 8025 Batch in panel version,
- the dosing controller type 8025 Batch in wall-mounted version,
- the dosing controller type 8035 Batch or
- the dosing controller type SE35 Batch.

1.3 Validity of these Operating Instructions

The Operating Instructions are valid for the following devices:

serial numbers higher or equal to 20 000.

2 INTENDED USE

Use of the device that does not comply with the instructions could present risks to people, nearby installations and the environment.

The device installed in series with one or two valves, has been designed to do the dosing of one or several quantities (volumes or masses) of a liquid.

- ▶ Protect this device against electromagnetic interference, ultraviolet rays and, when installed outdoors, the effects of climatic conditions.
- ▶ Use this device in compliance with the characteristics and commissioning and use conditions specified in the contractual documents and in the operating instructions.
- ▶ Never use this device for security applications.
- ▶ Requirements for the safe and proper operation of the device are proper transport, storage and installation, as well as careful operation and maintenance.
- ► Only operate a device in perfect working order.

3 BASIC SAFETY INFORMATION

This safety information does not take into account any contingencies or occurrences that may arise during installation, use and maintenance of the product.

The operating company is responsible for the respect of the local safety regulations including for the staff safety.



Danger due to electrical voltage.

- ▶ If a 12...36 V DC powered version is installed either in a wet environment or outdoors, all the electrical voltages must be of max. 35 V DC.
- Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.





Danger due to electrical voltage (followed)

- ▶ All equipment connected to the wall-mounted or panel version of the dosing controller type 8025 Batch must be double insulated in relation to the mains in accordance with standard UL/EN 61010-1.
- ▶ Observe all applicable accident protection and safety regulations for electrical equipment.

Risk of injury due to high pressure in the installation.

- Stop the circulation of fluid, cut off the pressure and drain the pipe before loosening the process connections.
- ▶ Observe the fluid temperature/fluid pressure dependency depending on the fitting used.

Risk of injury due to high fluid temperatures.

- ▶ Use safety gloves to handle the device.
- ▶ Stop the circulation of fluid and drain the pipe before loosening the process connections.

Risk of injury due to the nature of the fluid.

► Respect the prevailing regulations on accident prevention and safety relating to the use of aggressive fluids.



Various dangerous situations

To avoid injury take care:

- ▶ not to use the device in explosive atmospheres.
- ▶ not to use the device in an environment incompatible with the materials it is made of.
- ▶ not to use fluid that is incompatible with the materials the device is made of.
- ▶ not to subject the device to mechanical stress.
- ▶ not to make any modifications to the device.
- ▶ to prevent any unintentional power supply switch-on.
- ▶ to carry out the installation and maintenance work by qualified and skilled staff with the appropriate tools.
- ▶ to guarantee a defined or controlled restarting of the process, after a power supply interruption.
- ▶ to observe the general technical rules when installing and using the device.



NOTICE

The device may be damaged by the fluid in contact with.

▶ Systematically check the chemical compatibility of the component materials of the device and the fluids likely to come into contact with it (for example: alcohols, strong or concentrated acids, aldehydes, alkaline compounds, esters, aliphatic compounds, ketones, halogenated aromatics or hydrocarbons, oxidants and chlorinated agents).

NOTICE

Elements / Components sensitive to electrostatic discharges

This device contains electronic components sensitive to electrostatic discharges. They may be damaged if they are touched by an electrostatically charged person or object. In the worst case scenario, these components are instantly destroyed or go out of order as soon as they are activated.

- ► To minimise or even avoid all damage due to an electrostatic discharge, take all the precautions described in standard EN 61340-5-1.
- ► Also ensure that you do not touch any of the live electrical components.

4 GENERAL INFORMATION

4.1 Manufacturer's address and international contacts

To contact the manufacturer of the device, use following address:

Bürkert SAS

Rue du Giessen

BP 21

F-67220 TRIEMBACH-AU-VAL

You may also contact your local Bürkert sales office.

The addresses of our international sales offices are available on the internet at: country.burkert.com.

4.2 Warranty conditions

The condition governing the legal warranty is the conforming use of the device in observance of the operating conditions specified in these operating instructions.

4.3 Information on the Internet

You can find the Operating Instructions and technical data sheets regarding the type 8025 Batch, 8035 Batch and SE35 Batch at: country.burkert.com.



5 DESCRIPTION

5.1 Area of application

When mounted in series with one or two valves the device enables the dosing of one or several quantities of a liquid.

It controls the opening or closing of the valves via the relay outputs and counts the quantity of flown liquid.

The dosing is done either locally by pressing the navigation keys under the display or remotely by a PLC via one up to four digital inputs.

The dosing principle is described in chapter 10.5.

The eight available dosing modes are described in chapter 10.6.

5.2 Construction of the device

The device has:

- four digital inputs (called DI1 to DI4),
- two transistor outputs (called DO1 and DO4, which can be parametered),
- two relay outputs (called DO2 and DO3, which can be parametered) and
- four totalizers (two volume or mass totalizers and two totalizers of the done dosings).

Depending on the version the device is energized by a 12...36 V DC or a 115/230 V AC power supply.

Electrical connection is made on the terminal blocks of the electronic board, either directly or via 2 or 5 cable glands.

5.2.1 Construction of the 8025 Batch in compact version



A: Paddle-wheel flow sensor, the rotation of which generates pulses.

Set in rotation by the flow, the 4 permanent magnets integrated in the vanes of the paddle generate pulses, the frequency of which is proportional to the flow velocity of the fluid. A conversion coefficient specific to each pipe (material and diameter) is necessary to establish the flow rate value associated with the measurement.

The conversion coefficient (K-factor) expressed in pulses per litre is given in the Operating Instructions for the S020 fitting used, available under country.burkert.com.

B: Dosing controller with display and 2 cable glands

Fig. 1: Construction of the 8025 Batch in compact version



5.2.2 Construction of the 8025 Batch in panel version



The 8025 Batch in panel version is a dosing controller in an open housing with display.

Fig. 2: Construction of the 8025 Batch in panel version

5.2.3 Construction of the 8025 Batch in wall-mounted version



The 8025 Batch in wall-mounted version is a dosing controller with display and 5 cable glands.

Fig. 3: Construction of the 8025 Batch in wall-mounted version


5.2.4 Construction of the SE35 Batch



The SE35 Batch is a dosing controller with display and 2 cable glands

Fig. 4: Construction of the SE35 Batch

5.2.5 Construction of the 8035 Batch



A: S030 sensor-fitting including the paddle-wheel flow sensor.

Set in rotation by the flow, the 4 permanent magnets integrated in the vanes of the paddle generate pulses, the frequency of which is proportional to the flow velocity of the fluid. A conversion coefficient specific to each pipe (material and diameter) is necessary to establish the flow rate value associated with the measurement.


The conversion coefficient (K-factor) expressed in pulses per litre is given in the Operating Instructions for the S030 sensor-fitting used available under <u>country.burkert.com</u>.

B: Dosing controller type SE35 Batch (see chapter <u>5.2.4</u>).

Fig. 5: Construction of the 8035 Batch



5.2.6 Construction of the SE35 Batch with sensor-fitting S070 or S077



A: S070 or S077 sensor-fitting including the flow sensor with oval gears.




Set in rotation by the flow, the magnets integrated in the oval gears generate pulses, the frequency of which is proportional to the volume of fluid. A conversion coefficient specific to each pipe (material and diameter) is necessary to establish the flow rate value associated with the measurement.

The conversion coefficient (K-factor) expressed in pulses per litre is given in the Operating Instructions for the S070 or S077 sensor-fitting used, available under: country.burkert.com.

B: Dosing controller type SE35 Batch (see chapter <u>5.2.4</u>).

Fig. 6: Construction of the SE35 Batch with sensor-fitting S070 or S077

5.3 Description of the type label



- 1. Type of the device
- 2. Sensor specifications
- 3. Specifications of the transistor outputs DO1 and DO4
- 4. Power supply and max. current consumption
- 5. Protection class of the device
- 6. Manufacturing code

- 7. Conformity marking
- 8. Certification
- 9. Warning: Before using the device, take into account the technical specifications described in these operating instructions
- 10. Specifications of the relay outputs DO2 and DO3
- 11.Serial number
- 12.Article number

Fig. 7: Type label of the device (example)



5.4 Symbols on the device

Symbol	Description
===	Direct current
\sim	Alternating current
<u></u>	Earth terminal
	Protective conductor terminal

6 TECHNICAL DATA

6.1 Technical data of the dosing controller 8025 Batch in compact version

6.1.1 Conditions of use of a 8025 Batch in compact version

Ambient temperature	
• 1236 V DC version	• -10 °C+60 °C
• 115/230 V AC version	• −10 °C+50 °C
Air humidity	< 80 %, non condensated
Height above sea level	≤ 2000 m
Operating conditions	Continuous
Equipment mobility	Fixed
Use	Indoor and outdoor
	(Protect the device against electromagnetic interference, ultraviolet rays
	and, when installed outdoors, against the effects of climatic conditions)
Installation category	Category I according to UL 61010-1 (UL device)
	Category II according to EN 61010-1 (non UL device)
Degree of pollution	Degree 2 according to UL/EN 61010-1
Protection rating according to	IP65 ¹⁾ , device wired, cover lid screwed tight and cable glands
IEC/EN 60529	tightened

¹⁾ not evaluated by UL



6.1.2 Standards and directives

The device complies with the relevant EU harmonisation legislation. In addition, the device also complies with the requirements of the laws of the United Kingdom.

The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity/UK Declaration of Conformity.

Conformity to the Pressure Equipment Directive

- → Make sure the device materials are compatible with the fluid.
- → Make sure the pipe DN is adapted for the device.

The device conforms to Article 4, Paragraph 1 of the Pressure Equipment Directive 2014/68/EU under the following conditions:

• Device used on a pipe (PS = maximum admissible pressure in bar; DN = nominal dimension of the pipe in mm)

Type of fluid	Conditions
Fluid group 1, Article 4, Paragraph 1.c.i	DN ≤ 25
Fluid group 2, Article 4, Paragraph 1.c.i	DN ≤ 32 or PSxDN ≤ 1000
Fluid group 1, Article 4, Paragraph 1.c.ii	DN ≤ 25 or PSxDN ≤ 2000
Fluid group 2, Article 4, Paragraph 1.c.ii	DN ≤ 200 or PS ≤ 10 or PSxDN ≤ 5000

UL-Certification

Finished products with variable key PU01 or PU02 are UL-certified products and comply also with the following standards:

- UL 61010-1
- CAN/CSA-C22.2 n°61010-1

Identification on the device	Certification	Variable key
c Fl °us	UL-recognized	PU01
CULUS Measuring Equipment EXXXXXX	UL-listed	PU02



6.1.3 Fluid data of a 8025 Batch in compact version

Type of fluid	neutral or slightly aggressive liquids
Fluid viscosity	max. 300 cSt
Rate of solid particles	max. 1 %
Fluid temperature	The fluid temperature may be restricted by the fluid pressure and the material the S020 fitting used is made of (see Fig. 8)
with S020 fitting in PVC	• 0 °C+50 °C
with S020 fitting in PP	• 0 °C+80 °C
• with S020 fitting in PVDF, stainless steel or brass	• −15 °C+80 °C
Fluid pressure	PN10 ¹⁾ max
	The fluid pressure may be restricted by the fluid temperature and the material the S020 fitting used is made (see Fig. 8)
Flow rate measurement	
Measurement range	• 0.310 m/s
Measurement deviation	
- with standard K-factor of the S020 fitting	- ±2.5 % of the measured value ²⁾
- with K-factor determined with a Teach-In procedure	- ±1 % of the measured value ²⁾ (at the value of the Teach-In flow rate)
Linearity	• ±0.5 % of the full scale (10 m/s)
Repeatability	• ±0.4 % of the measured value ²⁾

¹⁾ not evaluated by UL

²⁾ Determined in the following reference conditions: medium = water, water and ambient temperatures 20 °C, min. upstream and downstream distances respected, appropriate pipe dimensions




Fig. 8: Fluid temperature/fluid pressure dependency curves for the 8025 Batch in compact version, depending on the material the S020 fitting is made of



6.1.4 Material data of a 8025 Batch in compact version

Part	Material
Housing /cover, lid, nut	PC
Frontfoil / Screws	Polyester / Stainless steel
Cable glands	PA
Identification label	Polyester
Wetted parts	
Sensor holder / Paddle-wheel	• PVDF
Axis and bearings of the paddle-wheel	Ceramics
Seal	FKM (optional EPDM)
• Fitting S020	Refer to the Operating Instructions of the fitting

6.1.5 Dimensions of a 8025 Batch in compact version

→ Please refer to the technical data sheets regarding the dosing controller type 8025 Batch in compact version, available at: country.burkert.com.

6.1.6 Electrical data of a 8025 Batch in compact version

1236 V DC power supply	filtered and regulated
	• oscillation rate: ±10 %
	The device must be connected permanently to a Safety Extra-Low Voltage circuit (SELV circuit) or Protective Extra Low Voltage (PELV circuit).
Power source (not supplied) for versions supplied with 1236 V DC	Energize the device through a Limited Power Source (LPS) according to standards UL/EN 62368-1 or through a limited-energy circuit according to standards UL/EN 61010-1, Paragraph 9.4.
115/230 V AC power supply	
admissible voltage fluctuation	• ±10 %
• frequency	• 50/60 Hz
supplied voltage	27 V DC, regulated
maximum current	• 125 mA
integrated protection	125 mA time-delay fuse
• power	• 3 VA
Max. current consumption version 1236 V DC	100 mA (at 12 V DC) and 50 mA (at 36 V DC)
Max. current consumption version 115/230 V AC	55 mA
Pulse output (transistor) DO1 and DO4	polarized, potential-free
• type	NPN/PNP (wiring dependant)
DO1 function	pulse output (can be configured and parametered)
DO4 function	dosing state (can be configured and parametered)
• frequency (f)	• 300 Hz max.
electrical data	• 536 V DC, 100 mA max., voltage drop 2.7 V DC at 100 mA
duty cycle	• > 0.45
• protection	• galvanically insulated, and protected against overvoltages, polarity reversals and short-circuits



Relay output DO2 and DO3	To use the relay outputs in a wet location, observe the following DANGER safety instruction.
operating	hysteresis, adjustable thresholds, normally open
DO2 function	• valve 100 %, cannot be modified
DO3 function	alarm (can be configured and parametered)
electrical data of the load	• 230 V AC / 3 A or
(non UL recognized devices)	40 V DC / 3 A (resistive load)
 electrical data of the load (UL recognized devices) 	 max. 30 V AC and 42 V peak / 3 A or max. 60 V DC / 1 A
Digital inputs DI1 to DI4	1
• commutation threshold V _{on}	• 536 V DC
• commutation threshold V _{off} max.	• 2 V DC
min. pulse duration	• 100 ms
input impedance	• 9.4 kΩ
• protection	 galvanically isolated, and protected against polarity reversals and voltage spikes

\triangle

DANGER

Danger due to the operation of the relay outputs of a UL device in a wet location.

- ▶ If a UL device is used in a wet location:
- energize the relay outputs with an alternating voltage of max. 16 Vrms and 22.6 Vpeak.
- or energize the relay outputs with a direct voltage of max. 35 V DC.

6.2 Technical data of the dosing controller 8025 Batch in panel version

6.2.1 Conditions of use of a 8025 Batch in panel version

Ambient temperature	−10 °C+60 °C
Air humidity	< 80 %, non condensated
Height above sea level	≤ 2000 m
Operating conditions	Continuous
Equipment mobility	Fixed
Use	Indoor and outdoor
	(Protect the device against electromagnetic interference, ultraviolet rays
	and, when installed outdoors, against the effects of climatic conditions)
Installation category	Category I according to UL 61010-1 (UL device)
	Category II according to EN 61010-1 (non UL device)
Degree of pollution	Degree 2 according to UL/EN 61010-1
Protection rating according to IEC/EN 60529	
• front side	• IP65 ¹⁾ , installation completed and closed cabinet
non-front side	IP20 ¹⁾ in the closed cabinet

¹⁾ not evaluated by UL



6.2.2 Standards and directives

The device complies with the relevant EU harmonisation legislation. In addition, the device also complies with the requirements of the laws of the United Kingdom.

The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity/UK Declaration of Conformity.

UL-Certification

Finished products with variable key PU01 or PU02 are UL-certified products and comply also with the following standards:

- UL 61010-1
- CAN/CSA-C22.2 n°61010-1

Identification on the device	Certification	Variable key
c Fl °us	UL-recognized	PU01
CULUS Measuring Equipment EXXXXXX	UL-listed	PU02

6.2.3 Material data of a 8025 Batch in panel version

Part	Material
Housing /cover	PC
Frontfoil / Screws	Polyester / Stainless steel
Cable glands	PA
Identification label	Polyester

6.2.4 Dimensions of a 8025 Batch in panel version

→ Please refer to the technical data sheets regarding the dosing controller type 8025 Batch in panel version, available at: country.burkert.com.

6.2.5 Electrical data of a 8025 Batch in panel version

1236 V DC power supply	filtered and regulated
	• oscillation rate: ±10 %
	The device must be connected permanently to a Safety Extra-Low Voltage circuit (SELV circuit) or Protective Extra Low Voltage (PELV circuit).
Power source (not supplied)	Energize the device through a Limited Power Source
for versions supplied with 1236 V DC	(LPS) according to standards UL/EN 62368-1
	or through a limited-energy circuit according to
	standards UL/EN 61010-1, Paragraph 9.4.
Max. current consumption version 1236 V DC	70 mA (at 12 V DC) and
	45 mA (at 36 V DC)



Pulse output (transistor) DO1 and DO4	polarized, potential-free
• type	NPN/PNP (wiring dependant)
DO1 function	• pulse output (can be configured and parametered)
DO4 function	dosing state (can be configured and parametered)
• frequency (f)	• 2200 Hz max.
electrical data	• 536 V DC, 100 mA max., voltage drop 2.7 V DC at 100 mA
duty cycle	
- if 0.6 < f < 300 Hz	- > 0.45
- if 300 < f < 1500 Hz	- > 0.4
- if 1500 < f < 2200 Hz	- < 0.4
• protection	 galvanically insulated, and protected against over- voltages, polarity reversals and short-circuits
Relay output DO2 and DO3	To use the relay outputs in a wet location, observe the following DANGER safety instruction.
operating	hysteresis, adjustable thresholds, normally open
DO2 function	• valve 100 %, cannot be modified
DO3 function	 alarm (can be configured and parametered)
electrical data of the load	• 230 V AC / 3 A or
(non UL recognized devices)	40 V DC / 3 A (resistive load)
electrical data of the load	 max. 30 V AC and 42 V peak / 3 A or
(UL recognized devices)	max. 60 V DC / 1 A
Digital inputs DI1 to DI4	
commutation threshold V _{on}	• 536 V DC
• commutation threshold V _{off} max.	• 2 V DC
min. pulse duration	• 100 ms
input impedance	• 9.4 kΩ
• protection	 galvanically isolated, and protected against polarity reversals and voltage spikes



DANGER

Danger due to the operation of the relay outputs of a UL device in a wet location.

- ▶ If a UL device is used in a wet location:
- energize the relay outputs with an alternating voltage of max. 16 Vrms and 22.6 Vpeak.
- or energize the relay outputs with a direct voltage of max. 35 V DC.



6.2.6 Specifications of a remote flow sensor connected to a 8025 Batch in panel version

Signal from the remote sensor		
• type	 pulse, sine-wave (typical sensitivity 50 mV peak-to-peak at 250 Hz), "on/off", or standard voltage 05 V DC 	
• frequency	• 2200 Hz max., can be parametered	
• max. voltage	• 36 V DC	
Input impedance	depends on the position of selector "LOAD" on the electronic board of the 8025 Batch in panel version. See chapter 8.7 and 8.9.	
Power supply		
dosing controller supplied with a 1236 V DC voltage	supplied by the dosing controller depending on the position of selector "SENSOR SUPPLY" of the 8025 Batch in panel version, either:	
	• 5 V DC, 30 mA max.	
	• (L+) – 12V: supply voltage (L+) of the dosing controller minus 12 V DC (minus 12.5 V DC max.), 80 mA max.	
	• L+: supply voltage (L+) of the dosing controller (minus 1.5 V DC max.), 140 mA max.	

6.3 Technical data of the dosing controller 8025 Batch in wall-mounted version

6.3.1 Conditions of use of a 8025 Batch in wall-mounted version

Ambient temperature	−10 °C+60 °C
Air humidity	< 80 %, non condensated
Height above sea level	≤ 2000 m
Operating conditions	Continuous
Equipment mobility	Fixed
Use	Indoor and outdoor (Protect the device against electromagnetic interference, ultraviolet rays and, when installed outdoors, against the effects of climatic conditions)
Installation category	Category I according to UL 61010-1 (UL device) Category II according to EN 61010-1 (non UL device)
Degree of pollution	Degree 2 according to UL/EN 61010-1
Protection rating according to IEC/EN 60529	IP65 ¹⁾ , device wired, cable glands tightened, cover lid screwed tight and entry item nuts of the cable glands tightened at a screwing torque of 1.5 Nm (1.11 lbf·ft).

¹⁾ not evaluated by UL



6.3.2 Standards and directives

The device complies with the relevant EU harmonisation legislation. In addition, the device also complies with the requirements of the laws of the United Kingdom.

The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity/UK Declaration of Conformity.

UL-Certification

Finished products with variable key PU01 or PU02 are UL-certified products and comply also with the following standards:

- UL 61010-1
- CAN/CSA-C22.2 n°61010-1

Identification on the device	Certification	Variable key
c Al °us	UL-recognized	PU01
CULUS Measuring Equipment EXXXXXX	UL-listed	PU02

6.3.3 Material data of a 8025 Batch in wall-mounted version

Part	Material
Housing / Cover	ABS
Frontfoil / Screws	Polyester / Stainless steel
Cable glands	PA
Identification label	Polyester

6.3.4 Dimensions of a 8025 Batch in wall-mounted version

→ Please refer to the technical data sheets regarding the dosing controller type 8025 Batch in wall-mounted version, available at: country.burkert.com.

6.3.5 Electrical data of a 8025 Batch in wall-mounted version

1236 V DC power supply	filtered and regulated
	• oscillation rate: ±10 %
	 The device must be connected permanently to a Safety Extra-Low Voltage circuit (SELV circuit) or Protective Extra Low Voltage (PELV circuit).
Power source (not supplied)	Energize the device through a Limited Power Source
for versions supplied with 1236 V DC	(LPS) according to standards UL/EN 62368-1
	or through a limited-energy circuit according to
	standards UL/EN 61010-1, Paragraph 9.4.



115/000 V AQ naviar avents	
115/230 V AC power supply	40.0/
admissible voltage fluctuation	• ±10 %
• frequency	• 50/60 Hz
• supplied voltage	• 27 V DC, regulated
maximum current	• 250 mA
integrated protection	250 mA time-delay fuse
• power	• 6 VA
Maximum current consumption version	70 mA (at 12 V DC) and
1236 V DC	45 mA (at 36 V DC)
Maximum current consumption version 115/230 V AC	
Pulse output (transistor) DO1 and DO4	polarized, potential-free
• type	NPN/PNP (wiring dependant)
DO1 function	pulse output (can be configured and parametered)
DO4 function	dosing state (can be configured and parametered)
• frequency (f)	• 2200 Hz max.
electrical data	• 536 V DC, 100 mA max.,
	voltage drop 2.7 V DC at 100 mA
duty cycle	
- if 0.6 < f < 300 Hz	- > 0.45
- if 300 < f < 1500 Hz	- > 0.4
- if 1500 < f < 2200 Hz	- < 0.4
protection	galvanically insulated, and protected against over-
	voltages, polarity reversals and short-circuits
Relay output DO2 and DO3	To use the relay outputs in a wet location, observe
	the following DANGER safety instruction.
operating	hysteresis, adjustable thresholds, normally open
DO2 function	• valve 100 %, cannot be modified
DO3 function	 alarm (can be configured and parametered)
electrical data of the load	• 230 V AC / 3 A or
(non UL recognized devices)	40 V DC / 3 A (resistive load)
electrical data of the load	 max. 30 V AC and 42 V peak / 3 A or
(UL recognized devices)	max. 60 V DC / 1 A
Digital inputs DI1 to DI4	
commutation threshold V _{on}	• 536 V DC
• commutation threshold V _{off} max.	• 2 V DC
• min. pulse duration	• 100 ms
input impedance	• 9.4 kΩ
• protection	galvanically isolated, and protected against
	polarity reversals and voltage spikes
	Francisco de la companya de la compa



DANGER

Danger due to the operation of the relay outputs of a UL device in a wet location.

- ▶ If a UL device is used in a wet location:
 - energize the relay outputs with an alternating voltage of max. 16 Vrms and 22.6 Vpeak.
 - or energize the relay outputs with a direct voltage of max. 35 V DC.



6.3.6 Specifications of a remote flow sensor connected to a 8025 Batch in wall-mounted version

Signal from the remote senso	r
• type	 pulse, sine-wave (typical sensitivity 50 mV peak-to-peak at 250 Hz), "on/off", or standard voltage 05 V DC
frequency	• 2200 Hz max., can be parametered
• max. voltage	• 36 V DC
Input impedance	depends on the position of selector "LOAD" on the electronic board of the 8025 Batch in wall-mounted version. See chapter 8.8 and 8.9.
Power supply	
dosing controller supplied with a 1236 V DC voltage	 supplied by the dosing controller depending on the position of selector "SENSOR SUPPLY" of the 8025 Batch in wall-mounted version, either: 5 V DC, 30 mA max. (L+) – 12V: supply voltage (L+) of the dosing controller minus 12 V DC (minus 12.5 V DC max.), 80 mA max. L+: supply voltage (L+) of the dosing controller (minus 1.5 V DC max.), 140 mA max.
dosing controller supplied with a 115/230 V AC voltage	supplied by the dosing controller depending on the position of selector "SENSOR SUPPLY" of the 8025 in wall-mounted version, either: • 5 V DC, 30 mA max. • (L+) – 12V: 27 V DC minus 12 V DC (minus 12.5 V DC max.), 80 mA max. • L+: 27 V DC, 80 mA max.

6.4 Technical data of the dosing controller SE35 Batch



The technical data of the flow transmittedosing controller SE35 Batch can be restricted by the sensor-fitting used.

▶ Please refer to the Operating Instructions of the concerned sensor-fitting.

6.4.1 Conditions of use of a SE35 Batch

Ambient temperature	
• 1236 V DC version	● -10 °C+60 °C
• 115/230 V AC version	● -10 °C+50 °C
Air humidity	< 80 %, non condensated
Height above sea level	≤ 2000 m
Operating conditions	Continuous
Equipment mobility	Fixed
Use	Indoor and outdoor (Protect the device against electromagnetic interference, ultraviolet rays and, when installed outdoors, against the effects of climatic conditions)
Installation category	Category I according to UL 61010-1 (UL device)
	Category II according to EN 61010-1 (non UL device)
Degree of pollution	Degree 2 according to UL/EN 61010-1
Protection rating according to IEC/EN 60529	IP65 ¹⁾ , device wired, cover lid screwed tight and cable glands tightened

¹⁾ not evaluated by UL



6.4.2 Standards and directives

The device complies with the relevant EU harmonisation legislation. In addition, the device also complies with the requirements of the laws of the United Kingdom.

The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity/UK Declaration of Conformity.

UL-Certification

Finished products with variable key PU01 or PU02 are UL-certified products and comply also with the following standards:

- UL 61010-1
- CAN/CSA-C22.2 n°61010-1

Identification on the device	Certification	Variable key
c Al °us	UL-recognized	PU01
CULUS Measuring Equipment EXXXXXX	UL-listed	PU02

6.4.3 Material data of a SE35 Batch

Part	Material
Housing, cover, lid, nut	PC
Frontfoil / Screws	Polyester / Stainless steel
Cable glands	PA
Identification label	Polyester

6.4.4 Dimensions of a SE35 Batch

→ Please refer to the technical data sheet regarding the dosing controller type SE35 Batch, available at: country.burkert.com.



6.4.5 Electrical data of a SE35 Batch

40. 00 V DO	
1236 V DC power supply	• filtered and regulated
	• oscillation rate: ±10 %
	The device must be connected permanently to a
	Safety Extra-Low Voltage circuit (SELV circuit) or
	Protective Extra Low Voltage (PELV circuit).
Power source (not supplied)	Energize the device through a Limited Power Source
for versions supplied with 1236 V DC	(LPS) according to standards UL/EN 62368-1
	or through a limited-energy circuit according to
	standards UL/EN 61010-1, Paragraph 9.4.
115/230 V AC power supply	
admissible voltage fluctuation	• ±10 %
• frequency	• 50/60 Hz
supplied voltage	• 27 V DC, regulated
maximum current	• 125 mA
integrated protection	• 125 mA time-delay fuse
• power	• 3 VA
M	100 (. 1 10) / DO) 1
Maximum current consumption version 1236 V DC	100 mA (at 12 V DC) and
NA :	50 mA (at 36 V DC)
Maximum current consumption version 115/230 V AC	55 mA
Pulse output (transistor) DO1 and DO4	polarized, potential-free
• type	NPN/PNP (wiring dependant)
• DO1 function	pulse output (can be configured and parametered)
DO4 function	dosing state (can be configured and parametered)
• frequency (f)	• 300 Hz max.
electrical data	• 536 V DC, 100 mA max.,
	voltage drop 2.7 V DC at 100 mA
duty cycle	• > 0.45
• protection	galvanically insulated, and protected against over-
	voltages, polarity reversals and short-circuits
Relay output DO2 and DO3	To use the relay outputs in a wet location, observe
	the following DANGER safety instruction.
operating	hysteresis, adjustable thresholds, normally open
DO2 function	• valve 100 %, cannot be modified
DO3 function	alarm (can be configured and parametered)
electrical data of the load	• 230 V AC / 3 A or
(non UL recognized devices)	40 V DC / 3 A (resistive load)
electrical data of the load	• max. 30 V AC and 42 V peak / 3 A or
(UL recognized devices)	max. 60 V DC / 1 A
Digital inputs DI1 to DI4	
• commutation threshold V _{on}	• 536 V DC
• commutation threshold V _{off} max.	• 2 V DC
• min. pulse duration	• 100 ms
• input impedance	• 9.4 kΩ
• protection	galvanically isolated, and protected against
	polarity reversals and voltage spikes
	, , , , , , , , , , , , , , , , , , ,





DANGER

Danger due to the operation of the relay outputs of a UL device in a wet location.

- ▶ If a UL device is used in a wet location:
 - energize the relay outputs with an alternating voltage of max. 16 Vrms and 22.6 Vpeak.
 - or energize the relay outputs with a direct voltage of max. 35 V DC.

6.5 Technical data of the dosing controller 8035 Batch

The dosing controller 8035 Batch comprises an S030 sensor-fitting including the paddle-wheel flow sensor and a dosing controller type SE35 Batch (see chapter <u>5.2.5</u>).



The technical data of the dosing controller 8035 Batch may be restricted by the S030 sensor-fitting used.

▶ Please refer to the Operating Instructions of the concerned sensor-fitting S030.

6.5.1 Conditions of use of a 8035 Batch

Ambient temperature	
• 1236 V DC version	• −10 °C+60 °C
• 115/230 V AC version	● -10 °C+50 °C
Air humidity	< 80 %, non condensated
Height above sea level	≤ 2000 m
Operating conditions	Continuous
Equipment mobility	Fixed
Use	Indoor and outdoor
	(Protect the device against electromagnetic interference, ultraviolet rays and, when installed outdoors, against the effects of climatic conditions)
Installation category	Category I according to UL 61010-1 (UL device)
	Category II according to EN 61010-1 (non UL device)
Degree of pollution	Degree 2 according to UL/EN 61010-1
Protection rating according to	IP65 ¹⁾ , device wired, cover lid screwed tight and cable glands
IEC/EN 60529	tightened

¹⁾ not evaluated by UL

6.5.2 Standards and directives

The device complies with the relevant EU harmonisation legislation. In addition, the device also complies with the requirements of the laws of the United Kingdom.

The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity/UK Declaration of Conformity.

Conformity to the Pressure Equipment Directive

- ightarrow Make sure the device materials are compatible with the fluid.
- → Make sure the pipe DN is adapted for the device.



The device conforms to Article 4, Paragraph 1 of the Pressure Equipment Directive 2014/68/EU under the following conditions:

• Device used on a pipe (PS = maximum admissible pressure in bar; DN = nominal dimension of the pipe in mm)

Type of fluid	Conditions
Fluid group 1, Article 4, Paragraph 1.c.i	DN ≤ 25
Fluid averus O. Article 4. Developed 1 e.i.	DN ≤ 32
Fluid group 2, Article 4, Paragraph 1.c.i	or PSxDN ≤ 1000
Fluid group 1, Article 4, Paragraph 1.c.ii	DN ≤ 25
	or PSxDN ≤ 2000
	DN ≤ 200
Fluid group 2, Article 4, Paragraph 1.c.ii	or PS ≤ 10
	or PSxDN ≤ 5000

UL-Certification

Finished products with variable key PU01 or PU02 are UL-certified products and comply also with the following standards:

- UL 61010-1
- CAN/CSA-C22.2 n°61010-1

Identification on the device	Certification	Variable key
c FN ° US	UL-recognized	PU01
CULUS Measuring Equipment EXXXXXX	UL-listed	PU02

6.5.3 Fluid data of a 8035 Batch

Type of fluid	neutral or slightly aggressive liquids
Fluid viscosity	max. 300 cSt
Rate of solid particles	max. 1 %
Fluid temperature	The fluid temperature may be restricted by the fluid pressure and the material the S030 sensor-fitting used is made of (see Fig. 9).
with S030 sensor-fitting in PVC	• 0 °C+50 °C
with S030 sensor-fitting in PP	• 0 °C+80 °C
 with S030 sensor-fitting in PVDF, stainless steel or brass 	• –15 °C+100 °C
Fluid pressure	The fluid pressure may be restricted by the fluid temperature and the material the S030 sensor-fitting used is made (see Fig. 9).
with sensor-fitting S030 in plastic	PN10 ¹⁾
• with sensor-fitting S030 in metal	PN16 ¹⁾ (PN40 ¹⁾ on request)



Flow rate measurement	
Measurement range	• 0.310 m/s
Measurement deviation	
- with standard K-factor of the S020 fitting	- ±2.5 % of the measured value ²⁾
 with K-factor determined with a Teach-In procedure 	- ±1 % of the measured value ²⁾ (at the value of the Teach-In flow rate)
Linearity	• ±0.5 % of the full scale (10 m/s)
Repeatability	• ±0.4 % of the measured value ²⁾

¹⁾ not evaluated by UL

²⁾ Determined in the following reference conditions: medium = water, water and ambient temperatures 20 °C, min. upstream and downstream distances respected, appropriate pipe dimensions




Fig. 9: Fluid temperature/fluid pressure dependency curves for a dosing controller type 8035 Batch, depending on the material the S030 sensor-fitting is made of

6.5.4 Material data of a 8035 Batch

Part	Material
Housing, cover, lid, nut	PC
Frontfoil / Screws	Polyester / Stainless steel
Cable glands	PA
Identification label	Polyester
Wetted parts	
Sensor holder / Paddle-wheel	• PVDF
Axis and bearings of the paddle-wheel	Ceramics
Seal	FKM (optional EPDM)
Sensor-fitting S030	Refer to the Operating Instructions of the sensor-fitting



6.5.5 Dimensions of a 8035 Batch

→ Please refer to the technical data sheets regarding the dosing controller type 8035 Batch, available at: country.burkert.com.

6.5.6 Electrical data of a 8035 Batch

 \rightarrow Please refer to the electrical data of the dosing controller type SE35 Batch, chapter <u>6.4.5</u>.

6.6 Technical data of the dosing controller SE35 Batch associated with a sensor-fitting S070 or S077



The technical data of the dosing controller SE35 Batch may be restricted by the S070 or S077 sensor-fitting used.

▶ Please refer to the Operating Instructions of the concerned sensor-fitting S070 or S077.

6.6.1 Conditions of use of a SE35 Batch with a S070 or a S077

Ambient temperature	
• 1236 V DC version	● -10 °C+60 °C
• 115/230 V AC version	● -10 °C+50 °C
Air humidity	< 80 %, non condensated
Height above sea level	≤ 2000 m
Operating conditions	Continuous
Equipment mobility	Fixed
Use	Indoor and outdoor
	(Protect the device against electromagnetic interference, ultraviolet rays and, when installed outdoors, against the effects of climatic conditions)
Installation category	Category I according to UL 61010-1 (UL device)
	Category II according to EN 61010-1 (non UL device)
Degree of pollution	Degree 2 according to UL/EN 61010-1
Protection rating according to	IP65 ¹⁾ , device wired, cover lid screwed tight and cable glands
IEC/EN 60529	tightened

¹⁾ not evaluated by UL

6.6.2 Standards and directives

The device complies with the relevant EU harmonisation legislation. In addition, the device also complies with the requirements of the laws of the United Kingdom.

The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity/UK Declaration of Conformity.

Conformity to the Pressure Equipment Directive

- → Make sure the device materials are compatible with the fluid.
- → Make sure the pipe DN is adapted for the device.



The device conforms to Article 4, Paragraph 1 of the Pressure Equipment Directive 2014/68/EU under the following conditions:

• Device used on a pipe (PS = maximum admissible pressure in bar; DN = nominal dimension of the pipe in mm)

Type of fluid	Conditions
Fluid group 1, Article 4, Paragraph 1.c.i	DN ≤ 25
Fluid group 2, Article 4, Paragraph 1.c.i	DN ≤ 32
Fluid group 2, Article 4, Faragraph 1.c.i	or PSxDN ≤ 1000
Fluid group 1, Article 4, Paragraph 1.c.ii	DN ≤ 25
Tidio group 1, Article 4, Faragraph 1.C.II	or PSxDN ≤ 2000
	DN ≤ 200
Fluid group 2, Article 4, Paragraph 1.c.ii	or PS ≤ 10
	or PSxDN ≤ 5000

6.6.3 Fluid data of a SE35 Batch with a S070 or a S077

Type of fluid	Please refer to the Operating Instructions of the concerned sensor- fitting S070 or S077
Fluid temperature	The fluid temperature may be restricted by the fluid pressure and the material the S070 or S077 sensor-fitting used is made of
	Please refer to the Operating Instructions delivered with the sensor- fitting S070 or S077 or to the concerned technical datasheets
Fluid pressure	The fluid pressure may be restricted by the fluid temperature and the material the S070 or S077 sensor-fitting used is made of
	• Please refer to the Operating Instructions delivered with the sensor- fitting S070 or S077 or to the concerned technical datasheets
Flow rate measurement	
Measurement range	
- viscosity > 5 mPa.s	- S070 : 21200 I/min
	- S077 : 21200 I/min
- viscosity < 5 mPa.s	- S070 : 3616 I/min
	- S077 : 3616 I/min
Measurement deviation	
 with standard K-factor of the sensor-fitting 	- S070: ±0.5 % of the measured value 1)
	- S077: ±1 % of the measured value 1)
- with K-factor determined with a teach-in procedure	- S070 : ±0.5 % of the measured value ¹⁾ (at the value of the teach-in flow rate)
	- S077 : ± 0.5 % of the measured value $^{1)}$ (at the value of the teach-in flow rate)
Repeatability	• ±0.03 % of the measured value 1)

¹⁾ Determined in the following reference conditions: medium = water, water and ambient temperatures 20 °C, min. upstream and downstream distances respected, appropriate pipe dimensions



6.6.4 Material data of a SE35 Batch with a S070 or a S077

Part	Material
Housing, cover, lid, nut	PC
Frontfoil / Screws	Polyester / Stainless steel
Cable glands	PA
Identification label	Polyester
Wetted parts	
Sensor-fitting S070	Refer to the Operating Instructions of the con- cerned sensor-fitting

6.6.5 Dimensions of a SE35 Batch with a S070 or a S077

→ Please refer to the technical data sheets regarding the dosing controller type SE35 Batch and the sensor-fittings type S070 and S077, available at: country.burkert.com.

6.6.6 Electrical data of a SE35 Batch with a S070 or a S077

 \rightarrow Please refer to the electrical data of the dosing controller type SE35 Batch, chapter <u>6.4.5</u>.



7 FLUID INSTALLATION

7.1 Safety instructions



DANGER

Danger due to electrical voltage.

- ▶ If a 12...36 V DC powered version is installed either in a wet environment or outdoors, all the electrical voltages must be of max. 35 V DC.
- ▶ Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- ▶ All equipment connected to the wall-mounted or panel version of the device must be double insulated in relation to the mains in accordance with standard UL/EN 61010-1.
- Observe all applicable accident protection and safety regulations for electrical equipment.

Risk of injury due to high pressure in the installation.

- Stop the circulation of fluid, cut off the pressure and drain the pipe before loosening the process connections.
- ▶ Observe the fluid temperature/fluid pressure dependency depending on the fitting used.

Risk of injury due to high fluid temperatures.

- ▶ Use safety gloves to handle the device.
- ► Stop the circulation of fluid and drain the pipe before loosening the process connections.

Risk of injury due to the nature of the fluid.

▶ Respect the prevailing regulations on accident prevention and safety relating to the use of aggressive fluids.



WARNING

Risk of injury due to non-conforming installation.

- ▶ The fluid and electrical installation can only be carried out by qualified and skilled staff with the appropriate tools.
- ▶ Observe mounting instructions of the fitting or sensor-fitting.



WARNING

Risk of injury due to unintentional switch on of power supply or uncontrolled restarting of the installation.

- ▶ Take appropriate measures to avoid unintentional activation of the installation.
- ► Guarantee a set or controlled restarting of the process subsequent to any intervention on the product.



WARNING

Risk of injury if the fluid temperature/fluid pressure dependency is not respected.

- ► Take account of fluid temperature/fluid pressure dependency according to the nature of the materials the fitting is made of (see the technical data and the Operating Instructions of the fitting used).
- ► Comply with the Pressure Equipment Directive 2014/68/EU.





A device with cable glands can be damaged if it is not tight.

▶ Insert the supplied blanking plugs into the unused cable glands to ensure the tightness of the device.



Protect this device against electromagnetic interference, ultraviolet rays and, when installed outdoors, the effects of the climatic conditions.

7.2 Installation of the dosing controller type 8025 Batch in compact version

The dosing controller 8025 Batch is inserted into an S020 fitting mounted on the pipes:

- 1. Install the S020 fitting on the pipes,
- 2. Install the 8025 Batch in compact version into the S020 fitting,
- 3. Finalise the installation of the 8025 Batch in compact version.

7.2.1 Install the S020 fitting on the pipes

ightarrow Select an S020 fitting suitable for the speed of the fluid in the pipes



To select a fitting, refer to the calculation tables on the technical data sheet for the relevant fitting.

- → Choose a position for the fitting according to the design of the pipes, in such a way that:
 - the upstream and downstream distances are respected according to the design of the pipes, see Fig. 10 and norm EN ISO 5167-1,
 - the pipes are always filled to the level of the sensor (see Fig. 11),
 - when mounted vertically, the flow direction of the fluid is upwards (see Fig. 11),
 - air bubbles do not form around the sensor (see Fig. 11).
- → If necessary, use a flow conditioner to improve measurement precision,
- → Install the fitting on the pipes according to the instructions in the relevant Operating Instructions.






Fig. 10: Upstream and downstream distances depending on the design of the pipes.





Fig. 11: Filling of the pipe, flow direction of the fluid, Vertical mounting Air bubbles within the pipe



7.2.2 Install the 8025 Batch in compact version into the S020 fitting



- \rightarrow Install the fitting 4 onto the pipe following the instructions in chapter 7.2.1.
- → Check that there is a seal 6 on the device 1 and that it is not damaged. Replace the seal if necessary.
- → Insert the nut 3 on the fitting 4.
- \rightarrow Insert the snap ring 2 into the groove 5.
- \rightarrow Check that the seal 6 is correctly inserted on the device 1.
- → Insert the device 1 into the fitting 4.

If the mounting is correctly done the device 1 cannot be turned around anymore.

 \rightarrow Hand lock the assembly with nut 3.

Fig. 12: Installation of a 8025 Batch in compact version into an S020 fitting

7.2.3 Finalise the installation of the 8025 Batch in compact version

- \rightarrow Wire the device and switch it on (see chapter 8).
- \rightarrow Set the K-factor or determine it with Teach-In (see chapter <u>10.7.3</u> or <u>10.7.4</u>).

7.3 Installation of the dosing controller 8035 Batch

The dosing controller type 8035 Batch comprises a dosing controller type SE35 Batch and a sensor-fitting type S030. The dosing controller SE35 Batch is assembled on the sensor-fitting S030 by a quarter-turn rotation system:

- 1. Install the S030 sensor-fitting on the pipes,
- 2. Install the dosing controller SE35 Batch on the sensor-fitting S030,
- 3. Finalise the installation of the 8035 Batch.

7.3.1 Install the S030 sensor-fitting on the pipes

→ Select a sensor-fitting S020 suitable for the speed of the fluid in the pipes.




To select a sensor-fitting, refer to the calculation tables on the technical data sheet for the relevant sensor-fitting.

- → Choose a position for the sensor-fitting according to the design of the pipes, in such a way that:
 - the upstream and downstream distances are respected according to the design of the pipes, see Fig. 10, chapter 7.2.1 and norm EN ISO 5167-1,
 - the pipes are always filled to the level of the sensor (see Fig. 11, chapter 7.2.1),
 - when mounted vertically, the flow direction of the fluid is upwards (see Fig. 11, chapter 7.2.1),
- air bubbles do not form around the sensor-fitting (see Fig. 11, chapter 7.2.1).
- → If necessary, use a flow conditioner to improve measurement precision,
- → Install the sensor-fitting on the pipes according to the instructions in the relevant Operating Instructions.



7.3.2 Install the dosing controller SE35 Batch on the sensor-fitting S030



- → Install the dosing controller 2 in the sensor-fitting 1.
- → Turn the dosing controller 2 by a quarter turn.
- → Tighten the lateral screw(s) 3 to lock the dosing controller in place on the sensor-fitting.

Fig. 13: Installation of the dosing controller SE35 Batch on the sensor-fitting S030

7.3.3 Finalise the installation of the 8035 Batch

- \rightarrow Wire the device and switch it on (see chapter 8).
- \rightarrow Set the K-factor or determine it with Teach-In (see chapter 10.7.3 or 10.7.4).

7.4 Installation of the dosing controller SE35 Batch on the sensor-fitting S070 or S077

The dosing controller SE35 Batch is installed on the pipes using the sensor-fitting S070 or S077. The dosing controller SE35 Batch is assembled on the sensor-fitting S070 or S077 by a quarter-turn system:

- 1. Install the sensor-fitting S070 or S077 on the pipes,
- 2. Install the dosing controller SE35 Batch on the sensor-fitting S070 or S077,
- 3. Finalise the installation.

7.4.1 Install the sensor-fitting S070 or S077 on the pipes

→ Select a sensor-fitting S070 or S077 suitable for the viscosity of the fluid.



To select a sensor-fitting, refer to the technical data sheet for the relevant sensor-fitting.



CAUTION

Risk of damage when installing the sensor-fitting.

► Follow the installation instructions given in the Operating Instructions for the sensor-fitting.



- → Install the sensor-fitting S070 or S077 on the pipes in such a way that:
 - the axles of the oval gears are set horizontally, as shown in Fig. 14,
 - the installation instructions given in the Operating Instructions for the relevant sensor-fitting are respected.





Fig. 14: The axle of the oval gears must be horizontal

7.4.2 Install the dosing controller SE35 Batch on the sensor-fitting S070 or S077



- ightarrow Insert the dosing controller 1 in the sensor-fitting 2.
- → Turn the dosing controller 1 by a quarter turn.
- → Tighten the lateral screw(s) 3 to lock the dosing controller 1 in place on the sensor-fitting 2 (max. torque 1 Nm).

Fig. 15: Installation of the dosing controller SE35 Batch on the sensor-fitting S070 or S077

7.4.3 Finalise the installation

- \rightarrow Wire the device and switch it on (see chapter 8).
- \rightarrow Set the K-factor or determine it with Teach-In (see chapter 10.7.3 or 10.7.4).



7.5 Installation of the dosing controller 8025 Batch in panel version



Install the 8025 Batch in panel version in a cabinet with a protection class at least IP54 to ensure a degree of pollution 2 inside the cabinet.

 \rightarrow Respect the dimensions indicated in Fig. 16 to cut the opening in the cabinet door.




Fig. 16: Dimensions [mm] of the electrical cabinet frontage cutting plan




Fig. 17: Installation of the 8025 Batch in panel version

- → Insert the 4 screws in the housing (from the front). If the cabinet door is too thick use the 4 supplied M4*25 screws.
- → Insert the seal on the external threads of the 4 screws (rear of the housing).
- → Put the assembly on the cutout, electronics turned to the inside of the cabinet.
- → Put the 4 washers on the 4 screws.
- → Put a nut on each of the 4 screws and tighten the nuts to secure the device to the cabinet.
- \rightarrow Wire the device according to the instructions in chapter 8.7.
- \rightarrow Set the K-factor or determine it with Teach-In (see chapter 10.7.3 or 10.7.4).



7.6 Installation of the dosing controller 8025 Batch in wall-mounted version

NOTICE

Risk of material damage if the cable glands are not tightly screwed on the housing

▶ Before installing the wall-mounted housing on its support, tighten the nuts of the entry item of the cables glands at a torque of 1.5 Nm (1.11 lbf·ft).

The device in a wall-mounted version has 4 holes in the bottom of the housing.

→ Remove the blanking strips covering the screws.




Fig. 18: Location of the fastening nuts and the blanking strips

→ Loosen the 4 screws and open the cover to get access to the holes [1].




Fig. 19: Installation of the dosing controller 8025 Batch in wall-mounted version

- → Secure the housing to the support respecting the dimensions indicated in Fig. 19.
- → Wire according to the instructions in chapter 8.8.
- \rightarrow Close the housing and tighten the 4 screws of the cover.
- \rightarrow Set the K-factor or determine it with Teach-In (see chapter 10.7.3 or 10.7.4).

burkert

8 ELECTRICAL INSTALLATION AND WIRING

8.1 Safety instructions



DANGER

Danger due to electrical voltage.

- ▶ If a 12...36 V DC powered version is installed either in a wet environment or outdoors, all the electrical voltages must be of max. 35 V DC.
- ▶ Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- ▶ All equipment connected to the wall-mounted or panel version of the device must be double insulated in relation to the mains in accordance with standard UL/EN 61010-1.
- ► Observe all applicable accident protection and safety regulations for electrical equipment.

Risk of injury due to high pressure in the installation.

- Stop the circulation of fluid, cut off the pressure and drain the pipe before loosening the process connections.
- ► Observe the fluid temperature/fluid pressure dependency depending on the fitting used.

Risk of injury due to high fluid temperatures.

- ▶ Use safety gloves to handle the device.
- Stop the circulation of fluid and drain the pipe before loosening the process connections.

Risk of injury due to the nature of the fluid.

Respect the prevailing regulations on accident prevention and safety relating to the use of aggressive fluids.



DANGER

Danger due to the operation of the relay outputs of a UL device in a wet location.

- ▶ If a UL device is used in a wet location:
 - energize the relay outputs with an alternating voltage of max. 16 Vrms and 22.6 Vpeak.
 - or energize the relay outputs with a direct voltage of max. 35 V DC.



WARNING

Risk of injury due to non-conforming installation.

- ▶ The electrical and fluid installation can only be carried out by qualified and skilled staff with the appropriate tools.
- ▶ Install appropriate safety devices (correctly rated fuse and/or circuit-breaker).
- ▶ Install the circuit breaker or switch in a place which is easy to reach.
- Identify the circuit breaker or switch as the device's electrical power cut-off system.





WARNING

Risk of injury due to non-conforming installation (continued).

- ▶ It is imperative that devices be used that provide adequate protection against overloads. For the versions powered at 115/230 V AC, insert the device protecting against overcurrents in the live conductor (L) and in the neutral conductor (N).
- ▶ Do not power a device, version 12...36 V DC, with an alternating voltage or with a direct voltage in excess of 36 V DC.
- ▶ Observe the standard NF C 15-100 / IEC 60364.



WARNING

Risk of injury due to unintentional switch on of power supply or uncontrolled restarting of the installation.

- ► Take appropriate measures to avoid unintentional activation of the installation.
- ► Guarantee a set or controlled restarting of the process subsequent to any intervention on the device.

NOTICE

Risk of damage to the device if the incorrect supply voltage is applied.

► Energize the device with a supply voltage in accordance with the position of the selector. See <u>Fig. 27</u>, chapter <u>8.6</u>.



For a correct operation of the device, respect the following recommendations during the electrical installation:

- Make sure the installation is equipotential. See chapter 8.3.
- Do not install the cables near high voltage or high frequency cables; if a combined installation cannot be avoided, a minimum clearance of 30 cm should be respected.

For a device fed at 12...36 V DC, respect the following recommendations for the electrical installation:

- Use a filtered and regulated 12...36 V DC power supply. The circuit has to be safety extra low voltage (SELV) or Protective Extra Low Voltage (PELV circuit), with a safe energy level.
- The power supply of the device can be damaged if it is not protected.
 - Protect the device power supply by means of a 300 mA slow blow fuse and a switch.

The power supply of a transistor output can be damaged if it is not protected.


Protect the power supply of each transistor output by means of a 125 mA slow blow fuse.

- - The relays can be damaged if not protected.
 - Protect the relays by means of a max. 3 A fuse and a circuit breaker (depending on the process).
 - Do not apply both a dangerous voltage and a safety extra-low voltage to the relays.

A device with cable glands can be damaged if it is not tight.

• Insert the supplied blanking plugs into the unused cable glands to ensure the tightness of the device.

burkert



Protect this device against electromagnetic interference, ultraviolet rays and, when installed outdoors, the effects of the climatic conditions.

8.2 Specifications of the connection cables

8.2.1 Dosing controller 8025 Batch in compact version, 8035 Batch and SE35 Batch

The electrical connection is done via terminal blocks and via two M20x1.5 cable glands.

Tab. 1: Specifications of the cables and wires for the wiring through the M20x1.5 cable glands

Specifications of cables and conductors	Recommended values
Cable type	Shielded (not supplied)
Cross section of wires	• 0.21.5 mm ²
Diameter of each cable if only one cable is used per cable gland	• 612 mm
Diameter of each cable if two cables are used per cable gland	• 4 mm, with the supplied multi-way seal
Length	• max. 50 m
Operating temperature	• min. 80 °C (min. 90 °C for UL recognized version)

8.2.2 Dosing controller 8025 Batch in panel version

The electrical connection is done directly on the terminal blocks of the electronics.

Tab. 2: Specifications of the cables and wires for the direct wiring to the terminal blocks of a panel-mounted version

Specifications of cables and conductors	Recommended values
Cable type	Shielded (not supplied)
Cross section of wires	• 0.21.5 mm ²
Length	• max. 50 m
Operating temperature	• min. 80 °C (min. 90 °C for UL recognized version)

8.2.3 Dosing controller 8025 Batch in wall-mounting version

The electrical connection is done via terminal blocks and via five M16x1.5 cable glands.

Tab. 3: Specifications of the cables and wires for the wiring through the M16x1.5 cable glands

Specifications of cables and conductors	Recommended values
Cable type	Shielded (not supplied)
Cross section of wires	• 0.21.5 mm ²
Diameter of each cable if only one cable is used per cable gland	• 58 mm
Length	• max. 50 m
Operating temperature	• min. 80 °C



8.3 Equipotentiality of the installation

To ensure the equipotentiality of the installation (power supply - device - fluid):

- → Connect together the various earth spots in the installation to eliminate the potential differences that may occur between different earthes.
- → Observe faultless earthing of the shield of the power supply cable, at both ends.
- → Connect the negative power supply terminal to the earth to suppress the effects of common mode currents. If this connection cannot be made directly, a 100 nF/50 V capacitor can be fitted between the negative power supply terminal and the earth.
- → Special attention has to be paid if the device is installed on plastic pipes because there is no direct earthing possible. Proper earthing is performed by earthing together the metallic instruments such as pumps or valves, that are as close as possible to the device. If no such instrument is near the device, insert metallic earth rings inside the plastic pipes upstream and downstream the device and connect these parts to the same earth. The earth rings must be in contact with the fluid.




Fig. 20: 8025 Batch in compact version, 8035 Batch and SE35 Batch, equipotentiality skeleton diagrams






Fig. 21: 8025 Batch in panel-mounted or in wall-mounted version, equipotentiality skeleton diagram

8.4 Default position of the selectors


Only move the selectors when the power supply is off.

Tab. 4: Default positions of selectors "SENSOR SUPPLY", "LOAD" and "SENSOR TYPE"

Selector	Default position
SENSOR SUPPLY (A)	L+
LOAD (B)	2.2K
SENSOR TYPE (©)	NPN/PNP



8.5 Terminal assignment and use of the selectors



Terminal block 1

- NC: not connected
- L+: V+ (positive voltage)
- L-: 0V (power supply ground)
- PE: protective earth, factory wired
- P-: negative transistor output (DO1)
- P+: positive transistor output (DO1)

Terminal block 2

PE: shieldings of the power supply cable and the input / output cables

Terminal block 3: wiring the DO2 relay output.

Terminal block 4: wiring the DO3 relay output.

Connector 5: connection of the flow sensor

Terminal block 6 "BINARY"


- DI1 to DI4: 4 digital inputs
- DO4: transistor output
- ISOG: ISOGND, ground common to the 4 digital inputs and the transistor output DO4.
- PE: cable shielding

Selector B: see chapter 8.6.

Selector ©: see chapter 8.6.

Fig. 22: Terminal assignment of a 12...36 V DC fed version for the 8025 Batch in compact version, for the 8035 Batch and for the SE35 Batch





Terminal block 1

- NC: not connected
- L+: V+ (positive voltage)
- L-: 0V (power supply ground)
- PE: protective earth, factory wired
- P-: negative transistor output (DO1)
- P+: positive transistor output (DO1)

Terminal block 2

PE: shieldings of the power supply cable and the input / output cables

Terminal block 3: wiring the DO2 relay output.

Terminal block 4: wiring the DO3 relay output.

Terminal block 5 "FLOW SENSOR": Wiring the remote flow sensor. The wiring depends on the type of output signal originating from the flow sensor: See chapter 8.9.

Terminal block 6 "BINARY"

- DI1 to DI4: 4 digital inputs
- DO4: transistor output
- ISOG: ISOGND, ground common to the 4 digital inputs and the transistor output DO4.
- PE: cable shielding


Selector \triangle : see chapter 8.9.

Selector B: see Tab. 6, page 57.

Selector ©: see chapter 8.9.

Fig. 23: Terminal assignment of a 12...36 V DC fed version for the 8025 Batch in panel-mounted or in wall-mounted version





Terminal block 1

PE: shieldings of the power supply cable and the input / output cables

Terminal block 2

- NC: not connected
- L+: V+ (red wire, factory wired)
- L-: 0V (black wire, factory wired)
- PE: protective earth (green/yellow wire, factory wired)
- P-: negative transistor output (DO1)
- P+: positive transistor output (DO1)

Connector 3: connection of the flow sensor

Terminal block 4 "BINARY"

- DI1 to DI4: 4 digital inputs
- DO4: transistor output
- ISOG: ISOGND, ground common to the 4 digital inputs and the transistor output DO4.
- PE: cable shielding

Terminal block 5: wiring the DO2 relay output.

Terminal block 6: wiring the DO3 relay output.

Terminal block 7: wiring of the 115/230 V AC power supply

Mark 8: time-delay fuse to protect the 115/230 V AC power supply

Selector (A): see chapter 8.6;


Selector B: see chapter 8.6;

Selector ©: see chapter 8.6.

Selector D: see chapter 8.6.

Fig. 24: Terminal assignment of a 115/230 V AC fed version for the 8025 Batch in compact version, for the 8035 Batch and for the SE35 Batch





Terminal block 1

PE: factory wired shield.

Terminal block 2

- NC: not connected
- L+: V+ (red wire, factory wired)
- L-: 0V (black wire, factory wired)
- PE: protective earth, factory wired
- P-: negative transistor output (DO1) (brown wire, factory wired)
- P+: positive transistor output (DO1) (white wire, factory wired)

Terminal block 3 "BINARY"

- DI1 to DI4: 4 digital inputs
- DO4: transistor output
- ISOG: ISOGND, ground common to the 4 digital inputs and the transistor output DO4.
- PE: cable shielding

Terminal block 4 "FLOW SENSOR": Wiring the remote flow sensor. The wiring depends on the type of output signal originating from the flow sensor: see chapter 8.9.

Terminal block 5: wiring the DO2 relay output.

Terminal block 6: wiring the DO3 relay output.

Terminal block 7

- terminal 5 not connected
- terminal 6: positive 27 V DC power supply, available to energize an external instrument
- terminal 7: 0V (earth of the power supply available to energize an external instrument)
- terminal 8: protective earth for the cable shieldings
- terminal 9: negative transistor output (DO1)
- terminal 10: positive transistor output (DO1)

Terminal block 8: wiring of the 115/230 V AC power supply

Mark 9: time-delay fuse to protect the 115/230 V AC power supply

Selector (A): see chapter 8.9.

Selector B: see Tab. 6, page 57.

Selector ©: see chapter 8.9.

Selector D: see chapter 8.9.

Fig. 25: Terminal assignment of a 8025 Batch in wall-mounted version, fed with 115/230 V AC

Wiring the 8025 Batch in compact version, the 8.6 8035 Batch or the SE35 Batch

- Only move the selectors when the power supply is off.
- Insert the supplied blanking plug into the unused cable gland to ensure the tightness of the device.
 - Unscrew the unused cable gland.
 - Remove the transparent disk.
 - Insert the supplied blanking plug.
 - Screw the nut of the cable gland.
- → Set the selector "SENSOR TYPE" on "NPN/PNP" (default position).
- Never set selector "SENSOR TYPE" on "COIL" on a compact version.

Selector © makes it possible to configure the type of signal received from the flow sensor.




Fig. 26: Using selector "SENSOR TYPE" on the 8025 Batch in compact version, the 8035 Batch or the SE35 Batch

- → Set selector "SENSOR SUPPLY" depending on the value of the power supply of the device. See <u>Tab. 5</u>.
- \rightarrow Set selector "LOAD": See <u>Tab. 5</u>.



Tab. 5: Position of selectors "SENSOR TYPE", "SENSOR SUPPLY" and "LOAD" on the 8025 Batch in compact version, the 8035 Batch or the SE35 Batch

Selector "SENSOR TYPE"	Selector "SENSOR SUPPLY" SENSOR +5V L+ (L+)-12V	Selector "LOAD" 470 2.2K 39K NP OT
→ Set the selector on "NPN/PNP" (Fig. 26)	The flow sensor of the device needs a minimum voltage supply of 5 V DC: → If the device is fed with a voltage ≥ 12 V DC and < 17 V DC, set the voltage selector "SENSOR SUPPLY" on "5V" or "L+". → If the device is fed with a voltage ≥ 17 V DC, the voltage selector "SENSOR SUPPLY" can be set to any position. → If the device is fed with a 115/230V AC voltage, set the voltage selector "SENSOR SUPPLY" on "L+".	 → Set selector "LOAD": • either on "2.2K": the load resistance R is then 2.2 kΩ • either on "470": the load resistance R is then 470 Ω

 \rightarrow If the device is energized with a 115/230 V AC power supply, set selector \bigcirc as shown in Fig. 27.




Fig. 27: Selector of the supply voltage on a 115/230 V AC version




Fig. 28: Inserting the cable clips

- \rightarrow Install the device as described in chapter 7.2, 7.3 or 7.4.
- \rightarrow Wire according to chapter 8.11, 8.14 and 10.6.
- \rightarrow Secure the power supply cable and the relay connection cables, with the cable clips.
- → Close the housing and tighten the 4 screws of the cover.



8.7 Wiring the 8025 Batch in panel version



Only move the selectors when the power supply is off.

- \rightarrow Install the device as described in chapter <u>7.5</u>.
- → Set the selectors "SENSOR TYPE", "SENSOR SUPPLY" and "LOAD": see chapter <u>8.9 Connecting the</u> remote flow sensor to a 8025 Batch in panel-mounted or in wall-mounted version.



→ Before wiring the device insert the supplied cable clips into the slots of the electronic board.

Fig. 29: Inserting the cable clips

- \rightarrow Wire according to chapter 8.9, 8.11, 8.14 and 10.6.
- → Secure the power supply cable, the flow sensor connection cable and the relay connection cables, with the cable clips.

8.8 Wiring the 8025 Batch in wall-mounted version



Only move the selectors when the power supply is off.



Insert the supplied blanking plugs into the unused cable glands to ensure the tightness of the device.

- Unscrew the unused cable gland.
- Remove the transparent disk.
- Insert the supplied blanking plug.
- Screw the nut of the cable gland.
- → Install the device as described in chapter 7.6.
- → Set the selectors "SENSOR TYPE", "SENSOR SUPPLY" and "LOAD": see chapter <u>8.9 Connecting the</u> remote flow sensor to a 8025 Batch in panel-mounted or in wall-mounted version.
- → If the wall-mounted version is energized with a 115/230 V AC power supply, set selector ② as shown in Fig. 30.




Fig. 30: Selector of the supply voltage on a 115/230 V AC version



- → Loosen the nuts of the cable glands.
- → Insert each cable through a nut than through the cable gland, using the cable glands as shown in Fig. 31.




Fig. 31: Using the cable glands on a wall-mounted version

 \rightarrow On a 115/230 V AC fed wall-mounted version, remove both terminal blocks (marked 7 and 8 in Fig. 25) from the housing.




Fig. 32: Inserting the cable clips

- \rightarrow Depending on the operating voltage of the device, wire according to chapter 8.9, 8.11 to 8.14 and 10.6.
- → Insert the two terminal blocks (marked 7 and 8 in Fig. 25, page 51) into their original position.
- → Letting the housing stay completely open, secure the power supply cable, the flow sensor connection cable and the relay connection cables, with the cable clips.
- → Tighten the cable glands making sure the cable in the housing is long enough to allow complete opening of the housing.
- \rightarrow Close the cover.
- → Tighten the 4 screws.
- → Put the blanking strips on the housing.



8.9 Connecting the remote flow sensor to a 8025 Batch in panel-mounted or in wall-mounted version



Only move the selectors when the power supply is off.



Before connecting the flow sensor to the dosing controller 8025 Batch, in panel-mounted or in wallmounted version:

- Set selector "SENSOR TYPE" depending on the output signal originating from the flow sensor. See Fig. 33 and Tab. 6, page 57.
- If selector "SENSOR TYPE" is set on "NPN/PNP", set selector "SENSOR SUPPLY" depending on the dosing controller supply voltage. See Fig. 34 and Tab. 6, page 57.
- Set selector "LOAD" depending on the type of signal sent out by the flow sensor and on the load wanted on terminal 1 "PULSE INPUT" of terminal block "FLOW SENSOR". See Tab. 6, page 57.

Selector © makes it possible to configure the type of signal the device, receives from the remote flow sensor.



Set the selector on "NPN/PNP" (default position) when

C

• a pulse signal, NPN or PNP

device is either:

- an "on/off" signal (Reed relay for example)
- a 0...5 V DC standard voltage signal (TTL, for example)

the signal from the flow sensor which is connected to the




→ Set the selector on "COIL" when the signal from the flow sensor which is connected to the device is a sinewave signal (coil).

Fig. 33: Using selector "SENSOR TYPE" on the 8025 Batch in panel or in wall-mounted version

When selector "SENSOR TYPE" above is set on "NPN/PNP", selector (A) makes it possible to configure the supply voltage for the remote flow sensor.





- → If the device is energized with a 115/230 V AC power supply, set selector "SENSOR SUPPLY" on "L+" (default position).
- → If the device is energized with a 12...36 V DC power supply, set the voltage selector "SENSOR SUPPLY" depending on the voltage supply needed by the remote flow sensor: "+5V", "L+" or "(L+)-12V" (default position).

Fig. 34: Using selector "SENSOR SUPPLY" on the 8025 Batch in panel or in wall-mounted version



Tab. 6: Position of selectors "SENSOR TYPE" and "LOAD" of the 8025 Batch in panel or in wall-mounted version, and terminal assignment of terminal block "FLOW SENSOR" depending on the signal emitted by the remote flow sensor

rem	note flow sensor			
Type of signal emitted by the remote flow sensor	Selector "SENSOR TYPE"	Selector "SENSOR SUPPLY" (A)	Selector "LOAD" 470 2.2K 39K PO	Terminal assignment of terminal block "FLOW SENSOR"
sine-wave (coil)	→ Set the selector on "COIL" (Fig. 33)	→ Any position.	→ Set selector "LOAD" on "39K": the input impedance on terminals 1 and 2 of terminal block "FLOW SENSOR" will then be 39 kΩ	8025 39 kΩ NC 1 2 3 PE 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
pulse, PNP	→ Set the selector on "NPN/PNP" (Fig. 33)	→ Set the selector as shown in Fig. 34.	Set selector "LOAD" on "39K": the input impedance on terminals 1 and 2 of terminal block "FLOW SENSOR" will then be 39 kΩ	8025 39 kΩ 1 2 3 PE 1 2 3 PE Flow sensor
05 V DC standard voltage signal (TTL, for example)	→ Set the selector on "NPN/PNP" (Fig. 33)	→ Set the selector as shown in Fig. 34.	Set selector "LOAD" on "39K": the input impedance on terminals 1 and 2 of terminal block "FLOW SENSOR" will then be 39 kΩ	8025 39 kΩ 1 2 3 PE 1 1 2



Type of signal emitted by the remote flow sensor	Selector "SENSOR TYPE"	Selector "SENSOR SUPPLY"	Selector "LOAD" B 470 2.2K 39K	Terminal assignment of terminal block "FLOW SENSOR"
pulse, NPN	→ Set the selector on "NPN/PNP" (Fig. 33)	→ Set the selector as shown in Fig. 34.	 → Set selector "LOAD": • either on "2.2K": the load resistance R is then 2.2 kΩ • either on "470": the load resistance R is then 470 Ω 	8025 R 1 2 3 PE 1 2 3 PE Flow sensor
"on/off" signal (Reed relay for example)	→ Set the selector on "NPN/PNP" (Fig. 33)	→ Set the selector as shown in Fig. 34.	Set selector "LOAD": either on "2.2K": the load resistance R is then 2.2 kΩ either on "470": the load resistance R is then 470 Ω	R 1 2 3 PE 1 1



8.10 Wiring the digital inputs DI1 to DI4 and the transistor output DO4

Wiring of the digital inputs DI1 to DI4 and wiring of the transistor output DO4 are described in chapters 10.6.1 to 10.6.7, because they depend on the dosing mode configured.

8.11 Wiring the DO1 transistor output of device, fed with 12...36 V DC




Fig. 35: NPN or PNP wiring of the DO1 transistor output of the device

 \rightarrow Configure transistor output DO1 according to chapters <u>10.7.19</u> to <u>10.7.23</u>.

8.12 Wiring the DO1 transistor output of a version fed with 115/230 V AC for the 8025 Batch in compact version, for the 8035 Batch or for the SE35 Batch

- \rightarrow Wire the transistor output DO1 as described in chapter 8.11.
- → Configure transistor output DO1 according to chapters 10.7.19 to 10.7.23.



8.13 Wiring the DO1 transistor output of the 8025 Batch in wall-mounted version, fed with 115/230 V AC

Only move the selectors when the power supply is off.




Fig. 36: NPN wiring of the DO1 transistor output of a 8025 Batch in wall-mounted version, fed with 115/230 V AC

→ Configure transistor output DO1 according to chapters 10.7.19 to 10.7.23.




Fig. 37: PNP wiring of the DO1 transistor output of a 8025 Batch in wall-mounted version, fed with 115/230 V AC

 \rightarrow Configure transistor output DO1 according to chapters <u>10.7.19</u> to <u>10.7.23</u>.



8.14 Wiring the relay outputs DO2 and DO3 of a device



DANGER

Danger due to the operation of the relay outputs of a UL device in a wet location.

- ▶ If a UL device is used in a wet location:
 - energize the relay outputs with an alternating voltage of max. 16 Vrms and 22.6 Vpeak.
- or energize the relay outputs with a direct voltage of max. 35 V DC.



To carry out a dosing, connect a valve to the relay output DO2.

The device can control:

- either a dosing with a single valve connected to the relay output DO2.
- or a dosing with 2 valves connected to the relay outputs DO2 and DO3. In this case, connect the main valve (for the highest flow rates) to output DO2 and the auxiliary valve (for low flow rates) to output DO3.

If a single valve is used, connect a load to relay output DO3 suited for the configuration of the output.




Fig. 38: Wiring of the DO2 and DO3 relay outputs

- → To configure relay output DO2, see chapter 10.7.24.
- → To configure relay output DO3, see chapter 10.7.18.



9 COMMISSIONING

9.1 Safety instructions



WARNING

Danger due to non-conforming commissioning.

Non-conforming commissioning could lead to injuries and damage the device and its surroundings.

- ▶ Before commissioning, make sure that the staff in charge have read and fully understood the contents of the operating instructions.
- ▶ In particular, observe the safety recommendations and intended use.
- ► The device / the installation must only be commissioned by suitably trained staff.



Protect this device against electromagnetic interference, ultraviolet rays and, when installed outdoors, the effects of the climatic conditions.

9.2 Commissioning procedure

Before commissioning the device:

- \rightarrow Enter the K-factor of the fitting used. See chapter 10.7.3.
- → Wire the device depending on the desired dosing mode. See chapter 8 and chapters 10.6.1 to 10.6.7.
- → If the digital inputs are used, place DI4 in the off-position before energizing the device.
- \rightarrow Set the dosing mode. See chapter 10.7.5.



10 OPERATING AND FUNCTIONS

10.1 Safety instructions



DANGER

Danger due to electrical voltage.

- ▶ Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- ▶ Observe all applicable accident protection and safety regulations for electrical equipment.



WARNING

Risk of injury due to non-conforming operating.

Non-conforming operating could lead to injuries and damage the device and its surroundings.

- ► The operators in charge of operating must have read and understood the contents of these operating instructions.
- ▶ In particular, observe the safety recommendations and intended use.
- ► The device/installation must only be operated by suitably trained staff.

10.2 Operating levels of the device

The device has two operating levels: the Process level and the Configuration level.


The Process level allows for:

- starting a dosing.
- reading the values of the main and daily totalizers of the quantity of fluid counted since the last reset.
- reading the values of the main and daily totalizers of the done dosings since the last reset.
- resetting the daily volume or mass totalizer:
- resetting the daily totalizer of the done dosings.
- accessing the Configuration level.

The Configuration level comprises four menus (Parameters, Test, Information and History) and allow for:

- seting the device parameters.
- setting the dosing mode on the device.
- doing the Teach-In of the quantity to be dosed (only if dosing modes "LOC. REP" or "EXT. REP" are active on the device).
- testing the inputs and the outputs of the device.
- reading and confirming, when the device state LED is orange or red and when no dosing is being done, the warning and fault messages generated by the device.
- consulting the history of the last 10 dosings.






¹⁾ Accessible when the device state LED is orange or red and when no dosing is being done (see chapter 10.3).

²⁾ The warning messages of the menu can also be remotely consulted and confirmed: see chapter 10.11.



10.3 Description of the navigation keys and the state LEDs






10.4 Using the navigation keys

You want to	Press
move between parameters within a level or a menu.	• to go to the next parameter.
	• One of the previous parameter.
access the Parameters menu.	ewers + simultaneously for 5 s, in the Process level, if no dosing has been started.
access the Test menu.	simultaneously for 5 s, in the Process level, if no dosing has been started.
access the Information menu.	for 2 s, in the Process level, when the device state LED is orange or red and no dosing has been started.
access the History menu.	for 2 s, in the Process level, if no dosing has been started.
reset the daily volume or mass totalizer, from the Process level.	simultaneously for 2 s, when the daily volume or mass totalizer is displayed in the Process level
reset the daily totalizer of the done dosings, from the Process level.	simultaneously for 2 s, when the daily totalizer of the done dosings is displayed in the Process level
select the displayed parameter.	ENTER
confirm the displayed value.	ENTER
modify a numerical value.	• Omega to increase the blinking digit.
	• to select the digit at the left of the blinking digit.
	• Omego + to move the decimal point.

 \rightarrow To start a dosing, see chapter 10.6.



10.5 Principle of a dosing and PLC scenarios



 \rightarrow The different dosing modi are described in chapter 10.7.5.



Tab. 7: Scenario of a dosing with no problem nor pause

Event	State, output DO4	
no dosing	OFF	
dosing	ON	
end of the dosing	OFF	

Tab. 8: Scenario of a dosing with pause

Event	State, output DO4	
no dosing	OFF	
dosing	ON	
dosing interrupted	1Hz	
dosing continued	ON if the dosing is not finished OFF if the dosing finished during the pause	
or reset the dosing	OFF	

Tab. 9: Scenario of a dosing with alarm

Event	State, output DO4
no dosing	OFF
dosing	ON
ALARM	3.5 Hz
confirm the alarm	OFF if the dosing finished during the alarm 1Hz
	• Line if the dosing is not finished: the dosing has been interrupted. See <u>Tab. 8</u> .



Tab. 10: Scenario of a dosing with pause and alarm during the pause

Event	State, output DO4	
no dosing	OFF	
dosing	ON	
dosing interrupted	1Hz	
ALARM	3.5 Hz	
confirm the alarm	OFF if the dosing finished during the alarm 3.5 Hz if the dosing is not finished: the dosing has been interrupted. See <u>Tab. 8</u> .	

Tab. 11: Scenario of a dosing with ERROR[T]

Event	State, output DO4
no dosing	OFF
dosing	ON
ERROR[T]	3.5 Hz
confirm the alarm	OFF
	(no pulse sent out on DOx output configured with function "END DOSE")

burkert

10.6 Details of the Process level

This level is active by default when the device is energized.



If the power supply of the device is shut down while a dosing is being done, the dosing has been interrupted when the power supply is restored: to continue or abort the dosing depending on the dosing mode that is active on the device, see chapter 10.6.1 to 10.6.7.

BATCH M.

Displayed in the Process level when the configured dosing mode is "LOC MANU" (see chapter 10.7.6) or "MEM+MANU" (see chapter 10.7.8).

Do a dosing by entering the quantity to be dosed using the navigation keys.

BRTCH A.

Displayed in the Process level when the configured dosing mode is "LOC MEM." (see chapter 10.7.7) or "MEM+MANU" (see chapter 10.7.8).

Do a dosing by choosing the quantity to be dosed in the device memory using the navigation keys.

BATCH R.

Displayed in the Process level when the configured dosing mode is "LOC. REP" (see chapter 10.7.6).

Do a dosing, using the navigation keys, of the quantity determined by means of a Teach-In procedure.

BRTCH S.

Displayed in the Process level when the configured dosing mode is "EXT.+LOC" (see chapter 10.7.10).

Do:

- a dosing using the digital inputs.
- or a semi-automatic dosing: the quantity to be dosed is chosen via the navigation keys but the dosing is started using the digital inputs.

87654 L

Value of the main volume or mass totalizer, total quantity of fluid counted by the device since the last reset.

231 L.

Value of the daily volume or mass totalizer (identified by a dot after the volume or mass units), quantity of fluid counted by the device since the last reset.

1254 B

Value of the main totalizer of the done dosings since the last reset.



Value of the daily totalizer of the done dosings (identified by a dot after letter B) since the last reset.

Resets:

- the daily volume or mass totalizer (identified by a dot after the volume or mass units).
- or the daily totalizer of the done dosings (identified by a dot after letter B).





10.6.1 Doing a dosing in dosing mode "LOC. MANU." or "MEM.+MANU."

Dosing mode "LOC. MANU." allows for entering a dosing quantity and starting the dosing, via the navigation keys.

Dosing mode "MEM.+MANU." allows for:


- either entering a dosing quantity and starting the dosing, via the navigation keys,
- or starting the dosing, via the navigation keys, of a quantity saved in the memory.

\wedge

DANGER

Danger due to electrical voltage.

- ▶ Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- ▶ Observe all applicable accident protection and safety regulations for electrical equipment.
- \rightarrow Connect the valves to the DO2 and DO3 outputs: see chapter 8.14.
- → Wire the output DO4 as described in Fig. 39.



¹⁾ The LED can be replaced by another indicating system depending on the configuration of the transistor output DO4. See chapter 10.7.18.

Fig. 39: Electrical connection of the transistor output DO4 in the dosing modes "LOC. MANU", "LOC. MEM", "MEM+MANU" or "LOC. REP"

- → Start the device again.
- \rightarrow Configure the device with the dosing mode "LOC. MANU." or "MEM.+MANU.": see chapter <u>10.7.6</u> or <u>10.7.8</u>.
- \rightarrow Do a dosing as shown in Fig. 40.

²⁾ On a version energized with a 12...36 V DC voltage, the power supply of the device can be used to energize the transistor output DO4; If this is the case, connect the terminal "ISOG" to the terminal (L-) of terminal block A and use a 300 mA-fuse (instead of a 125 mA-fuse) to protect the power supply.





- If the generation of alarms (alarm "DURING") for problems occurring during a dosing has been activated (see chapter 10.7.16), an alarm is generated if there is no flow rate measured in the pipe whereas the valves are open. See chapter 11.3.4 to solve the problem.
- If the generation of alarms (alarm "AFTER") for problems occurring at the end of the dosing has been activated (see chapter 10.7.17), an alarm is generated if there is still flow in the pipe whereas the valves are closed. See chapter 11.3.4 to solve the problem.




Fig. 40: Doing a manual dosing in dosing modes "LOC. MANU." or "MEM.+MANU."



To interrupt the dosing, press the valve connected to output DO2 and possibly the valve connected to output DO3 close, the device state LED flashes at a 1 Hz-frequency and the DO4 output (if configured to transmit the device state, see chapter 10.7.26) generates a 1 Hz-frequency.

CONTINUE

CONTINUE

CONTINUE

CONTINUE

CONTINUE

CONTINUE

CONTINUE

The countdown of the dosing quantity continues.

RESET

The device is ready for a new dosing.

Fig. 41: Interrupting the dosing in dosing modes "LOC. MANU." or "MEM.+MANU."

10.6.2 Doing a dosing in dosing mode "LOC. MEM." or "MEM.+MANU."

Dosing mode "LOC. MEM." allows for starting the dosing, via the navigation keys, of a quantity saved in the memory.

Dosing mode "MEM.+MANU." allows for:

- either entering a dosing quantity and starting the dosing, via the navigation keys,
- or selecting a dosing quantity from the memory and starting the dosing, via the navigation keys,



DANGER

- ▶ Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- Observe all applicable accident protection and safety regulations for electrical equipment.
- → Connect the valves to the DO2 and DO3 outputs: see chapter 8.14.
- \rightarrow Wire the output DO4 as described in Fig. 39, chapter 10.6.1.
- → Start the device again.
- \rightarrow Configure the device with the dosing mode "LOC. MEM." or "MEM.+MANU.": see chapter <u>10.7.7</u> or <u>10.7.8</u>.
- \rightarrow Do a dosing as shown in Fig. 42.





- If the generation of alarms (alarm "DURING") for problems occurring during a dosing has been activated (see chapter 10.7.16), an alarm is generated if there is no flow rate measured in the pipe whereas the valves are open. See chapter 11.3.4 to solve the problem.
- If the generation of alarms (alarm "AFTER") for problems occurring at the end of the dosing has been activated (see chapter 10.7.17), an alarm is generated if there is still flow in the pipe whereas the valves are closed. See chapter 11.3.4 to solve the problem.




Fig. 42: Doing a dosing in dosing modes "LOC. MEM." or "MEM.+MANU."






Fig. 43: Interrupting the dosing in dosing modes "LOC. MEM." or "MEM.+MANU."

10.6.3 Doing a dosing in dosing mode "EXT. MEM."


Dosing mode"EXT. MEM" allows for selecting a dosing quantity from the device memory and starting the dosing, via the digital inputs.



DANGER

- Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- ▶ Observe all applicable accident protection and safety regulations for electrical equipment.
- → Connect the valves to the DO2 and DO3 outputs: see chapter 8.14.
- → Wire the output DO4 and the digital inputs DI1 to DI4 as described in <u>Fig. 44</u> and depending on the following requirements:
- the transistor output DO4 allows for transmitting the dosing state if the output DO4 is configured with the function "STATE" (see chapter 10.7.26).
- the digital input DI4 allows for starting, interrupting, continuing or aborting a dosing. It also allows for confirming an alarm, if the generation of alarms has been activated on the device (see chapter 10.7.16 and 10.7.17).
- the digital inputs DI1 to DI3 allow for selecting one of the 7 dosing quantities stored in the memory of the device. If all the 7 dosing quantities are not used, only connect the necessary inputs. When a dosing has been interrupted, the digital inputs allow for the navigation within the pause menu, between the function "CONTINUE" and the function "RESET".





¹⁾ The LED can be replaced by another indicating system depending on the configuration of the transistor output DO4. See chapter 10.7.18.

²⁾ On a version energized with a 12...36 V DC voltage, the power supply of the device can be used to energize the digital inputs DI and the transistor output DO4; If this is the case, connect the terminal "ISOG" to the terminal (L-) of terminal block A and use a 300 mA-fuse (instead of a 125 mA-fuse) to protect the power supply.

Fig. 44: Electrical connection of the digital inputs DI and of the transistor output DO4 in dosing modes "EXT. MEM", "EXT. +LOC" or "EXT. [T]"

- → Restart the device:
- If the DI4 input is at the low level (not powered) when energizing the device, the four digital inputs will be active at high level.
- If the DI4 input is at the high level (not powered) when energizing the device, the four digital inputs will be active at low level.
- → Configure the device with this dosing mode: see chapter 10.7.9.
- \rightarrow Do a dosing as shown in Fig. 45.



- If the generation of alarms (alarm "DURING") for problems occurring during a dosing has been activated (see chapter 10.7.16), an alarm is generated if there is no flow rate measured in the pipe whereas the valves are open. See chapter 11.3.4 to solve the problem.
- If the generation of alarms (alarm "AFTER") for problems occurring at the end of the dosing has been activated (see chapter 10.7.17), an alarm is generated if there is still flow in the pipe whereas the valves are closed. See chapter 11.3.4 to solve the problem.






Fig. 45: Doing a dosing of a quantity from the memory, in dosing mode "EXT. MEM."






Fig. 46: Interrupting the dosing, in dosing mode "EXT. MEM."

10.6.4 Doing a dosing in dosing mode "EXT.+LOC."

Dosing mode "EXT.+LOC." allows for:

- selecting a dosing quantity from the memory of the device, via the navigation keys or the digital inputs,
- then starting the dosing via the digital input DI4 (only).



DANGER

- Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- Observe all applicable accident protection and safety regulations for electrical equipment.
- → Connect the valves to the DO2 and DO3 outputs: see chapter 8.14.
- → Wire the output DO4 and the digital inputs DI as described in Fig. 44, chapter 10.6.3, and depending on the following requirements:
- the transistor output DO4 allows for transmitting the dosing state.
- the digital input DI4 allows for starting, interrupting, continuing or aborting a dosing. It also allows for confirming an alarm, if the generation of alarms has been activated on the device (see chapters 10.7.16 and 10.7.17).
- the digital inputs DI1 to DI3 allow for selecting one of the 7 dosing quantities, entered into the device memory (see Fig. 45, chapter 10.6.3). If all the 7 dosing quantities are not used, only connect the necessary inputs. When a dosing has been interrupted, the digital inputs allow for the navigation within the pause menu, between the function "CONTINUE" and the function "RESET". If the dosing quantity is selected via the navigation keys and no dosing will be remotely aborted, inputs DI1 to DI3 can be left unconnected.
- → Restart the device:
- If the DI4 input is at the low level (not powered) when energizing the device, the four digital inputs will be active at high level.
- If the DI4 input is at the high level (not powered) when energizing the device, the four digital inputs will be active at low level.
- \rightarrow Configure the device with this dosing mode: see chapter 10.7.10.
- \rightarrow Do the dosing of a quantity stored in the memory and selected with the navigation keys, see Fig. 47.
- → Do the dosing of a quantity stored in the memory via the digital inputs, see Fig. 48.



- If the generation of alarms (alarm "DURING") for problems occurring during a dosing has been activated (see chapter 10.7.16), an alarm is generated if there is no flow rate measured in the pipe whereas the valves are open. See chapter 11.3.4 to solve the problem.
- If the generation of alarms (alarm "AFTER") for problems occurring at the end of the dosing has been activated (see chapter 10.7.17), an alarm is generated if there is still flow in the pipe whereas the valves are closed. See chapter <u>11.3.4</u> to solve the problem.



- To select the dosing quantity via the navigation keys, deactivate the 3 digital inputs DI1 to DI3.
- If a warning message is generated by the device and no dosing is being done, a long pulse (> 2 s) on DI4 allows for remotely accessing to the Information menu, whatever the state of the inputs DI1 to DI3. See chapter 10.11.




Fig. 47: Doing the dosing of a quantity from the device memory via the navigation keys and the digital input DI4, in dosing mode "EXT.+LOC."






Fig. 48: Doing a dosing of a quantity from the memory via the digital inputs, in dosing mode "EXT.+LOC."






Fig. 49: Interrupting the dosing, in dosing mode "EXT.+LOC."



10.6.5 Doing a dosing in dosing mode "EXT. [T]"



In this mode, the dosing starts as soon as the digital input DI1 is switched.

The dosing mode "EXT. [T]" allows for starting the dosing of a quantity proportional to the duration the digital input DI1 is activated.



DANGER

- ▶ Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- Observe all applicable accident protection and safety regulations for electrical equipment.
- → Connect the valves to the DO2 and DO3 outputs: see chapter 8.14.
- → Wire the output DO4 and the digital inputs DI as described in <u>Fig. 44</u>, chapter <u>10.6.3</u>, and depending on the following requirements:
- the transistor output DO4 allows for transmitting the dosing state.
- the digital input DI1 allows for starting a dosing whose dosing quantity is proportional to the activation duration of DI1.
- the digital input DI4 allows for interrupting or continuing a dosing. It also allows for confirming an alarm, if the generation of alarms has been activated on the device (see chapter 10.7.16 and 10.7.17).
- when a dosing has been interrupted, the digital inputs DI2 and/or DI3 allow for the navigation within the pause menu, between the function "CONTINUE" and the function "RESET".
- → Restart the device:
- If the DI4 input is at the low level (not powered) when energizing the device, the four digital inputs will be active at high level.
- If the DI4 input is at the high level (not powered) when energizing the device, the four digital inputs will be active at low level.
- \rightarrow Configure the device with this dosing mode: see chapter 10.7.11.
- \rightarrow Do a dosing as shown in Fig. 50.



- If the generation of alarms (alarm "DURING") for problems occurring during a dosing has been activated (see chapter 10.7.16), an alarm is generated if there is no flow rate measured in the pipe whereas the valves are open. See chapter 11.3.4 to solve the problem.
- If the generation of alarms (alarm "AFTER") for problems occurring at the end of the dosing has been activated (see chapter 10.7.17), an alarm is generated if there is still flow in the pipe whereas the valves are closed. See chapter 11.3.4 to solve the problem.




Fig. 50: Doing a dosing, in dosing mode "EXT. [T]"






Fig. 51: Interrupting the dosing, in dosing mode "EXT. [T]"


10.6.6 Doing a dosing in dosing mode "EXT. REP."

The dosing mode "EXT. REP." allows for starting, via the digital inputs, the dosing of the quantity determined by a Teach-In procedure.



DANGER

- ▶ Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- Observe all applicable accident protection and safety regulations for electrical equipment.
- → Connect the valves to the DO2 and DO3 outputs: see chapter 8.14.
- → Wire the output DO4 and the digital inputs as described in <u>Fig. 52</u> and depending on the following requirements:
- the transistor output DO4 allows for transmitting the dosing state.
- when a dosing has been interrupted, the digital input DI1 allows for the navigation within the pause menu, between the function "CONTINUE" and the function "RESET".
- the digital input DI4 allows for interrupting or continuing a dosing, when the digital input DI1 is active. It also allows for confirming an alarm, if the generation of alarms has been activated on the device (see chapters 10.7.16 and 10.7.17).



¹⁾ The LED can be replaced by another indicating system depending on the configuration of the transistor output DO4. See chapter 10.7.18.

Fig. 52: Electrical connection of the digital inputs DI and of the transistor output DO4 in the dosing mode "EXT. REP"

²⁾ On a version energized with a 12...36 V DC voltage, the power supply of the device can be used to energize the digital inputs DI and the transistor output DO4; If this is the case, connect the terminal "ISOG" to the terminal (L-) of terminal block A and use a 300 mA-fuse (instead of a 125 mA-fuse) to protect the power supply.



- → Restart the device:
- If the DI4 input is at the low level (not powered) when energizing the device, the four digital inputs will be active at high level.
- If the DI4 input is at the high level (not powered) when energizing the device, the four digital inputs will be active at low level.
- \rightarrow Configure the device with this dosing mode, see chapter <u>10.7.12</u>.
- → Do a dosing as shown in Fig. 53.



- If the generation of alarms (alarm "DURING") for problems occurring during a dosing has been activated (see chapter 10.7.16), an alarm is generated if there is no flow rate measured in the pipe whereas the valves are open. See chapter 11.3.4 to solve the problem.
- If the generation of alarms (alarm "AFTER") for problems occurring at the end of the dosing has been activated (see chapter 10.7.17), an alarm is generated if there is still flow in the pipe whereas the valves are closed. See chapter 11.3.4 to solve the problem.
- If the digital input DI1 is active, no dosing has been started and no warning message has been generated by the device, a long pulse (> 2 s) on DI4 allows for accessing to the Information menu. See chapter 10.11.




Fig. 53: Doing a dosing, in dosing mode "EXT. REP."






Fig. 54: Interrupting the dosing, in dosing mode "EXT. REP."



10.6.7 Doing a dosing in dosing mode "LOC. REP."

The dosing mode "LOC. REP." allows for starting, via the navigation keys, the dosing of the quantity determined by a Teach-In procedure.



DANGER

- Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- Observe all applicable accident protection and safety regulations for electrical equipment.
- \rightarrow Wire the output DO4 as described in Fig. 39.
- → Connect the valves to the DO2 and DO3 outputs: see chapter 8.14.
- → Start the device again.
- \rightarrow Configure the device with this dosing mode: see chapter 10.7.13.
- \rightarrow Do a dosing as shown in Fig. 55.



- If the generation of alarms (alarm "DURING") for problems occurring during a dosing has been activated (see chapter 10.7.16), an alarm is generated if there is no flow rate measured in the pipe whereas the valves are open. See chapter 11.3.4 to solve the problem.
- If the generation of alarms (alarm "AFTER") for problems occurring at the end of the dosing has been activated (see chapter 10.7.17), an alarm is generated if there is still flow in the pipe whereas the valves are closed. See chapter 11.3.4 to solve the problem.






Fig. 55: Doing a dosing, in dosing mode "LOC. REP."




Fig. 56: Interrupting the dosing, in dosing mode "LOC. REP."



10.7 Details of the Parameters menu

To access the Parameters menu, simultaneously press keys for at least 5 s

This menu comprises the following configurable parameters:




Fig. 57: Diagram of the Parameters menu

10.7.1 Choosing the display language

When the device is energized for the first time, the display language is English.




Fig. 58: Diagram of the "LANGUAGE" parameter of the Parameters menu

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.

10.7.2 Choosing the dosing units, the flow rate units, the units and number of decimals of the volume or mass totalizers

When the units of the dosing quantities are changed:

- · Reset both totalizers.
- Manually convert the volume or mass values in the different settings.

If, furthermore, the unit changes from "metric" to "gallon" and vice versa, convert the K-factor using following formulae:

- K-factor in pulse/US Gallon = K-factor in pulse/I x 3.785
- K-factor in pulse/IMP Gallon = K-factor in pulse/I x 4.546
- If the dosing units chosen is a mass unit, convert the K-factor depending on the density of the fluid to measure.
- The number of decimals of a dosing quantity is chosen when entering the quantity.

The "UNIT" parameter allows for choosing:

- the volume or mass units of the dosing quantities.
- the flow rate units (only used to display the flow measured during a dosing).
- the units of the volume totalizers if the dosing units previously chosen is in litres, millilitres or cubic-meters.
- a number of decimals (choice 0, 1 or 2) to display the volume or mass totalizers in the Process level.






Fig. 59: Diagram of the "UNIT" parameter of the Parameters menu



10.7.3 Entering the K-factor of the fitting used

The device determines the quantity of fluid that flows through the pipe using the fitting K-factor.

The K-factor of the fitting used can be entered here. The device may also determine the K-factor using a Teach-In procedure: see chapter 10.7.4.



The device uses the new K-factor as soon as "SAVE YES" is confirmed when leaving the Parameters menu.



The K-factor of the fitting used can be found within the operating instructions of the fitting.

The operating instructions of the Bürkert fittings can be found on the internet at country.burkert.com.




Fig. 60: Entering the K-factor of the fitting used

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.

10.7.4 Determining the fitting K-factor using a Teach-In procedure

The device determines the flow rate in the pipe using the fitting K-factor.

The "TEACH V." or "TEACH F." parameter allows the device to determine the fitting K-factor using a Teach-In procedure. The K-factor may also be directly entered: see chapter 10.7.3.

The Teach-In can be done either depending on a known volume ("TEACH V.") or depending on the flow rate ("TEACH F.") in the pipe, measured by a reference instrument.



Determining the fitting K-factor using a Teach-In procedure depending on a volume ("TEACH V.")



- Before starting the Teach-In procedure, connect valves to the relays output DO2 and DO3 (if DO3 is configured as VALVE).
- The device uses the new K-factor as soon as "SAVE YES" is confirmed when leaving the Parameters menu.




Fig. 61: Teach-In procedure depending on a volume



Determining the fitting K-factor using a Teach-In procedure depending on a flow rate ("TEACH F.")



- Before starting the Teach-In procedure, connect valves to the relays output DO2 and DO3 (if DO3 is configured as VALVE).
- The device uses the new K-factor as soon as "SAVE YES" is confirmed when leaving the Parameters menu.




Fig. 62: Teach-In procedure depending on the flow rate



10.7.5 Configuring the dosing mode (general diagram)




Fig. 63: Diagram of the "OPTIONAL" parameter of the Parameters menu

10.7.6 Configuring the dosing mode "LOC. MANU."

This dosing mode allows for entering a dosing quantity and starting the dosing, via the navigation keys.




Fig. 64: Configuring the dosing mode "LOC. MANU."

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.

10.7.7 Configuring the dosing mode "LOC. MEM."

This dosing mode allows for starting the dosing, via the navigation keys, of a quantity saved in the memory.




Fig. 65: Configuring the dosing mode "LOC. MEM."

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.

10.7.8 Configuring the dosing mode "MEM+MANU"

This dosing mode allows for:

- either entering a dosing quantity and starting the dosing, via the navigation keys,
- or starting the dosing, via the navigation keys, of a quantity saved in the memory.




Fig. 66: Configuring the dosing mode "MEM+MANU"



10.7.9 Configuring the dosing mode "EXT. MEM."

This dosing mode allows for starting the dosing, via the digital inputs, of a quantity saved in the memory.




Fig. 67: Configuring the dosing mode "EXT. MEM."

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.

10.7.10 Configuring the dosing mode "EXT. +LOC"

This dosing mode allows for selecting a quantity saved in the memory, via the navigation keys (or via the digital inputs), then starting the dosing via the digital input DI4.




Fig. 68: Configuring the dosing mode "EXT. +LOC."

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.

10.7.11 Configuring the dosing mode "EXT. [T]"

- In this mode, the dosing starts as soon as the digital input DI1 is switched.
- If the conditions for calculating A and B are not respected, an alarm ERROR [T] will be generated and the device will abort the current dosing.

This dosing mode allows for starting the dosing of a quantity proportional to the activation duration of the digital input DI1, according to the formula:

$$X = A^*T + B$$

- where A is the proportionality factor in dosing units per second,
- B is the offset in dosing units,
- X is the dosing quantity, in dosing units,
- and T is the activation duration of the digital input DI1, in seconds with a resolution of 5 ms.
- → Calculate constants A and B (see example in Tab. 12) in order:
- the activation duration "T" is within a time interval related to the process,
- the activation duration "T" is lower than the real filling duration, taking into account the flow rate in the pipe,
- (A*T + B) is always lower than 100 000 dosing units,
- (A*T + B) is higher than or equal to 6 divided by the set K-factor (in pulse/litre),
- the minimum activation duration (100 ms) is observed,
- the maximum activation duration (300 s) is observed,




Fig. 69: Configuring the dosing mode "EXT. [T]"

Tab. 12: Calculation example of constants A and B

Dosing quantities	Required activation durations "T"	Value of constant A	Value of constant B
110 litres	2 seconds	5 l/s	100 litres
120 litres	4 seconds		
130 litres	6 seconds		
150 litres	10 seconds		



10.7.12 Configuring the dosing mode "EXT. REP"

The dosing mode allows for starting, via the digital inputs, the dosing of the quantity determined by a Teach-In procedure.

Teach-In of the dosing quantity can be done either via the digital inputs or using the navigation keys.

With the Teach-In, the device automatically determines:

- the dosing quantity for each dosing made in dosing mode "EXT.REP." or "LOC. REP".
- the overfilling value to be corrected. If the overfill correction function is deactivated before the Teach-In is started, it will be automatically activated with the "DIRECT" option at the end of the Teach-In.
- the ratio of fluid that passes through each valve, if two valves are used.



Before starting the Teach-In procedure:

- Connect the valves to the DO2 and DO3 outputs: see chapter 8.14.
- Parameter the operating of and the time delay before the valve connected to the DO2 output is opened: see chapter 10.7.24.
- If two valves are used, configure output DO3 with the function "valve" and parameter the operating of the valve connected to the DO3 output: see chapter 10.7.25.



- If the generation of alarms (alarm "DURING") for problems occurring during a dosing has been activated (see chapter 10.7.16), an alarm is generated if there is no flow rate measured in the pipe whereas the valves are open. See chapter 11.3.4 to solve the problem.
- If the generation of alarms (alarm "AFTER") for problems occurring at the end of the dosing has been activated (see chapter 10.7.17), an alarm is generated if there is still flow in the pipe whereas the valves are closed. See chapter 11.3.4 to solve the problem.
- Do not anticipate the quantity of liquid that flows after the valves have been closed. Their closing must be controlled once the exact dosing quantity has been reached. The liquid surplus is measured and will be corrected in the next dosings.




Fig. 70: Configuring the dosing mode "EXT. REP."




Fig. 71: Determination of the dosing quantity using a Teach-In procedure



10.7.13 Configuring the dosing mode "LOC. REP."

The dosing mode allows for starting, via the navigation keys, the dosing of the quantity determined by a Teach-In procedure.

Teach-In of the dosing quantity can be done either via the digital inputs or using the navigation keys.

With the Teach-In, the device automatically determines:

- the dosing quantity for each dosing made in dosing mode "EXT.REP." or "LOC. REP".
- the overfilling value to be corrected. If the overfill correction function is deactivated before the Teach-In is started, it will be automatically activated with the "DIRECT" option at the end of the Teach-In.
- the ratio of fluid that passes through each valve, if two valves are used.



Before starting the Teach-In procedure:

- Connect the valves to the DO2 and DO3 outputs: see chapter 8.14.
- Parameter the operating of and the time delay before the valve connected to the DO2 output is opened: see chapter 10.7.24.
- If two valves are used, configure output DO3 with the function "valve" and parameter the operating
 of the valve connected to the DO3 output: see chapter 10.7.25.



- If the generation of alarms (alarm "DURING") for problems occurring during a dosing has been activated (see chapter 10.7.16), an alarm is generated if there is no flow rate measured in the pipe whereas the valves are open. See chapter 11.3.4 to solve the problem.
- If the generation of alarms (alarm "AFTER") for problems occurring at the end of the dosing has been activated (see chapter 10.7.17), an alarm is generated if there is still flow in the pipe whereas the valves are closed. See chapter 11.3.4 to solve the problem.
- Do not anticipate the quantity of liquid that flows after the valves have been closed. Their closing must be controlled once the exact dosing quantity has been reached. The liquid surplus is measured and will be corrected in the next dosings.




Fig. 72: Configuring the dosing mode "LOC. REP."




Fig. 73: Determination of the dosing quantity using a Teach-In procedure



10.7.14 Entering the dosing quantities in the device memory

The parameter "VOLUMES" of the sub-menu "OPTIONAL" allows for entering up to 7 dosing quantities in the device memory.

These quantities are then available when the dosing modes "LOC. MEM", "MEM+MANU", "EXT. MEM" or "EXT. +LOC" is active.




Fig. 74: Configuring the dosing quantities

10.7.15 Configuring the overfill correction or deactivating it

When a dosing is finished, the device controls the closing of the main valve (or of the auxiliary valve).

The overfilling is the quantity of liquid that has been counted by the device once the valve is closed.

When the overfill correction is active, the overfilling of a dosing is deducted from the next dosing(s).

The overfill correction can be either:

- direct: the overfilling is deducted from the next dosing.
- or smoothed: the device smoothes (with a "low", "medium" or "high" effect) the overfillings of the last x dosings and deducts the calculated value from the next dosing.

Tolerance of the overfilling:

A tolerance for the overfilling value can be furthermore entered: if the overfilling of a dosing exceeds the tolerance, that overfilling value will not be taken into account in the next smoothing calculations and the warning message "W. OVER." is generated by the device. See chapter 11.3.3 to solve the problem.

To avoid a false dosing after a modification in the process, reset the table of the overfill correction values before restarting the process. See <u>Fig. 75</u>.




Fig. 75: Configuring the overfill correction



10.7.16 Activating / deactivating the generation of alarms for problems occurring during a dosing

The following problems can occur during a dosing:

- no flow in the pipe whereas the valves are open.
- a flow is measured in the pipe whereas the valves are closed.

These problems can be signalled by the generation of an alarm.

When an alarm is generated, the device stops the process:

- the valves connected to the relay outputs DO2 and DO3 are closed,
- the device state LED becomes orange and flashes fast,
- a 3.5 Hz-frequency is generated on the transistor output DO4 if it is configured to transmit the state of the device (see chapter 10.7.26),
- the outputs configured with the function "ALARM" are switched (see chapter 10.7.19),
- the message "ALARM" is displayed.




Fig. 76: Activating / deactivating the generation of alarms for problems occurring during a dosing

burkert

10.7.17 Activating / deactivating the generation of alarms for problems occurring at the end of a dosing

When the following 3 criteria are fulfilled the dosing is finished:

- no flow rate measured in the pipe,
- the valves are closed,
- and the quantity has entirely been dosed.

If a flow rate is measured in the pipe whereas the valves should be closed (once the dosing is finished or when a dosing has been interrupted), an alarm can be generated.

When an alarm is generated, the device stops the process:

- the valves connected to the relay outputs DO2 and DO3 are closed,
- the device state LED becomes orange and flashes fast,
- a 3.5 Hz-frequency is generated on the transistor output DO4 if it is configured to transmit the state of the device (see chapter 10.7.26),
- the outputs configured with the function "ALARM" are switched (see chapter 10.7.19),
- the message "ALARM" is displayed.




Fig. 77: Activating / deactivating the generation of alarms for problems occurring at the end of a dosing

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.



10.7.18 Configuring the outputs (general diagram)




Fig. 78: Diagram 1/2 of the "OUTPUT" parameter of the Parameters menu




Fig. 79: Diagram 2/2 of the "OUTPUT" parameter of the Parameters menu

10.7.19 Configuring the transistor output DO1 or DO4 or the relay output DO3 to switch when an alarm is generated during or at the end of a dosing

An alarm is generated during or at the end of a dosing (can be parametered, see chapters <u>10.7.16</u> and <u>10.7.17</u>).

The generation of an alarm can be signalled by the switching of the output DO1 and/or DO3 and/or DO4.

The relay output DO3 can be configured to switch when an alarm is generated during or at the end of a dosing, if the output is not configured to control an auxiliary valve. See chapter 10.7.25.




Fig. 80: Configuring the output DO1 or DO3 or DO4 to signal the generation of an alarm during or at the end of a dosing

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.



10.7.20 Configuring the transistor output DO1 or DO4 or the relay output DO3 to switch when a warning message is emitted by the device

When the device generates a warning message, the device state LED is orange.

The generation of a warning message can be indicated by the switching of the output DO1 and/or DO3 and/or DO4.



The relay output DO3 can be configured to switch when a warning message is generated by the device, if the output is not configured to control an auxiliary valve. See chapter 10.7.25.




Fig. 81: Configuring the output DO1 or DO3 or DO4 to indicate the generation of a warning message

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.

10.7.21 Configuring the transistor output DO1 or DO4 or the relay output DO3 to signal the end of the dosing

When the 3 following criteria are fulfilled the dosing is finished:

- the valves are closed (with the exception of a dosing being interrupted),
- no flow rate measured in the pipe,
- and the quantity has entirely been dosed.

The end of a dosing can be signalled by the generation of a 200 ms pulse on the output DO1 and/or DO3 and/or DO4, if the dosing has not been aborted on purpose or interrupted by the generation of an "ERROR [T]" alarm.



The relay output DO3 can be configured to signal the end of the dosing, if the output is not configured to control an auxiliary valve. See chapter 10.7.25.

burkert




Fig. 82: Configuring the output DO1 or DO3 or DO4 to signal the end of the dosing

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.

10.7.22 Configuring the transistor output DO1 or DO4 as a pulse output proportional to a volume or a mass

When the DO1 or DO4 transistor output is configured as a pulse output proportional to a volume or a mass, a pulse is transmitted on the output each time the parametered volume or mass of fluid has been measured by the device.



- When the frequency emitted on the pulse output is between 0.6 and 300 Hz, the duty cycle of the signal is between 45 % and 60 %.
- When the frequency emitted on the pulse output is between 300 and 1500 Hz, the duty cycle of the signal is between 40 % and 50 %.
- When the frequency emitted on the pulse output is between 1500 and 2200 Hz, detection on a pulse edge is possible.




Fig. 83: Configuring the transistor output DO1 or DO4 as a pulse output proportional to a volume or a mass

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.

10.7.23 Configuring the transistor output DO1 or DO4 to transmit the rotational frequency of the paddle wheel

When the transistor output DO1 or DO4 is configured with the function "PULSE" and the units "HERTZ", each pulse from the paddle wheel flow sensor is transmitted to the transistor output DO1 or DO4. The frequency generated by this output then equals the rotational frequency of the paddle wheel (this value can be read from the parameter "FREQUENC" in the Test menu).




Fig. 84: Configuring the transistor output DO1 or DO4 as a pulse output propotional to the rotational frequency of the paddle wheel

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.

burkert

10.7.24 Configuring the relay output DO2



DANGER

Danger due to the operation of the relay outputs of a UL device in a wet location.

- ▶ If a UL device is used in a wet location:
 - energize the relay outputs with an alternating voltage of max. 16 Vrms and 22.6 Vpeak.
 - or energize the relay outputs with a direct voltage of max. 35 V DC.

Connect the main valve (installed into the pipe with high flow rate) to the relay output DO2. See chapter <u>8.14</u>.

The output DO2 is dedicated to the control of the main valve (installed into the pipe with high flow rate).




Fig. 85: Configuring the DO2 relay output

 \rightarrow If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.



10.7.25 Configuring the relay output DO3 to control an auxiliary valve



DANGER

Danger due to the operation of the relay outputs of a UL device in a wet location.

- ▶ If a UL device is used in a wet location:
 - energize the relay outputs with an alternating voltage of max. 16 Vrms and 22.6 Vpeak.
 - or energize the relay outputs with a direct voltage of max. 35 V DC.



- Connect the auxiliary valve (installed into the pipe with low flow rate) to the relay output DO3. See chapter 8.14.
- The time delay before opening the auxiliary valve is the same as the time delay before opening the main valve.
- If no auxiliary valve is necessary, enter a filling rate of 100 in the settings of the relay output DO2.

If the filling rate associated to the relay output DO2 is < 100, the relay output DO3 is automatically configured to control the auxiliary valve that completes the filling up to 100 (see chapter 10.7.24).




Fig. 86: Configuring the relay output DO3 to control an auxiliary valve

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press [ENTER] to save the settings or not and go back to the Process level.

10.7.26 Configuring the transistor output DO4 to transmit the device state and activating / deactivating the generation of a 10 Hz frequency when an error message is generated by the device

The transistor output DO4 can be configured to transmit the device state to a LED or a remote instrument (PLC for example).

If, furthermore, the device signals an operating error (see chapter <u>11.3.2</u>), the transistor output DO4 can be configured to generate a 10-Hz-frequency.



The following states are transmitted:

State of the device	State of the transistor output DO4
No dosing being done	OFF
Dosing being done	ON
Dosing interrupted	1 Hz-frequency
 Problem which occurs during or at the end of a dosing: no flow in the pipe whereas the valves are open. a flow is measured in the pipe whereas the valves are closed. when the dosing mode "EXT [T]" is active on the device, the activation duration of the digital input DI1 does not respect the conditions described in chapter 10.7.11. 	3.5 Hz-frequency
An error message has been generated by the device. See chapter 11.3.	10 Hz-frequency, if the function is active on the device: see Fig. 87.
The power supply has been cut during a dosing	10 Hz-frequency for 2 seconds when the device is started, if the function is active on the device: see Fig. 87.
Selected quantity Vn, when the dosing mode "EXT. +LOC" is active (see Fig. 47, chapter 10.6.4).	n pulses generated at a 50 Hz-frequency




Fig. 87: Configuring the transistor output DO4 to transmit the device state

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.



10.7.27 General diagram of the "RESET" sub-menu




Fig. 88: General diagram of the "RESET" sub-menu

10.7.28 Resetting the two volume or mass totalizers

The function allows for resetting the two volume or mass totalizers.




Fig. 89: Diagram of the "TOTAL" parameter of the sub-menu "RESET"

The daily totalizer can be reset from the Process level. See chapter 10.6.

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.



10.7.29 Resetting the two totalizers of the done dosings

The function allows for resetting the two totalizers of the done dosings.




Fig. 90: Diagram of the "BATCH" parameter of the sub-menu "RESET"

- The daily totalizer can be reset from the Process level. See chapter 10.6.
- → If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings or not and go back to the Process level.

10.7.30 Clearing the history table of the done dosings




Fig. 91: Diagram of the "HISTORIC" parameter of the sub-menu "RESET"

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press [ENTER] to save the settings or not and go back to the Process level.



10.7.31 Setting the brightness of the display and how long it stays ON, or deactivating the backlight

This parameter makes it possible:

- to adjust the brightness of the display and how long the display is backlit after a key press.
- to deactivate the backlight.




Fig. 92: Diagram of the "BACKLIT" parameter of the Parameters menu

→ If you do not want to adjust another parameter, confirm the "END" parameter to save the settings or not and go back to the Process level.



10.8 Details of the Test menu

To access the Test menu, simultaneously press keys for at least 5 s.

This menu comprises the following configurable parameters:




Fig. 93: Diagram of the Test menu



10.8.1 Checking the inputs functions

The function allows for checking the correct working of the digital inputs.



The device state LED flashes during the running check of the input working.




Fig. 94: Diagram of the "TEST DI" parameter of the Test menu

→ If you do not want to adjust another parameter, go to the "END" parameter of the Test menu and press to save the settings or not and go back to the Process level.

10.8.2 Checking the outputs functions



If a valve is connected to the output DO2 or DO3, this function will open the valve.

The function allows for checking the correct working of the outputs.



- The device state LED flashes during the running check of the output working.
- After having confirmed the output to be checked, the display shows the current state of the output ("DOx ON" or "DOx OFF").






Fig. 95: Diagram of the "TEST DO" parameter of the Test menu

→ If you do not want to adjust another parameter, go to the "END" parameter of the Test menu and press to save the settings or not and go back to the Process level.

10.8.3 Checking the paddle-wheel operation

1

Risk of disrupting the process due to accidental opening of the valves.

 Before confirming the parameter "FREQUENC" and thus opening the valves, make sure there is no risk for the process.




Fig. 96: Diagram of the "FREQUENC." parameter of the Test menu

→ If you do not want to adjust another parameter, go to the "END" parameter of the Test menu and press to save the settings or not and go back to the Process level.



10.8.4 Monitoring the flow rate in the pipe

A malfunction in your process or in the flow sensor may be indicated either by too low or too high a flow rate.

The parameter "FLOW-W." makes it possible to monitor the flow rate.



- To disable the flow rate monitoring, set W-=W+=0.
- To disable one of the limits, set it to 0.
- When the warning message "WARN. LO" or "WARN. HI" is generated, access to the information menu, go to the message and confirm the message by simultaneously pressing the keys of for 2 seconds.




Fig. 97: Diagram of the "FLOW-W." parameter of the sub-menu "WARNING"

To be warned when the flow rate is too low or too high, enter the flow rate range (in the units that have been chosen in the "UNIT" parameter of the Parameters menu), outside which the device generates a warning message, "WARN LO" or "WARN HI", and turns the device status LED to orange.

When a warning message, "WARN LO" or "WARN HI", is generated by the device:

- ightarrow check the process.
- → if the process is not faulty, check the flow sensor condition and clean it if necessary.
- → if the flow rate measurement is still faulty, contact the Bürkert retailer.

burkert



- The transistor output DO1 or DO4 or the relay output DO3 can be configured to switch when a warning message is emitted by the device. See chapter 10.7.18.
- See also "If you encounter problems" in chapter 11.3.
- → If you do not want to adjust another parameter, confirm the "END" parameter to save the settings or not and go back to the Process level.

10.8.5 Monitoring the value of the daily volume or mass totalizer

The parameter "VOLUME-W." makes it possible to monitor the value of the volume or mass daily totalizer. When the daily totalizer has reached the set value, a warning message is generated by the device.



- To deactivate the monitoring of the totalizer, set "VOLUME-W." to zero.
- When the warning message "WARN. VOL." is sent out, reset the daily volume or mass totalizer: see chapter 10.6 or 10.7.28.




Fig. 98: Diagram of the "VOLUME-W." parameter of the sub-menu "WARNING"



- The transistor output DO1 or DO4 or the relay output DO3 can be configured to switch when a warning message is emitted by the device. See chapter 10.7.18.
- See also "If you encounter problems" in chapter 11.3.
- → If you do not want to adjust another parameter, confirm the "END" parameter to save the settings or not and go back to the Process level.

10.8.6 Monitoring the number of done dosings

The parameter "BATCH-W." makes it possible to monitor the value of the done dosings daily totalizer. When the daily totalizer has reached the set value, a warning message is generated by the device.



- To deactivate the monitoring of the number of done dosings, set "BATCH-W." to zero.
- When the warning message "W. BATCH" is sent out, reset the daily totalizer of the done dosings: see chapter 10.6 or 10.7.28.




Fig. 99: Diagram of the "BATCH-W." parameter of the sub-menu "WARNING"





- The transistor output DO1 or DO4 or the relay output DO3 can be configured to switch when a warning message is emitted by the device. See chapter 10.7.18.
- See also "If you encounter problems" in chapter 11.3.
- → If you do not want to adjust another parameter, confirm the "END" parameter to save the settings or not and go back to the Process level.

10.8.7 Saving the user set configuration

You may save the current configuration of the device in order to restore it later.




Fig. 100: Saving the current user configuration

→ If you do not want to adjust another parameter, confirm the "END" parameter to save the settings or not and go back to the Process level.

10.8.8 Restoring the saved configuration

You can restore the configuration of the device that has been previously saved (see chapter 10.8.7).



The device will use the restored configuration as soon as "SAVE YES" is confirmed when leaving the Test menu.




Fig. 101: Restoring the configuration previously saved

→ If you do not want to adjust another parameter, confirm the "END" parameter to save the settings or not and go back to the Process level.



10.8.9 Restoring the default configuration



The device will use the default configuration as soon as "SAVE YES" is confirmed when leaving the Test menu.

The parameter makes it possible to restore the default configuration of the device (Tab. 13).




Fig. 102: Restoring the default configuration of the device

Tab. 13: Default configuration of the device

Function	Default value	
LANGUAGE	English	
Dosing UNITS	litre	
UNIT of the flow rate	l/s	
UNIT of the totalizers	litre, 0 decimals	
K FACTOR	1.00	
OPTIONAL	dosing mode "LOC. MANU"	
	V1 to V7=0.00	
Parameters A and B for dosing mode "EXT. [T]"	0	
Teach-In dosing quantity for dosing modes "EXT. REP." and "LOC. REP."	0	
OVERFILL CORRECTION	yes, direct, tolerance 0	
ALARME during dosing	no	
	Time delay = 1s	
ALARME at the end of the dosing	no	
	Time delay = 1s	
OUTPUT DO1	Pulse, PU=0.0	
	Litre	
OUTPUT DO2	Valve 100 %, not inverted, time delay before opening = 0 s	
OUTPUT DO3	Alarm, not inverted	
OUTPUT DO4	State	
	ERR10Hz inactive	
BACKLIGHT	level 9, activated for 30 s	
FLOW-WARNING	W-=W+=0.000	
	Time delay = 1s	
VOLUME-WARNING	0	
BATCH-WARNING	0	

^{ightarrow} If you do not want to adjust another parameter, confirm the "END" parameter to save the settings or not and go back to the Process level.



10.9 Details of the History menu

To access the History menu, press the key for at least 2 s, in the Process level.

The menu makes it possible to consult the quantities dosed in the last 10 dosings done on the device.




Fig. 103: Diagram of the History menu

10.10 Details of the Information menu

- 1
- This menu is available when the device state LED is orange or red.
- For the meaning of a message, go to chapter 11.3.
- The messages "WARN. LOW", "WARN. HIG" and "W. OVER." can be confirmed in the Information menu by simulteously pressing keys and for 2 seconds: the message "OK" is displayed.
- The messages "WARN. VOL" and "W. BATCH" are confirmed when the related totalizers are reset.

To access the Information menu, press the key for at least 2 s, in the Process level.

In this menu read the fault and warning messages generated by the device.




Fig. 104: Diagram of the Information menu

 \rightarrow To remotely consult and confirm the warning messages, see chapter 10.11.

burkert

10.11 Remote consultation and confirmation of the warning messages



If the power supply of the device is cut during the remote consultation, the device will generate for 2 s a few 10 Hz-pulses on the output DO4 configured with the function "STATE" and the Process level will be active when the power supply is restored.



When the remote consultation is active on the device:

- no dosing can be done.
- the digital inputs are only used for the consultation and the confirmation of the warning messages.
- the navigation keys are blocked, except to exit the consultation when "END" is displayed.
- the device state LED flashes.

Remote consultation and confirmation of the warning messages via the digital inputs is only possible:

- from the Process level,
- when no dosing is being done on the device.
- if at least 1 warning message has been generated (the output(s) configured with the function "WARNING" take the value 1).

To use the feature:

- → Configure the device with the dosing mode "EXT. MEM", "EXT.+LOC", "EXT. [T]" or "EXT. REP".
- → Connect the 4 digital inputs DI1 to DI4 to 4 outputs of the PLC.
- → Configure DO1 or DO3 with the function "WARNING": see chapter 10.7.20.
- → Connect the transistor output DO1 or the relay output DO3 to an input of the PLC.
- → In order for the PLC to be informed that the remote consultation has started or has finished, connect the transistor output DO4 to an input of the PLC and configure the output DO4 with the function "STATE": see chapter 10.7.26.




Fig. 105: Remote consultation of the warning messages



- 1. To remotely access to the warning messages, the PLC sends out the code 000 on the digital inputs DI1 to DI3 then 1 pulse on DI4.
- 2. The device generates a 200 ms pulse on the output DO4 to confirm the access to the messages; The dosing feature cannot be accessed any more.
- 3. The output(s) configured with the function "WARNING" are switched to 0.
- 4. To identify which warning messages have been generated by the device, the PLC sends one after the other on the digital inputs DI1 to DI3 the codes related to the messages (see <u>Tab. 14</u>).
- 5. When the PLC encounters a message that has been generated by the device, the output(s) configured with the function "WARNING" switch to 1.
- 6. To confirm the message, the PLC sends out one pulse on DI4 and, if the active message is "WARN. VOL." or "W. BATCH", the related daily totalizer is reset.
- 7. To exit the consultation, the PLC sends the code 000 on the digital inputs DI1 to DI3 then confirms "END" by sending out one pulse on DI4. Pressing the key ENTER also confirms "END".
- 8. The device generates a 200 ms pulse on the output DO4 to confirm the end of the message consultation; The dosing feature is available again.

Tab. 14: Code DI1/DI2/DI3 of the warning messages

DI1	DI2	DI3	Chosen message
0	0	0	END
1	0	0	WARN.LOW
0	1	0	WARN.HIG.
1	1	0	WARN. VOL.
0	0	1	W. BATCH
1	0	1	W.OVER






Fig. 106: Timing chart for the remote consultation of the warning messages



11 MAINTENANCE AND TROUBLESHOOTING

11.1 Safety instructions



DANGER

Danger due to electrical voltage.

- ▶ Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- ▶ Observe all applicable accident protection and safety regulations for electrical equipment.



WARNING

Risk of injury due to non-conforming maintenance.

- ▶ Maintenance must only be carried out by qualified and skilled staff with the appropriate tools.
- ► Ensure that the restart of the installation is controlled after any interventions.

11.2 Cleaning the device

The device can be cleaned with a cloth dampened with water or a detergent compatible with the materials the device is made of.

Please feel free to contact your Bürkert supplier for any additional information.

11.3 If you encounter problems

11.3.1 Resolution of problems when the device state LED is OFF

Device state LED	Output DO4	Output DO1 and/or DO2 and/or DO3	Possible cause	Recommended action
OFF	0 Hz	not switched	The device is not energized.	 → Check the wiring. → Check the fuse of the installation and replace it if necessary. → Check that the installation is not shut-down. → Check that the power source is working properly. → If the problem occurs again, take contact with the retailer.



11.3.2 Resolution of problems related to an error message and the device state LED is red

Device state LED	Output DO4	Output DO1 and/or DO2 and/or DO3	Message displayed	Possible cause	Recommended action
red	0 Hz	not switched	"PWRFAIL"	The supply voltage is too low. The device does not function.	 → Check that the supply voltage is between 12 and 36 V DC. → If the problem occurs again, take contact with the retailer.
red	0 Hz		"ERROR3"	The user parameters are lost.	 → Start the device again. → If the message persists, configure the device again. → If the problem occurs again, take contact with the retailer.
red	10 Hz ¹⁾		"ERROR4"	The totalizer values are lost. The values saved upon the next to last power down are retrieved.	 → Start the device again. → If the problem occurs again, take contact with the retailer.
red	0 Hz		"ERROR5"	Both "ERROR3" and "ERROR4".	 → Start the device again. → If the message persists, configure the device again. → If the problem occurs again, take contact with the retailer.
red	10 Hz ¹⁾		"ERROR6"	Totalizers definitely lost. The totalizers are reset.	 → Start the device again. → If the problem occurs again, take contact with the retailer.
red	0 Hz		"ERROR7"	Both "ERROR3" and "ERROR6".	 → Start the device again. → If the message persists, configure the device again. → If the problem occurs again, take contact with the retailer.
red	10 Hz ¹⁾		dosing being done	The rotational frequency of the paddle wheel is > 2.2 kHz.	 → Check the flow rate in the pipe. → If necessary, adjust the flow rate. → If the problem occurs again, take contact with the retailer.

¹⁾ If parameter "ERR. 10HZ" is set to "ACTIVE". See chapter 10.7.26.



11.3.3 Resolution of problems related to a warning message and the device state LED is orange

Device state LED	Output DO1 and/or DO2 and/or DO3	Message displayed	Possible cause	Recommended action
orange	Switched ²⁾	"WARN. LOW"	During dosing, the measured flow rate has stayed under the minimum threshold for the set time delay. This message appears when the flow rate is monitored (see chapter 10.8.4).	 → Check the flow rate in the pipe and its consequences on the process. → If necessary, clean the flow sensor. → When the dosing is finished, access the Information menu and confirm the message. See chapter 10.10. → Check the connection between the device and the flow sensor.
orange	Switched 2)	"WARN. HIG"	During a dosing, the measured flow rate has stayed above the maximum threshold for the set time delay. This message appears when the flow rate is monitored (see chapter 10.8.4).	 → Check the flow rate in the pipe and its consequences on the process. → If necessary, clean the flow sensor. → When the dosing is finished, access the Information menu and confirm the message. See chapter 10.10.
orange	Switched 2)	"W.OVER"	The last dosing could not be correctly corrected and the dosed quantity has exceeded the threshold set in the overfill correction parameter (see chapter 10.7.15).	 → Chek the process, and especially for the flow rate being stable. → Check the last dosing (missing liquid or overfilling). → If the problem occurs again after several dosings, use the function to smoothen the overfill correction. See chapter 10.7.15. → Access the Information menu and confirm the message. See chapter 10.10.
orange	Switched 2)	"WARN. VOL."	The daily volume or mass totalizer has reached the value set in parameter "VOLUME-W." of the Test menu.	 → Do the planned maintenance operation. → Reset the daily volume or mass totalizer: see chapter 10.6 or 10.7.28.
orange	Switched ²⁾	"W. BATCH"	The number of done dosings has reached the value set in parameter "BATCH-W." of the Test menu.	 → Do the planned maintenance operation. → Reset the daily totalizer of the done dosings: see chapter 10.6 or 10.7.29.

²⁾ If the output is configured to switch when a warning message is generated. See chapter 10.7.20.



11.3.4 Resolution of a problem occurring during a dosing

Device state LED	Output DO1 and/or DO2 and/or DO3	Output DO4 in "STATE" mode	Message displayed	Possible cause	Recommended action
orange, 3.5 Hz flashing	Switched ²⁾	3.5 Hz frequency	"ALARM"	The message can appear if the generation of alarms during dosing is active on the device. See chapter 10.7.16. The device has opened the valves but there is no flow.	 → Check the process. → Check the operation of the valves. → Check the wiring of the valves, for example via the TEST menu. See chapter 10.8.2. → Check the flow sensor. → To confirm the message, press the key "ENTER" or send out a pulse on DI4: the dosing has been interrupted. current dosing can be continued or aborted.
orange, 3.5 Hz flashing	Switched ²⁾	3.5 Hz-fre- quency	"ALARM"	The message can appear if the generation of alarms at the end of dosing is active on the device. See chapter 10.7.17. The device has closed the valves but there is still flow in the pipe.	 → Check the process. → Check the operation of the valves. → Check the wiring of the valves, for example via the TEST menu. See chapter 10.8.2. → Check the flow sensor. → To confirm the message, press the key "ENTER" or send out a pulse on DI4: if the dosing is finished, the device goes back to the Process level. Else, the dosing has been interrupted and can be continued or aborted.



Device state LED	Output DO1 and/or DO2 and/or DO3	Output DO4 in "STATE" mode	Message displayed	Possible cause	Recommended action
orange, 3.5 Hz flashing	Switched ²⁾	3.5 Hz-fre- quency	"ERROR [T]"	The message can only appear if the dosing mode "EXT. [T]" is active. The dosing quantity is exceeded when the input DI1 has been deactivated.	 → Increase the values of the parameters A and B in order to reduce the activation time of the digital input DI1 and so that "A*T + B" < flow rate times T. → or set a time delay before the valves open. See chapter 10.7.24 and 10.7.25. → or reduce the flow rate in the pipe. → Confirm the message by pressing the key "ENTER" or by sending out a pulse on DI4: the current dosing is aborted.
orange, 3.5 Hz flashing	Switched ²⁾	3.5 Hz-fre- quency	"ERROR [T]"	The message can only appear if the dosing mode "EXT. [T]" is active. The dosing quantity, determined by the device depending on the activation duration of the digital input DI1, has exceeded the required thresholds.	 → Set the values of the parameters A and B and the value of the activation duration T so that "A*T+B" < 100 000 and "A*T+B" times the K-factor of the fitting used is higher or equal to 6. → Set an activation duration T < 300 s. → Confirm the message by pressing the key "ENTER" or by sending out a pulse on DI4: the current dosing is aborted.

²⁾ If the output is configured to switch when an alarm is generated. See chapter 10.7.18.



11.3.5 Resolution of problems without message generation and the device status LED is green

Device state LED	Possible cause	Recommended action
green	During a dosing, the displayed quantity is increased or decreased very slowly.	 → Check that the K-factor corresponds to the fitting used. → Do a Teach-In procedure to determine the K-factor of the fitting used. → Check that the flow rate in the pipe is high enough.
green	The dosing does not start although the procedure has been correctly started:	
	Either the dosing quantity times the set K-factor is lower than 6.	→ Set a dosing quantity that is higher or equal to 6 divided by the set K-factor.
	Either the pipe diameter is too high for the dosing of small quantities.	→ Reduce the pipe diameter.
green	The display shows that the dosing has started (the units blink) but the valve connected to DO2 and/or DO3 does not open.	 → Check the value of the time delay before opening of the valves. → Check that the flow rate in the pipe is high enough.



11.3.6 Resolution of problems linked to warning messages not registered in the Information menu

Device state LED	Output DO4 in "STATE" mode	Message displayed	Possible cause	Recommended action
any colour	-	"PU L LIM"	The message is displayed after the pulse value has been entered (parameter "PU" of the transistor output DO1) or upon validation of the settings of the Parameters menu.	 → Enter a lower quantity per pulse. See chapter 10.7.22.
			The pulse value times the K-factor of the device is > 1000000.	
			The quantity entered for a pulse is too high.	
any colour	-	"PU H LIM"	The message is displayed after the pulse value has been entered (parameter "PU" of the transistor output DO1) or upon validation of the settings of the Parameters menu.	→ Enter a higher quantity per pulse. See chapter 10.7.22.
			The pulse value times the K-factor of the device is < 1.	
			The quantity entered for a pulse is too low.	
any colour	flashes at a 10 Hz-frequency	"CONTINUE"	The power supply has been cut during a dosing	→ Check the electrical installation.
	for 2 seconds after the device has been ener- gized, then flashes at a 1 Hz-frequency		the dosing has been interrupted.	→ Abort the current dosing or continue the dosing: in that case check that the current dosing is correct.
any colour	flashes at a 10 Hz-frequency for 2 s then flashes at a 1 Hz-frequency	Process level	The power supply has been cut during the consultation of the messages of the Information menu via the digital inputs.	→ Check that the PLC knows that the device has returned to the Process level.



12 SPARE PARTS AND ACCESSORIES



CAUTION

Risk of injury and/or damage caused by the use of unsuitable parts.

Incorrect accessories and unsuitable replacement parts may cause injuries and damage the device and the surrounding area.

▶ Use only original accessories and original replacement parts from Bürkert.



The damaged electronic board or housing can be replaced.

• Contact your local Bürkert sales office.

Spare part for 8025 Batch in panel version		Article number
1	Mounting set (screws, washers, nuts, cable clips) (positions 1, 2, 3, 4)	554 807
2	Seal (position 5)	419 350
3 4 4 5 5 5	Set with 8 FLOW foils	553 191

Spare part for 8025 Batch in wall-mounting	Article number	
	Power supply board 115/230 V AC + mounting instruction sheet	555 722



Spare part for the 8025 Batch in compact version		Article number
	Electronic board mounted in the cover with lid, with window, foil and four screws (position 1)	425 432
1	Power supply board 115/230 V AC (position 2) + mounting instruction sheet	553 168
, L	Set including:	
2	• two M20x1.5 cable glands (position 3)	
3 4 5	two neoprene flat seals (position 5) for cable gland or screw plug	449 755
	• two M20x1.5 screw plugs (position 6)	
	• two 2x6 mm multiway seals (position 8)	
	Set including:	
6 7 - 8	• two M20x1.5 / NPT1/2" reductions (mounted o-ring seal) (position 4)	551 782
9	• two neoprene flat seals for plug (position 5)	
	• two M20x1.5 screw plugs (position 6)	
	Set including:	
10	• one M20x1.5 cable gland blanking plug (position 7)	
11	• one multiway seal, 2x6 mm, for cable gland (position 8)	551 775
	• one black EPDM seal (position 12) for the flow sensor	
	one mounting instruction sheet	
12/	Housing (position 9) with snap ring and nut	425 526
	Snap ring (position 10)	619 205
	Nut (position 11)	619 204
	Set including:	
13	• one black EPDM seal (position 12) for the flow sensor	552 111
11/	one green FKM seal (position 12) for the flow sensor	
	Short flow sensor, Hall effect (position 13)	418 316
	Long flow sensor, Hall effect (position 14)	418 324
	Set with 8 FLOW foils	553 191



Spare part for the 8035 Batch a	nd the SE35 Batch	Article number
opare part for the 6000 Batema	Electronic board mounted in the cover with lid, with window, foil and four screws (position 1)	425 432
	Power supply board 115/230 V AC (position 2) + mounting instruction sheet	553 168
1	Set including: • two M20x1.5 cable glands (position 3)	
2	two neoprene flat seals (position 5) for cable gland or screw plug	449 755
- 11 . 1 - 10 . 10 . 10 . 10 . 10 . 10 .	• two M20x1.5 screw plugs (position 6)	
3 4 5	• two 2x6 mm multiway seals (position 8) Set including:	
	• two M20x1.5 / NPT1/2" reductions (mounted o-ring seal) (position 4)	551 782
	• two neoprene flat seals for plug (position 5)	
6 7 8	• two M20x1.5 screw plugs (position 6)	
	Set including:	
	• one M20x1.5 cable gland blanking plug (position 7)	
9	• one multiway seal, 2x6 mm, for cable gland (position 8)	551 775
ځ ځ	one black EPDM seal (unused)	
	one mounting instruction sheet	
	Housing (position 9) with Hall effect flow sensor	425 248
	Set with 8 FLOW foils	553 191



13 PACKAGING, TRANSPORT

NOTICE

Damage due to transport

Transport may damage an insufficiently protected device.

- Transport the device in shock-resistant packaging and away from humidity and dirt.
- ▶ Do not expose the device to temperatures that may exceed the admissible storage temperature range.
- ▶ Protect the electrical interfaces using protective plugs.

14 STORAGE

NOTICE

Poor storage can damage the device.

- ▶ Store the device in a dry place away from dust.
- ► Storage temperature of the device: -10 °C...+60 °C.

15 DISPOSAL OF THE DEVICE

Environmentally friendly disposal



- ► Follow national regulations regarding disposal and the environment.
- ► Collect electrical and electronic devices separately and dispose of them as special waste.

Further information: country.burkert.com

