

# Typ SE58 S

Transmitter



CE

## Operating Instructions

DE

Ausführliche Informationen finden Sie in der Bedienungsanleitung  
unter der Internetadresse:  
[country.burkert.com](http://country.burkert.com) > SE58  
oder  
scannen Sie folgenden QR-Code ein:



EN

Detailed information can be found in the operating instructions  
at the Internet address:  
[country.burkert.com](http://country.burkert.com) > SE58  
or  
scan the following QR code:



FR

Vous trouverez des informations détaillées dans le mode d'emploi  
à l'adresse Internet suivante :  
[country.burkert.com](http://country.burkert.com) > SE58  
ou  
scannez le code QR suivant :



**INDEX**


INTRODUCTION	2
SAFETY INFORMATION	2
SAFETY CONVENTION	3
TECHNICAL CHARACTERISTICS	4
TORQUES	6
ELECTRICAL CONNECTIONS	7
GROUNDING	8
POWER SUPPLY	8
OUTPUTS WIRING	9
ACCESS TO THE CONFIGURATION MENU <i>(ONLY MCP)*</i>	10
START VISUALIZATION PAGES ON MCP INTERFACE <i>(ONLY MCP)*</i>	12
TRANSMITTER ACCESS CODE <i>(ONLY MCP)*</i>	13
MANUAL REVIEWS	19

(\*) Any changes using MCP are not recommended, unless:

- after receiving corresponding training by Burkert,
- done by professional,
- agreed by the end user, and done inline with the MCP manual

## INTRODUCTION

- These operating instructions and the description of device functions are provided as part of the scope of supply.
- They could be modified without prior notice. The improper use, possible tampering of the device or parts of it and substitutions of any components not original, renders the warranty automatically void.
- The flow meter realizes a measure with liquids of conductivity greater than  $20\mu\text{S}/\text{cm}$  in closed conduits, and is composed of a transmitter (described in this manual) and a sensor (refer to the specific manual).
- The transmitter could be coupled directly on the sensor (compact version).



## SAFETY INFORMATION

Any other use than the one described in this manual affects the protection provided by the manufacturer and compromises the safety of people and the entire measuring system and is, therefore, not permitted. The manufacturer is not liable for damaged caused by improper or non-designated use.

Transport the measuring device to the measuring point in the original packaging. In case of carton packaging it is possible to place one above the other but no more than three cartons. In case of wooden packaging don't place one above the other.

Disposal of this product or parts of it must be carried out according to the local public or private waste collection service regulations.

The electromagnetic flow meter must only be installed, connected and maintained by qualified and authorized specialists (e.g. electrical technicians) in full compliance with the instructions in these Operating Instructions, the applicable norms, legal regulations and certificates (depending on the application).

The specialists must have read and understood these Operating Instructions and must follow the instructions it contains. If something isn't clear to you in these Operating Instructions, you must call the Bürkert service. The Operating Instructions provide detailed information about the device.

- The flow meter should only be installed after having verified technical data provided in this operating instructions and on the data plate.
- Specialists must take care during installation and use personal protective equipment as provided by any related security plan about risk assessment.
- Never mount or wire SE58 S while it is connected to the power supply and avoid any liquid contact with the device's internal components.
- Before connecting the power supply check the safety equipment.
- Repairs may only be performed if a genuine spare parts kit is available and this repair work is expressly permitted.
- For the cleaning of the device use only a damp cloth, and for the maintenance/repairs contact the service center.

**Before starting up the equipment please verify the following:**

- Power supply voltage must correspond to that specified on the data plate
- Electric connections must be completed as described
- Ground (earth) connections must be completed as specified

**Verify periodically (every 3-4 months):**

- The power supply cables integrity, wiring and other connected electrical parts
- The housing integrity
- The suitable tightness of the sealing elements
- The front panel integrity (display and keyboard)
- The mechanical fixing of the transmitter to the pipe or wall stand

## SAFETY CONVENTION



DANGER ELECTRIC  
SHOCK



WARNING



PRECAUTIONS



ATTENTION

## TECHNICAL CHARACTERISTICS


### Electrical Characteristic



Device classification: class I, IP67/IP68 installation category II, rated pollution degree 2.

Power supply voltage	Power Max
min10 / max30 V DC	1W

- Voltage variations must not exceed  $\pm 10\%$  of the nominal one.
- Digital input/outputs are insulated up to 500V.
- 4-20mA max load: see graph here below; not insulated from power supply.



### Environmental Use Conditions



- The device can be installed inside or outside buildings
- Altitude: from -200m to 2000m (from -656 to 5602 feet)
- Humidity range: 0-100% (IP 67)

ENVIRONMENTAL TEMPERATURE			LIQUID TEMPERATURE		
	Min *	Max		Min*	Max
°C	-20**	60	°C	-10	100
°F	-4**	140	°F	14	212


[\*] For discontinuous use, a thermostat heat source installation may be necessary

[\*\*] -10 °C, 14 °F if no analog output used

## Data Plate

On the data plate there is some technical information

Transmitter data		Transmitter		Transmitter data	
Transmitter model		Type	<b>SE58 S (B0B1A0A)</b>		
Transmitter serial number		S/N	<b>AAZ000004</b>		
Identification code		ID	<b>XXXXXX</b>		
		Power	<b>18-30 V DC 1W</b>		Min-Max supply voltage range-supply voltage type-max. power consumption
Protection grade		IP	<b>67</b>	MaxTa	<b>60°C</b>
					Maximum ambient operation temperature
Sensor data		Sensor		Sensor data	
Sensor model		Type	<b>SO56 (T10-3B1A)</b>		
Sensor serial number		S/N	<b>09Y006468</b>		
Identification code		ID	<b>XXXXXX</b>		
Nominal Diameter		DN	<b>10</b>	PN	<b>1600 kPa</b>
Lining material		Liner	<b>PTFE</b>	Conn.	<b>ISO 2852</b>
Electrodes number and type		Electr.	<b>2-AISI316L</b>		Maximum nominal pressure
Protection grade		IP	<b>67</b>	MaxTm	<b>130 °C</b>
Coefficient of calibration		KA	<b>-2.4682</b>		Process connection
					Maximum supported medium temperature



## Maintenance




### ATTENTION

In case of the maintenance involving the change of SE58 transmitter or sensor, an additional measurement deviation can occur.

To ensure the original accuracy announced in the datasheet, a flow calibration of the full instrument must be performed by Burkert.

## TORQUES


POS.	DESCRIPTION	TIGHTENING TORQUE Nm
1	SCREW M6x16	3.5
2	PG9 PLUG	4
3	CABLE GLAND PG11	4







## ELECTRICAL CONNECTIONS


### VERSION WITH CABLE





- 1 (+) POWER SUPPLY  
 2 (+) OUTPUT 1 / INPUT  
 3 (+) OUTPUT 2 (OPTIONAL)  
 4 (+) 4-20mA max load: 500Ω OUTPUT (OPTIONAL)  
 5 (-) POWER SUPPLY / OUTPUTS / INPUT  
 6 SHIELD (CONNECT TO GROUND)   
 PIN 5-6 TO BE CONNECT TO THE GROUND



### VERSION WITH CONNECTOR




- 1 (+) POWER SUPPLY  
 2 (+) OUTPUT 1 / INPUT  
 3 (+) OUTPUT 2 (OPTIONAL)  
 4 (+) 4-20mA max load: 500Ω OUTPUT (OPTIONAL)  
 5 (-) POWER SUPPLY / OUTPUTS / INPUT  
 PIN 5 TO BE CONNECT TO THE GROUND 




## GROUNDING



ALWAYS ensure that the device is grounded (earthed) correctly. The grounding ensures that the equipment and liquid are equipotential.




## POWER SUPPLY




- Before connecting the power supply, verify that the main voltage is within the limits indicated on data plate.
- For the connections use only approved conductors, with fire-proof properties, whose section varies from 0.25 mm<sup>2</sup> to 2.50 mm<sup>2</sup>, based on distance/power; additionally fix the power supply wires with an additional fastening system located close to the terminal.
- The power supply line must be equipped with an external protection for overload current (fuse or automatic line breaker).
- Provide in close proximity the transmitter a circuit breaker easily accessible for the operator and clearly identified; whose symbols must conform to the electrical safety and local electrical requirements.
- Ensure that the component complies with the requirements of the standard for electrical safety distance.
- Check chemical compatibility of materials used in the connection security systems in order to minimize electrochemical corrosion.

## OUTPUTS WIRING



### DIGITAL OUTPUTS

- Opto-insulated output
- Maximum switching voltage: 30V ---  
Maximum switching current: 100mA @ 25°C
- Maximum saturation voltage between collector and emitter @100mA: 1.2V ---
- Maximum switching frequency (load on the collector or emitter,  $R_L=470\Omega$ ,  $V_{OUT}=24V$ ): 1250Hz
- Maximum reverse current bearable on the input during and accidental polarity reversion (VEC): 100mA
- Insulation from other secondary circuits: 500V ---



### ANALOG OUTPUT

- Maximum load: see "Electrical Characteristic" page 4
- Refresh frequency equal to the sample frequency
- Protected against persistent over voltages up to 30V ---

**NOTE:** shielded cables are recommended for input and output wiring

## ACCESS TO THE CONFIGURATION MENU

### Access Via Mcp interface (Virtual Display)

You can access the device configuration menu by MCP.

MCP is a software that can be installed on Microsoft Windows® and allows you to set all the functions of the transmitter and customize the menu. To use the MCP interface, see its own manual.

However any changes using MCP are not recommended, unless:

- after receiving corresponding training by burkert,
- done by professional,
- agreed by the end user, and done inline with the MCP manual

With using this MCP software you agree to the following Software Tools End User License Agreement "MCP" (STEULA):

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software") to use the Software, and to permit persons to whom the Software is furnished to do so, subject to the conditions of this STEULA.

#### In a nutshell:

- The Software is intended for use by professionals and professionally, and in connection with our products only;
- While we took care to provide access to a convenient tool, it is not required for the use of our products; we cannot be liable for any consequence in using this Software;
- We will update the Software from time to time based but not regularly and may at any point in time discontinue to offer the Software or its updates for download.
- The Software could include technical or other mistakes, inaccuracies or typographical errors.
- At any time without prior notice, we may make changes to the software pointing to third-party websites or shops or documentation made available on the third-party's website.
- The software may be out of date, and we make no commitment to update such materials.

#### Legal advise:


1. One registered copy of supplied software may either be used by a single person who uses the software personally on one or more computers, or installed on a single computer used non-simultaneously by multiple people, but not both.
2. You may access to software through a network, provided that you have obtained and agreed to individual licenses for the software covering all computers that will access the software through the network regardless if they access the software program concurrently or at different times.
3. You are not allowed to modify its content, decompose, decompile its components, redistribute, offer or sell the Software.
4. You are solely responsible for determining the appropriateness of using the software and assume any risks associated with your exercise of permissions under this license.
5. THIS SOFTWARE AND ANY ACCOMPANYING FILES ARE GIVEN FREE OF CHARGE "AS IS" AND WITHOUT WARRANTIES, EXPRESS OR IMPLIED, AS TO PERFORMANCE OR MERCHANTABILITY OR NON-INFRINGEMENT OF THIRD PARTY RIGHTS.
6. No advice or information, whether oral or written, obtained by you from us shall create any warranty for the software.
7. Good data processing procedure dictates that any program shall be thoroughly tested in a non-critical environment before using the Software. You must assume the entire risk of using the program. NOTE THAT

USING THE SOFTWARE IMPACTS THE OPERABILITY / FUNCTIONALITY OF THE HARDWARE AND MAY HAVE SEVERE CONSEQUENCES FOR THE PRODUCTION OF THE FACILITY THE HARDWARE IS INSTALLED IN.



8. THE SOFTWARE IS IN PARTICULAR NOT DESIGNED, INTENDED, LICENSED, OR AUTHORIZED FOR USE IN ANY TYPE OF SYSTEM OR APPLICATION IN WHICH THE FAILURE OF THE SYSTEM OR APPLICATION COULD CREATE A SITUATION WHERE PERSONAL INJURY OR DEATH MAY OCCURE (E.G., MEDICAL SYSTEMS, LIFE SUPPORT, LIFE-SUSTAINING SYSTEMS, LIFE-SAVING SYSTEMS, OR SECURITY SYSTEMS) OR IN HAZARDOUS ENVIRONMENTS REQUIRING FAIL-SAFE CONTROLS, INCLUDING WITHOUT LIMITATION, THE DESIGN, CONSTRUCTION, MAINTENANCE OR OPERATION OF NUCLEAR FACILITIES, AIRCRAFT NAVIGATION OR COMMUNICATION SYSTEMS, AIR TRAFFIC CONTROL, OR WEAPONS SYSTEMS. LICENSOR SPECIFICALLY DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR SUCH PURPOSES.

9. IN NO EVENT SHALL WE BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.


To connect the transmitter to the computer, connect the USB cable as shown below. Remove the PG9 cap.



Connect USB cable type mini B. Verify connection symbol on display.



## START VISUALIZATION PAGES ON MCP INTERFACE



## TRANSMITTER ACCESS CODE

The access for the device configuration is regulated by six access levels logically grouped. Every level is protected by a different code.

Access Levels 1-2-3-4 Freely configurable by user

### Access Code Set : Menu 13 System

```

SYSTEM
L1 code=*****
L2 code=*****
L3 code=*****
L4 code=*****
L5 code=*****
L6 code=*****
Restr.access= ON
010.011.012.013
010.011.012.014
255.255.255.000
KT= 0.96469
KS= 1.00000
KR= 1.00000
DAC1 4mA= 02460
DAC1 20mA= 11050
FW update
  
```

```

SYSTEM
L1 code=*****
L2 code=*****
L3 code=*****
L4 code=*****
L5 code=*****
L6 code=*****
0199999999
  
```

The CODE is inserted by MCP.

Depending on the level of access different display functions will be visible. These access levels interact with the "Restricted access"

13-System

### Restricted Access Set : Menu 13 System

```

SYSTEM
L1 code=*****
L2 code=*****
L3 code=*****
L4 code=*****
L5 code=*****
L6 code=*****
  
```

Restr.access=OFF

Values

ON

OFF

**Restrict = ON:** Access permitted only to functions provided for a specific level;

**Example:** If the operator has a code of access level 3, after having set it, he can change only the functions with level 3 access.

**Restrict = OFF:** It enables to change functions for the selected level and ALL the functions with lower access level.

**Example:** If the operator has the code of level 3, after having set it, he can change all the functions at level 3 and those at lower levels.




**\* WARNING:** take careful note of the customized code, since there is no way for the user to retrieve or reset it if lost.

### Factory preset access codes:


- L1: 10000000
- L2: 20000000
- L3: 30000000
- L4: 40000000

The following example shows how to change the Full scale by Quick Start menu; the second illustrates how to change the function by the Main menu.


**EXAMPLE:** modifying the full scale value from 4.0 l/s to 5.0 dm<sup>3</sup>/s, from the “Quick start menu”




Press enter key to access in the “Quick Start menu”




Use the right-left arrow keys to select the character and the up-down arrow key to assign the numeric value of the access code



Press the enter key to confirm the access code




Select the FS1 function with the arrow keys  
Press the enter key to modify the function



Press the indicated arrow keys to select the character




Press the arrow keys indicated to change the value



Press the enter button to confirm the changed value




Press the esc key to exit from the “quick start menu” and return to the main page




Main Page




EXAMPLE: modifying the full scale value from 4.0 l/s to 5.0 dm<sup>3</sup>/s, from the “Main Menu” (quick start menu enabled)



Press enter key to access in the “Quick Start menu”



Use the right-left arrow keys to select the character and the up-down arrow key to assign the numeric value of the access code




Press the enter key to confirm the access code




Select the Main Menu function with the arrow keys




Press the enter key to access the main menu




Select menu 3 with the arrow keys




Press the enter key to access menu 3




Select the FS1 function with the arrow keys and press the enter key to confirm




Press the indicated arrow keys to select the character




Press the indicated arrow keys to change the value




Press the enter key to confirm the changed value



Press the esc key to exit from the "quick start menu"



Press the esc key to exit from the menu and return to the main page



Main Page



At the end of its lifetime, this product shall be disposed of in full compliance with the environmental regulations of the state in which it is located.

## MANUAL REVIEWS

REVIEW	DATE	DESCRIPTION
SE58S_EN_DE_BURKERT_R00_1.02.XXXX	25/02/2021	FIRST EDITION
SE58S_QUICK_EN_BU_R01_1.04.XXXX	08/10/2021	Changes to data relating to digital output
SE58S_QUICK_EN_BU_R02_1.04.XXXX	03/12/2021	Added note for maintenance
SE58S_QUICK_EN_BU_R02_1.04.XXXX	26/02/2022	Added notes for MCP and made some corrections on texts

