

## Type 8025 – 8035 – SE35

Flowmeter – Flow Transmitter  
Durchflussmessgerät – Durchflusstransmitter  
Débitmètre – Transmetteur de débit



## Operating Instructions

Bedienungsanleitung  
Manuel d'utilisation

We reserve the right to make technical changes without notice.  
Technische Änderungen vorbehalten.  
Sous réserve de modifications techniques.

©Bürkert SAS, 2013 – 2023

Operating Instructions 2311/07\_EU-ML 00562780 / Original EN

1 ABOUT THESE OPERATING INSTRUCTIONS .....8

1.1 Symbols used.....8

1.2 Definition of the word "device" .....9

2 INTENDED USE .....9

3 BASIC SAFETY INFORMATION .....10

4 GENERAL INFORMATION .....11

4.1 Manufacturer's address and international contacts .....11

4.2 Warranty conditions.....11

4.3 Information on the Internet.....11

5 DESCRIPTION .....12

5.1 Construction of the flowmeter 8025 compact version .....12

5.2 Construction of the flow transmitter 8025 in panel version .....12

5.3 Construction of the flow transmitter 8025 in wall-mounted version.....12

5.4 Construction of the flow transmitter SE35.....13

5.5 Construction of the flowmeter 8035.....13

5.6 Construction of the flow transmitter SE35 with sensor-fitting S070 or S077 .....14

5.7 Description of the type label .....14

5.8 Symbols on the device .....15

6 TECHNICAL DATA .....15

6.1 Technical data of the flowmeter 8025 compact version .....15

6.1.1 Conditions of use of a 8025 compact version.....15

6.1.2 Standards and directives.....16

6.1.3 Fluid data of a 8025 compact version .....16

6.1.4 Material data of a 8025 compact version .....17

6.1.5 Dimensions of a 8025 compact version .....18

6.1.6 Electrical data of a 8025 compact version .....18

6.2 Technical data of the flow transmitter 8025 in panel version.....19

6.2.1 Conditions of use of a 8025 in panel version .....19

6.2.2 Standards and directives.....20

6.2.3 Material data of a 8025 in panel version.....20

6.2.4 Dimensions of a 8025 in panel version .....20

6.2.5 Electrical data of a 8025 in panel version .....20

6.2.6 Specifications of a flow sensor connected to a 8025 in panel version .....21

MAN 1000215667 EN Version: H Status: RL (released | freigegeben) printed: 05.02.2024

<b>6.3</b>	<b>Technical data of the flow transmitter 8025 in wall-mounted version .....</b>	<b>22</b>
6.3.1	Conditions of use of a 8025 in wall-mounted version .....	22
6.3.2	Standards and directives.....	22
6.3.3	Material data of a 8025 in wall-mounted version .....	22
6.3.4	Dimensions of a 8025 in wall-mounted version.....	22
6.3.5	Electrical data of a 8025 in wall-mounted version.....	23
6.3.6	Specifications of a flow sensor connected to a 8025 in wall-mounted version .....	24
<b>6.4</b>	<b>Technical data of the flow transmitter SE35 .....</b>	<b>24</b>
6.4.1	Conditions of use of a flow transmitter SE35 .....	24
6.4.2	Standards and directives.....	24
6.4.3	Material data of a flow transmitter SE35 .....	25
6.4.4	Dimensions of a flow transmitter SE35.....	25
6.4.5	Electrical data of a flow transmitter SE35.....	25
<b>6.5</b>	<b>Technical data of the flowmeter 8035 .....</b>	<b>26</b>
6.5.1	Conditions of use of a flowmeter 8035.....	27
6.5.2	Standards and directives.....	27
6.5.3	Fluid data of a flowmeter 8035.....	28
6.5.4	Material data of a flowmeter 8035 .....	29
6.5.5	Dimensions of a flowmeter 8035 .....	29
6.5.6	Electrical data of a flowmeter 8035 .....	29
<b>6.6</b>	<b>Technical data of the flow transmitter SE35 associated with a sensor-fitting S070 or S077 .....</b>	<b>30</b>
6.6.1	Conditions of use of a SE35 with sensor-fitting S070 or S077 .....	30
6.6.2	Standards and directives.....	30
6.6.3	Fluid data of an SE35 with sensor-fitting S070 or S077.....	31
6.6.4	Material data of an SE35 with sensor-fitting S070 or S077 .....	31
6.6.5	Dimensions of an SE35 with sensor-fitting S070 or S077 .....	31
6.6.6	Electrical data of an SE35 with sensor-fitting S070 or S077.....	31
<b>7</b>	<b>INSTALLATION.....</b>	<b>32</b>
<b>7.1</b>	<b>Safety instructions .....</b>	<b>32</b>
<b>7.2</b>	<b>Fluid installation of the compact version of the flowmeter 8025.....</b>	<b>33</b>
7.2.1	Install the S020 fitting on the pipes .....	33
7.2.2	Installation of the flowmeter 8025 into the fitting S020 .....	34
7.2.3	Finalise the installation of the flowmeter 8025 .....	34
<b>7.3</b>	<b>Installation of the flowmeter 8035 .....</b>	<b>35</b>
7.3.1	Install the S030 sensor-fitting on the pipes .....	35
7.3.2	Install the flow transmitter SE35 on the sensor-fitting S030 .....	35
7.3.3	Finalise the installation of the flowmeter 8035 .....	36

<b>7.4</b>	<b>Installation of the flow transmitter SE35 on the sensor-fitting S070 or S077.....</b>	<b>36</b>
7.4.1	Install the sensor-fitting S070 or S077 on the pipes .....	36
7.4.2	Install the flow transmitter SE35 on the sensor-fitting S070 or S077 .....	37
7.4.3	Finalise installation of the flow transmitter SE35 with the sensor-fitting S070 or S077 .....	37
<b>7.5</b>	<b>Installation of a flow transmitter 8025 in panel version .....</b>	<b>38</b>
<b>7.6</b>	<b>Installation of a flow transmitter 8025 in wall-mounted version .....</b>	<b>39</b>
<b>8</b>	<b>WIRING .....</b>	<b>40</b>
<b>8.1</b>	<b>Safety instructions .....</b>	<b>40</b>
<b>8.2</b>	<b>Specifications of the connection cables.....</b>	<b>41</b>
8.2.1	8025 compact version, 8035 and SE35 .....	41
8.2.2	8025 in panel version.....	42
8.2.3	8025 in wall-mounting version.....	42
<b>8.3</b>	<b>Making the installation equipotential .....</b>	<b>42</b>
<b>8.4</b>	<b>Wiring of devices with a 4 pin male fixed connector .....</b>	<b>44</b>
<b>8.5</b>	<b>Configuring the selectors .....</b>	<b>45</b>
8.5.1	FLOW SENSOR selector .....	45
8.5.2	SOURCE/SINK selector.....	46
8.5.3	115/230 V AC selector.....	46
<b>8.6</b>	<b>Wiring the 8025 compact version, the 8035 and the SE35, with or without relays, with cable glands .....</b>	<b>47</b>
8.6.1	Wiring instructions.....	47
8.6.2	Wiring of the relays (versions with relay output) .....	48
8.6.3	Wiring the power supply, the current output and the pulse output, version 12...36 V DC, without relays.....	48
8.6.4	Wiring the power supply, the current output and the pulse output, version 12...36 V DC, with relays.....	50
8.6.5	Wiring the power supply, the current output and the pulse output, version 115/230 V AC, without relays.....	52
8.6.6	Wiring the power supply, the current output and the pulse output, 115/230 V AC, with relays.....	54
<b>8.7</b>	<b>Wiring the 8025 in panel or in wall-mounted version, 12...36 V DC, with or without relays ...</b>	<b>57</b>
8.7.1	Wiring the power supply, the current output and the pulse output, 12...36 V DC, without relays .....	57
8.7.2	Wiring the power supply, the current output and the pulse output, 12...36 V DC, with relays .....	58
8.7.3	Connecting the flow sensor to the flow transmitter 8025 in panel version or in wall-mounted version .....	60

<b>8.8</b>	<b>Wiring the 8025 in wall-mounted version, 115/230 V AC, with or without relays .....</b>	<b>60</b>
8.8.1	Wiring instructions for a wall-mounted version .....	60
8.8.2	Wiring the power supply, the current output and the pulse output, 115/230 V AC, without relays .....	62
8.8.3	Wiring the power supply, the current output and the pulse output, 115/230 V AC, with relays .....	65
8.8.4	Connecting the flow sensor to the flow transmitter 8025 transmitter in wall-mounted version .....	67
<b>9</b>	<b>OPERATING AND COMMISSIONING .....</b>	<b>68</b>
9.1	Safety instructions .....	68
9.2	Operating levels of the device .....	68
9.3	Description of the navigation keys and the status LEDs .....	70
9.4	Using the navigation keys .....	70
9.5	Details of the Process level .....	71
9.6	Details of the Parameters menu .....	71
9.6.1	Choosing the display language .....	72
9.6.2	Choosing the flow rate units, the number of decimals and the units of the totalizers .....	72
9.6.3	Entering the K-factor of the fitting used .....	74
9.6.4	Configuring the current output .....	75
9.6.5	Configuring the pulse output .....	76
9.6.6	Configuring the relays .....	76
9.6.7	Configuring the filter of the measured flow rate .....	78
9.6.8	Resetting both totalizers .....	78
9.7	Details of the Test menu .....	79
9.7.1	Adjusting the OFFSET of the current output .....	79
9.7.2	Adjusting the SPAN of the current output .....	80
9.7.3	Reading the rotational frequency of the paddle wheel .....	80
9.7.4	Checking the outputs behaviour .....	80
<b>10</b>	<b>MAINTENANCE AND TROUBLESHOOTING .....</b>	<b>81</b>
10.1	Safety instructions .....	81
10.2	Cleaning the device .....	81
10.3	Problem solving .....	82

11 SPARE PARTS AND ACCESSORIES .....83

11.1 Spare parts of the 8025 compact version.....83

11.2 Spare parts of the 8035 or of the SE35.....85

11.3 Spare parts of a 8025 in panel version .....86

11.4 Spare parts of a 8025 in wall-mounted version.....86

12 PACKAGING, TRANSPORT.....86

13 STORAGE .....87

14 DISPOSAL OF THE DEVICE.....87

# 1 ABOUT THESE OPERATING INSTRUCTIONS

These Operating Instructions describes the entire life cycle of the device. Please keep these Operating Instructions in a safe place, accessible to all users and any new owners.

These Operating Instructions contains important safety information.

Failure to comply with these instructions can lead to hazardous situations. Pay attention in particular to the chapters [3 Basic safety information](#) and [2 Intended use](#).

► Whatever the version of the device, these Operating Instructions must be read and understood.

## 1.1 Symbols used



### DANGER

Warns against an imminent danger.

► Failure to observe this warning can result in death or in serious injury.



### WARNING

Warns against a potentially dangerous situation.

► Failure to observe this warning can result in serious injury or even death.



### CAUTION

Warns against a possible risk.

► Failure to observe this warning can result in substantial or minor injuries.

### NOTICE

Warns against material damage.



Indicates additional information, advice or important recommendations.



Refers to information contained in these Operating Instructions or in other documents.

► Indicates an instruction to be carried out to avoid a danger, a warning or a possible risk.

→ Indicates a procedure to be carried out.

✓ Indicates the result of a specific instruction.



## 1.2 Definition of the word "device"

The word "device" used within these Operating Instructions always refers to:

- the flowmeter type 8025 compact version,
- the flow transmitter type 8025 in panel version,
- the flow transmitter type 8025 in wall-mounted version,
- the flowmeter type 8035 or
- the flow transmitter type SE35.

## 2 INTENDED USE

**Use of the device that does not comply with the instructions could present risks to people, nearby installations and the environment.**

The flowmeter type 8025 compact version, the flowmeter type 8035 and the flow transmitter SE35 associated with a sensor-fitting are designed to measure the flow rate of a liquid and to totalise the volume of a liquid.

The flow transmitter type SE35 must be mounted on a sensor-fitting type S030, S070 or S077.

The flow transmitter type 8025 in panel or in wall-mounted version is a transmitter that must be connected to:

- an 8020 flow sensor with a sinus or a pulse output, only in "Low Power" version,
- an 8030 flow sensor with a sinus or a pulse output, only in "Low Power" version.
- Use this device in compliance with the characteristics and commissioning and use conditions specified in the contractual documents and in the operating instructions.
- Never use this device for security applications.
- Protect this device against electromagnetic interference, ultraviolet rays and, when installed outdoors, the effects of climatic conditions.
- Only operate a device in perfect working order.
- Requirements for the safe and proper operation of the device are proper transport, storage and installation, as well as careful operation and maintenance.
- Only use the device as intended.

### 3 BASIC SAFETY INFORMATION

This safety information does not take into account any contingencies or occurrences that may arise during installation, use and maintenance of the product.

The operating company is responsible for the respect of the local safety regulations including for the staff safety.



#### **Danger due to electrical voltage.**

- ▶ If a 12...36 V DC powered version is installed either in a wet environment or outdoors, all the electrical voltages must be of max. 35 V DC.
- ▶ Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- ▶ All equipment connected to the wall-mounted or to the panel versions of the flow transmitter 8025 must be double insulated with respect to the mains according to the standard UL/EN 61010-1.
- ▶ Observe all applicable accident protection and safety regulations for electrical equipment.

#### **Risk of injury due to high pressure in the installation.**

- ▶ Stop the circulation of fluid, cut off the pressure and drain the pipe before loosening the process connections.

#### **Risk of injury due to high fluid temperatures.**

- ▶ Use safety gloves to handle the device.
- ▶ Stop the circulation of fluid and drain the pipe before loosening the process connections.

#### **Risk of injury due to the nature of the fluid.**

- ▶ Respect the prevailing regulations on accident prevention and safety relating to the use of dangerous fluids.



#### **Various dangerous situations**

To avoid injury take care:

- ▶ not to use the device in explosive atmospheres.
- ▶ not to use the device in an environment incompatible with the materials it is made of.
- ▶ not to subject the device to mechanical loads.
- ▶ not to make any modifications to the device.
- ▶ to prevent any unintentional power supply switch-on.
- ▶ to carry out the installation and maintenance work by qualified and skilled staff with the appropriate tools.
- ▶ to guarantee a defined or controlled restarting of the process, after a power supply interruption.
- ▶ to use the device only if in perfect working order and in compliance with the instructions provided in the operating instructions.
- ▶ to observe the general technical rules when installing and using the device.

**NOTICE**

The device may be damaged by the fluid in contact with.

- ▶ Systematically check the chemical compatibility of the component materials of the device and the fluids likely to come into contact with it (for example: alcohols, strong or concentrated acids, aldehydes, alkaline compounds, esters, aliphatic compounds, ketones, halogenated aromatics or hydrocarbons, oxidants and chlorinated agents).

**NOTICE**

**Elements / Components sensitive to electrostatic discharges**

This device contains electronic components sensitive to electrostatic discharges. They may be damaged if they are touched by an electrostatically charged person or object. In the worst case scenario, these components are instantly destroyed or go out of order as soon as they are activated.

- ▶ To minimise or even avoid all damage due to an electrostatic discharge, take all the precautions described in standard EN 61340-5-1.
- ▶ Also ensure that you do not touch any of the live electrical components.

## 4 GENERAL INFORMATION

### 4.1 Manufacturer's address and international contacts

To contact the manufacturer of the device, use following address:

Bürkert SAS

Rue du Giessen

BP 21

F-67220 TRIEMBACH-AU-VAL

You may also contact your local Bürkert sales office.

The addresses of our international sales offices are available on the internet at: [country.burkert.com](https://country.burkert.com)

### 4.2 Warranty conditions

The condition governing the legal warranty is the conforming use of the device in observance of the operating conditions specified in this Operating Instructions.

### 4.3 Information on the Internet

You can find the Operating Instructions and Technical Data Sheets regarding the types 8025, 8035 and SE35 at: [country.burkert.com](https://country.burkert.com)


## 5 DESCRIPTION

According to the version, the device requires a 12...36 V DC or a 115/230 V AC power supply.


The electrical connection is carried out via a male fixed connector or on the terminal blocks of the electronic board: whether directly, whether via 2 or 3 cable glands.

### 5.1 Construction of the flowmeter 8025 compact version


The flowmeter 8025 compact version comprises:

	<p>A: a paddle-wheel flow sensor, the rotation of which generates pulses.</p> <p>Set in rotation by the flow, the 4 permanent magnets integrated in the vanes of the paddle generate pulses, the frequency of which is proportional to the flow velocity of the fluid. A conversion coefficient specific to each pipe (material and diameter) is necessary to establish the flow rate value associated with the measurement.</p> <p>The conversion coefficient (K-factor) expressed in pulses per litre is given in the Operating Instructions for the S020 fitting used, available under <a href="https://country.burkert.com">country.burkert.com</a></p> <p>B: a flow transmitter with display and 2 cable glands</p>
------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### 5.2 Construction of the flow transmitter 8025 in panel version

	<p>The 8025 in panel version is a flow transmitter with display</p>
-------------------------------------------------------------------------------------	---------------------------------------------------------------------

### 5.3 Construction of the flow transmitter 8025 in wall-mounted version

	<p>The 8025 in wall-mounted version is a flow transmitter with display and 3 cable glands</p>
-------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------


## 5.4 Construction of the flow transmitter SE35



The SE35 is a flow transmitter with display and 2 cable glands

## 5.5 Construction of the flowmeter 8035

The flowmeter 8035 comprises:




A: an S030 sensor-fitting including the paddle-wheel flow sensor.

Set in rotation by the flow, the 4 permanent magnets integrated in the vanes of the paddle generate pulses, the frequency of which is proportional to the flow velocity of the fluid. A conversion coefficient specific to each pipe (material and diameter) is necessary to establish the flow rate value associated with the measurement.

The conversion coefficient (K-factor) expressed in pulses per litre is given in the Operating Instructions for the S030 sensor-fitting used available under [country.burkert.com](https://country.burkert.com)

B: a flow transmitter type SE35 (see chapter [5.4](#))

## 5.6 Construction of the flow transmitter SE35 with sensor-fitting S070 or S077



## 5.7 Description of the type label








Fig. 1: Type label of the device (example)

## 5.8 Symbols on the device

Symbol	Description
	Direct current
	Alternating current
	Earth terminal
	Protective conductor terminal

## 6 TECHNICAL DATA

### 6.1 Technical data of the flowmeter 8025 compact version

#### 6.1.1 Conditions of use of a 8025 compact version

<b>Ambient temperature</b>	
• 12...36 V DC version	• –10 °C...+60 °C
• 115/230 V AC version	• –10 °C...+50 °C
<b>Air humidity</b>	< 80 %, non condensated
<b>Height above sea level</b>	≤ 2000 m
<b>Operating conditions</b>	Continuous operation
<b>Mobility of the device</b>	Fixed device
<b>Use</b>	Indoor and outdoor (Protect the device against electromagnetic interference, ultraviolet rays and, when installed outdoors, against the effects of climatic conditions)
<b>Installation category</b>	Category I according to UL 61010-1 (UL device)
	Category II according to EN 61010-1 (non UL device)
<b>Degree of pollution</b>	Degree 2 according to UL/EN 61010-1
<b>Protection class according to IEC/EN 60529</b>	IP65 <sup>1)</sup> , device wired, cover lid screwed tight and cable glands tightened or female connector plugged in and secured with screws (depending on the version)

<sup>1)</sup> not evaluated by UL

## 6.1.2 Standards and directives

The device complies with the relevant EU harmonisation legislation. In addition, the device also complies with the requirements of the laws of the United Kingdom.

The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity/UK Declaration of Conformity.

### Conformity to the Pressure Equipment Directive

→ Make sure the device materials are compatible with the fluid.

→ Make sure the pipe DN and the PN are adapted for the device.

The device conforms to Article 4, Paragraph 1 of the Pressure Equipment Directive 2014/68/EU under the following conditions:



- Device used on a piping (PS = maximum admissible pressure in bar; DN = nominal diameter of the pipe in mm)

Type of fluid	Conditions
Fluid group 1, Article 4, Paragraph 1.c.i	DN ≤ 25
Fluid group 2, Article 4, Paragraph 1.c.i	DN ≤ 32 or PSxDN ≤ 1000
Fluid group 1, Article 4, Paragraph 1.c.ii	DN ≤ 25 or PSxDN ≤ 2000
Fluid group 2, Article 4, Paragraph 1.c.ii	DN ≤ 200 or PS ≤ 10 or PSxDN ≤ 5000

### UL-Certification

Finished devices with variable key PU01 or PU02 are UL-certified devices and comply also with the following standards:

- UL 61010-1
- CAN/CSA-C22.2 n°61010-1

Identification on the device	Certification	Variable key
	UL-recognized	PU01
 Measuring Equipment EXXXXXX	UL-listed	PU02

## 6.1.3 Fluid data of a 8025 compact version

Type of fluid	neutral or slightly aggressive liquids
Fluid viscosity	max. 300 cSt
Rate of solid particles	max. 1 %



<b>Fluid temperature</b>	The fluid temperature may be restricted by the fluid pressure and the material the S020 fitting used is made of (see Fig. 2).
• with S020 fitting in PVC	• 0 °C...+50 °C
• with S020 fitting in PP	• 0 °C...+80 °C
• with S020 fitting in PVDF, stainless steel or brass	• -15 °C...+80 °C
<b>Fluid pressure</b>	PN10 <sup>1)</sup> max The fluid pressure may be restricted by the fluid temperature and the material the S020 fitting used is made of (see Fig. 2).
<b>Flow rate measurement</b>	
• Measurement range	
- Sensor with pulse output (Hall)	- 0.3...10 m/s
- Sensor with sinus output (coil)	- 0.5...10 m/s
• Measurement deviation	
- with standard K-factor of the S020 fitting	- ±2.5 % of the measured value <sup>2)</sup>
- with K-factor determined with a teach-in procedure	- ±1 % of the measured value (at the value of the teach-in flow rate) <sup>2)</sup>
• Linearity	• ±0.5 % of the full scale (10 m/s)
• Repeatability	• ±0.4 % of the measured value <sup>2)</sup>

<sup>1)</sup> not evaluated by UL

<sup>2)</sup> Determined in the following reference conditions: medium = water, water and ambient temperatures 20 °C, min. upstream and downstream distances respected, appropriate pipe dimensions




Fig. 2: Fluid temperature / fluid pressure dependency curves for the 8025 compact version, depending on the material the S020 fitting is made of

#### 6.1.4 Material data of a 8025 compact version

Part	Material
Housing / cover, lid, nut	PC
Frontfoil	Polyester
Screws	Stainless steel
Male fixed connector or cable glands	PA
Identification label	Polyester

Part	Material
<b>Wetted parts</b>	
• Sensor holder / Paddle-wheel	• PVDF
• Axis and bearings of the paddle-wheel	• Ceramics
• Seal	• FKM (optional EPDM)
• Fitting S020	• Refer to the Operating Instructions of the fitting

### 6.1.5 Dimensions of a 8025 compact version

→ Please refer to the technical data sheets regarding the flowmeter type 8025 compact version, available at:  
[country.burkert.com](http://country.burkert.com)

### 6.1.6 Electrical data of a 8025 compact version

12...36 V DC power supply	<ul style="list-style-type: none"> <li>• filtered and regulated</li> <li>• oscillation rate: <math>\pm 10\%</math></li> <li>• The device must be connected permanently to a Safety Extra-Low Voltage circuit (SELV circuit) or Protective Extra Low Voltage (PELV circuit).</li> </ul>
Power source (not supplied) for versions supplied with 12...36 V DC	Energize the device through a Limited Power Source (LPS) according to standards UL/EN 62368-1 or through a limited-energy circuit according to standards UL/EN 61010-1, Paragraph 9.4.
<b>115/230 V AC power supply</b>	
• admissible voltage fluctuation	• $\pm 10\%$
• frequency	• 50/60 Hz
• supplied voltage	• 27 V DC, regulated
• Maximum current	• 125 mA
• integrated protection	• 125 mA time-delay fuse
• power	• 3 VA
Maximum current consumption version 12...36 V DC without relais	25 mA
Maximum current consumption version 12...36 V DC with relais	70 mA
Maximum current consumption version 115/230 V AC	125 mA max. at 27 V DC
<b>Pulse output (transistor)</b>	
• type	• polarized, potential-free
• function	• NPN/PNP (wiring dependant)
• frequency (f)	• pulse output, adjustable pulse value
• electrical data	• 2.5...400 Hz
	• 5...36 V DC, 100 mA max., voltage drop 2.5 V DC at 100 mA
• duty cycle	• 0.5
• protection	• galvanically insulated, and protected against over-voltages, polarity reversals and short-circuits

<b>Relay output</b>	
• operating	• hysteresis, adjustable thresholds, normally open
• electrical data of the load (non UL recognized devices)	• 230 V AC / 3 A or 40 V DC / 3 A (resistive load)
• electrical data of the load (UL recognized devices)	• max. 30 V AC and 42 V peak / 3 A or max. 60 V DC / 1 A  To use the relay outputs in a wet location, observe the following DANGER safety instruction.
<b>Current output</b>	
	4...20 mA, sinking or sourcing mode (wiring dependant)
• accuracy	• $\pm 1 \%$
• response time (10 %...90 %)	• 6 s (default)
• max. loop impedance, 12...36 V DC version	• 900 $\Omega$ at 30 V DC, 600 $\Omega$ at 24 V DC, 50 $\Omega$ at 12 V DC
• max. loop impedance, 115/230 V AC version	• 800 $\Omega$
• wiring, version without relays	• 2-wire
• wiring, version with relays	• 3-wire
Protection against polarity reversals	yes

**DANGER**

Danger due to the operation of the relay outputs of a UL device in a wet location.

► If a UL device is used in a wet location:

- energize the relay outputs with an alternating voltage of max. 16 Vrms and 22.6 Vpeak.
- or energize the relay outputs with a direct voltage of max. 35 V DC.

## 6.2 Technical data of the flow transmitter 8025 in panel version

The following technical data are relevant for the flow transmitter 8025 in panel version, connected to a Bürkert flow sensor 8020, 8030 or SE30 in a "Low Power" version only.

### 6.2.1 Conditions of use of a 8025 in panel version

Ambient temperature	-10 °C...+60 °C
Air humidity	< 80 %, non condensated
Height above sea level	≤ 2000 m
Operating conditions	Continuous operation
Mobility of the device	Fixed device
Use	Indoor and outdoor (Protect the device against electromagnetic interference, ultraviolet rays and, when installed outdoors, against the effects of climatic conditions)
Installation category	Category I according to UL 61010-1 (UL device)
	Category II according to EN 61010-1 (non UL device)
Degree of pollution	Degree 2 according to UL/EN 61010-1
Protection class according to IEC/EN 60529	
• front parts	• IP65 <sup>1)</sup> , installation completed and closed cabinet
• non front parts	• IP20 <sup>1)</sup> in the closed cabinet

<sup>1)</sup> not evaluated by UL

## 6.2.2 Standards and directives



The device complies with the relevant EU harmonisation legislation. In addition, the device also complies with the requirements of the laws of the United Kingdom.

The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity/UK Declaration of Conformity.

### UL-Certification

Finished devices with variable key PU01 or PU02 are UL-certified devices and comply also with the following standards:

- UL 61010-1
- CAN/CSA-C22.2 n°61010-1

Identification on the device	Certification	Variable key
	UL-recognized	PU01
 Measuring Equipment EXXXXXX	UL-listed	PU02

## 6.2.3 Material data of a 8025 in panel version

Part	Material
Housing /cover	PC
Frontfoil	Polyester
Screws (4)	Stainless steel
Cable glands	PA
Identification label	Polyester

## 6.2.4 Dimensions of a 8025 in panel version

→ Please refer to the technical data sheets regarding the flow transmitter type 8025 in panel version, available at: [country.burkert.com](https://country.burkert.com)

## 6.2.5 Electrical data of a 8025 in panel version

12...36 V DC power supply	<ul style="list-style-type: none"> <li>• filtered and regulated</li> <li>• oscillation rate: <math>\pm 10\%</math></li> <li>• The device must be connected permanently to a Safety Extra-Low Voltage circuit (SELV circuit) or Protective Extra Low Voltage (PELV circuit).</li> </ul>
Power source (not supplied) for versions supplied with 12...36 V DC	Energize the device through a Limited Power Source (LPS) according to standards UL/EN 62368-1 or through a limited-energy circuit according to standards UL/EN 61010-1, Paragraph 9.4.

Maximum current consumption version 12...36 V DC without relays	25 mA
Maximum current consumption version 12...36 V DC with relays	70 mA
<b>Pulse output (transistor)</b>	polarized, potential-free
• type	• NPN/PNP (wiring dependant)
• function	• pulse output, adjustable pulse value
• frequency (f)	• 2.5...400 Hz
• electrical data	• 5...36 V DC, 100 mA max., voltage drop 2.5 V DC at 100 mA
• duty cycle	• 0.5
• protection	• galvanically insulated, and protected against over- voltages, polarity reversals and short-circuits
<b>Relay output</b>	
• operating	• hysteresis, adjustable thresholds, normally open
• electrical data of the load (non UL recognized devices)	• 230 V AC / 3 A or 40 V DC / 3 A (resistive load)
• electrical data of the load (UL recognized devices)	• max. 30 V AC and 42 V peak / 3 A or max. 60 V DC / 1 A
	To use the relay outputs in a wet location, observe the following DANGER safety instruction.
<b>Current output</b>	4...20 mA, sinking or sourcing mode (wiring dependant)
• accuracy	• $\pm 1\%$
• response time (10 %...90 %)	• 6 s (default)
• max. loop impedance, 12...36 V DC version	• 900 $\Omega$ à 30 V DC, 600 $\Omega$ à 24 V DC, 50 $\Omega$ à 12 V DC
• wiring, version without relays	• 2-wire
• wiring, version with relays	• 3-wire
Protection against polarity reversals	yes

**DANGER**

Danger due to the operation of the relay outputs of a UL device in a wet location.

► If a UL device is used in a wet location:

- energize the relay outputs with an alternating voltage of max. 16 Vrms and 22.6 Vpeak.
- or energize the relay outputs with a direct voltage of max. 35 V DC.

## 6.2.6 Specifications of a flow sensor connected to a 8025 in panel version

<b>Sensor input</b>	
• signal frequency	• 2.5...400 Hz
• pulse signal (Hall)	• NPN, open collector
• sinus signal (coil)	• typical sensitivity of 35 mV peak-peak, at 252 Hz
<b>Sensor output</b>	
• power supply	• 10...34 V DC (V+ minus 2 V DC), 1 mA max.

## 6.3 Technical data of the flow transmitter 8025 in wall-mounted version

The following technical data are relevant for the flow transmitter 8025 in wall-mounted version, connected to a Bürkert flow sensor 8020, 8030 or SE30 in a "Low Power" version only.

### 6.3.1 Conditions of use of a 8025 in wall-mounted version

Ambient temperature	–10 °C...+60 °C
Air humidity	< 80 %, non condensated
Height above sea level	≤ 2000 m
Operating conditions	Continuous operation
Mobility of the device	Fixed device
Use	Indoor and outdoor (Protect the device against electromagnetic interference, ultraviolet rays and, when installed outdoors, against the effects of climatic conditions)
Installation category	Category I according to UL 61010-1 (UL device)
	Category II according to EN 61010-1 (non UL device)
Degree of pollution	Degree 2 according to UL/EN 61010-1
Protection class according to IEC/EN 60529	IP65 <sup>1)</sup> , device wired, cover lid screwed tight and cable glands tightened

<sup>1)</sup> not evaluated by UL

### 6.3.2 Standards and directives

The device complies with the relevant EU harmonisation legislation. In addition, the device also complies with the requirements of the laws of the United Kingdom.

The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity/UK Declaration of Conformity.

### 6.3.3 Material data of a 8025 in wall-mounted version

Part	Material
Housing, cover	ABS
Frontfoil	Polyester
Screws (4)	Stainless steel
Cable glands / Cable clips	PA
Identification label	Polyester

### 6.3.4 Dimensions of a 8025 in wall-mounted version

→ Please refer to the technical data sheets regarding the flow transmitter type 8025 in wall-mounted version, available at: [country.burkert.com](https://country.burkert.com)

### 6.3.5 Electrical data of a 8025 in wall-mounted version

12...36 V DC power supply	<ul style="list-style-type: none"> <li>• filtered and regulated</li> <li>• oscillation rate: <math>\pm 10\%</math></li> <li>• The device must be connected permanently to a Safety Extra-Low Voltage circuit (SELV circuit) or Protective Extra Low Voltage (PELV circuit).</li> </ul>
Power source (not supplied) for versions supplied with 12...36 V DC	Energize the device through a Limited Power Source (LPS) according to standards UL/EN 62368-1 or through a limited-energy circuit according to standards UL/EN 61010-1, Paragraph 9.4.
115/230 V AC power supply	
• admissible voltage fluctuation	• $\pm 10\%$
• frequency	• 50/60 Hz
• supplied voltage	• 27 V DC, regulated
• Maximum current	• 250 mA
• integrated protection	• 250 mA time-delay fuse
• power	• 6 VA
Maximum current consumption version 12...36 V DC without relays	25 mA
Maximum current consumption version 12...36 V DC with relays	70 mA
Maximum current consumption version 115/230 V AC	250 mA max. at 27 V DC
Pulse output (transistor)	polarized, potential-free
• type	• NPN/PNP (wiring dependant)
• function	• pulse output, adjustable pulse value
• frequency (f)	• 2.5...400 Hz
• electrical data	• 5...36 V DC, 100 mA max., voltage drop 2.5 V DC at 100 mA
• duty cycle	• 0.5
• protection	• galvanically insulated, and protected against over-voltages, polarity reversals and short-circuits
Relay output	
• operating	• hysteresis, adjustable thresholds, normally open
• electrical data of the load	• 230 V AC / 3 A or 40 V DC / 3 A (resistive load)
Current output	4...20 mA, sinking or sourcing mode (wiring dependant)
• accuracy	• $\pm 1\%$
• response time (10 %...90 %)	• 6 s (default)
• max. loop impedance, 12...36 V DC version	• 900 $\Omega$ à 30 V DC, 600 $\Omega$ à 24 V DC, 50 $\Omega$ à 12 V DC
• max. loop impedance, 115/230 V AC version	• 800 $\Omega$
• wiring, version without relays	• 2-wire
• wiring, version with relays	• 3-wire
Protection against polarity reversals	yes

### 6.3.6 Specifications of a flow sensor connected to a 8025 in wall-mounted version

<b>Sensor input</b>	
• signal frequency	• 2.5...400 Hz
• pulse signal (Hall)	• NPN, open collector
• sinus signal (coil)	• typical sensitivity of 35 mV peak-peak, at 252 Hz
<b>Sensor output</b>	
• power supply	• 10...34 V DC (V+ minus 2 V DC), 1 mA max.

## 6.4 Technical data of the flow transmitter SE35



The technical data of the flow transmitter SE35 may be restricted by the sensor-fitting used.

► Please refer to the Operating Instructions of the concerned fitting or sensor-fitting.

### 6.4.1 Conditions of use of a flow transmitter SE35

<b>Ambient temperature</b>	
• 12...36 V DC version	• –10 °C...+60 °C
• 115/230 V AC version	• –10 °C...+50 °C
<b>Air humidity</b>	< 80 %, non condensated
<b>Height above sea level</b>	≤ 2000 m
<b>Operating conditions</b>	Continuous operation
<b>Mobility of the device</b>	Fixed device
<b>Use</b>	Indoor and outdoor (Protect the device against electromagnetic interference, ultraviolet rays and, when installed outdoors, against the effects of climatic conditions)
<b>Installation category</b>	Category I according to UL 61010-1 (UL device)
	Category II according to EN 61010-1 (non UL device)
<b>Degree of pollution</b>	Degree 2 according to UL/EN 61010-1
<b>Protection class according to IEC/EN 60529</b>	IP65 <sup>1)</sup> , device wired, cover lid screwed tight and cable glands tightened or female connector plugged in and secured with screws (depending on the version)

<sup>1)</sup> not evaluated by UL

### 6.4.2 Standards and directives

The device complies with the relevant EU harmonisation legislation. In addition, the device also complies with the requirements of the laws of the United Kingdom.



The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity/UK Declaration of Conformity.

#### UL-Certification

Finished devices with variable key PU01 or PU02 are UL-certified devices and comply also with the following standards:

- UL 61010-1
- CAN/CSA-C22.2 n°61010-1



Identification, on the device	Certification	Variable key
	UL-recognized	PU01
 Measuring Equipment EXXXXXX	UL-listed	PU02

### 6.4.3 Material data of a flow transmitter SE35

Part	Material
Housing / cover / lid / nut	PC
Frontfoil / screws	Polyester
Screws	Stainless steel
Male fixed connector or cable glands	PA
Identification label	Polyester

### 6.4.4 Dimensions of a flow transmitter SE35

→ Please refer to the technical data sheets regarding the flow transmitter SE35, available at:  
[country.burkert.com](http://country.burkert.com)

### 6.4.5 Electrical data of a flow transmitter SE35

12...36 V DC power supply	<ul style="list-style-type: none"> <li>• filtered and regulated</li> <li>• oscillation rate: <math>\pm 10\%</math></li> <li>• The device must be connected permanently to a Safety Extra-Low Voltage circuit (SELV circuit) or Protective Extra Low Voltage (PELV circuit).</li> </ul>
Power source (not supplied) for versions supplied with 12...36 V DC	Energize the device through a Limited Power Source (LPS) according to standards UL/EN 62368-1 or through a limited-energy circuit according to standards UL/EN 61010-1, Paragraph 9.4.
115/230 V AC power supply	
• admissible voltage fluctuation	• $\pm 10\%$
• frequency	• 50/60 Hz
• supplied voltage	• 27 V DC, regulated
• Maximum current	• 125 mA
• integrated protection	• 125 mA time-delay fuse
• power	• 3 VA
Maximum current consumption version 12...36 V DC without relays	25 mA
Maximum current consumption version 12...36 V DC with relays	70 mA
Maximum current consumption version 115/230 V AC	125 mA max. at 27 V DC

<b>Pulse output (transistor)</b>	polarized, potential-free
• type	• NPN/PNP (wiring dependant)
• function	• pulse output, adjustable pulse value
• frequency (f)	• 2.5...400 Hz
• electrical data	• 5...36 V DC, 100 mA max., voltage drop 2.5 V DC at 100 mA
• duty cycle	• 0.5
• protection	• galvanically insulated, and protected against over-voltages, polarity reversals and short-circuits
<b>Relay output</b>	
• operating	• hysteresis, adjustable thresholds, normally open
• electrical data of the load (non UL recognized devices)	• 230 V AC / 3 A or 40 V DC / 3 A (resistive load)
• electrical data of the load (UL recognized devices)	• max. 30 V AC and 42 V peak / 3 A or max. 60 V DC / 1 A
	To use the relay outputs in a wet location, observe the following DANGER safety instruction.
<b>Current output</b>	4...20 mA, sinking or sourcing mode (wiring dependant)
• accuracy	• $\pm 1 \%$
• response time (10 %...90 %)	• 6 s (default)
• max. loop impedance, 12...36 V DC version	• 900 $\Omega$ at 30 V DC, 600 $\Omega$ at 24 V DC, 50 $\Omega$ at 12 V DC
• max. loop impedance, 115/230 V AC version	• 800 $\Omega$
• wiring, version without relays	• 2-wire
• wiring, version with relays	• 3-wire
Protection against polarity reversals	yes



## DANGER

Danger due to the operation of the relay outputs of a UL device in a wet location.

► If a UL device is used in a wet location:

- energize the relay outputs with an alternating voltage of max. 16 Vrms and 22.6 Vpeak.
- or energize the relay outputs with a direct voltage of max. 35 V DC.

## 6.5 Technical data of the flowmeter 8035

The flowmeter 8035 comprises an S030 sensor-fitting including the paddle-wheel flow sensor and a flow transmitter type SE35 (see chapter 5.5).



The technical data of the flowmeter 8035 may be restricted by the S030 sensor-fitting used.

► Please refer to the Operating Instructions of the concerned sensor-fitting S030.

### 6.5.1 Conditions of use of a flowmeter 8035

<b>Ambient temperature</b>	
• 12...36 V DC version	• -10 °C...+60 °C
• 115/230 V AC version	• -10 °C...+50 °C
<b>Air humidity</b>	< 80 %, non condensated
<b>Height above sea level</b>	≤ 2000 m
<b>Operating conditions</b>	Continuous operation
<b>Mobility of the device</b>	Fixed device
<b>Use</b>	Indoor and outdoor (Protect the device against electromagnetic interference, ultraviolet rays and, when installed outdoors, against the effects of climatic conditions)
<b>Installation category</b>	Category I according to UL 61010-1 (UL device)
	Category II according to EN 61010-1 (non UL device)
<b>Degree of pollution</b>	Degree 2 according to UL/EN 61010-1
<b>Protection class according to IEC/EN 60529</b>	IP65 <sup>1)</sup> , device wired, cover lid screwed tight and cable glands tightened or female connector plugged in and secured with screws (depending on the version)

<sup>1)</sup> not evaluated by UL

### 6.5.2 Standards and directives

The device complies with the relevant EU harmonisation legislation. In addition, the device also complies with the requirements of the laws of the United Kingdom.

The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity/UK Declaration of Conformity.

#### Conformity to the Pressure Equipment Directive

- Make sure the device materials are compatible with the fluid.
- Make sure the pipe DN and the PN are adapted for the device.

The device conforms to Article 4, Paragraph 1 of the Pressure Equipment Directive 2014/68/EU under the following conditions:



- Device used on a piping (PS = maximum admissible pressure in bar; DN = nominal diameter of the pipe in mm)

Type of fluid	Conditions
Fluid group 1, Article 4, Paragraph 1.c.i	DN ≤ 25
Fluid group 2, Article 4, Paragraph 1.c.i	DN ≤ 32 or PSxDN ≤ 1000
Fluid group 1, Article 4, Paragraph 1.c.ii	DN ≤ 25 or PSxDN ≤ 2000
Fluid group 2, Article 4, Paragraph 1.c.ii	DN ≤ 200 or PS ≤ 10 or PSxDN ≤ 5000

## UL-Certification

Finished devices with variable key PU01 or PU02 are UL-certified devices and comply also with the following standards:

- UL 61010-1
- CAN/CSA-C22.2 n°61010-1

Identification on the device	Certification	Variable key
	UL-recognized	PU01
 Measuring Equipment EXXXXXX	UL-listed	PU02

## 6.5.3 Fluid data of a flowmeter 8035

Type of fluid	neutral or slightly aggressive liquids
Fluid viscosity	max. 300 cSt
Rate of solid particles	max. 1 %
Fluid temperature	The fluid temperature may be restricted by the fluid pressure and the material the S030 sensor-fitting used is made of (see Fig. 3)
• with sensor-fitting S030 in PVC	• 0 °C...+50 °C
• with sensor-fitting S030 in PP	• 0 °C...+80 °C
• with sensor-fitting S030 in PVDF, stainless steel or brass	• -15 °C...+100 °C
Fluid pressure	The fluid pressure may be restricted by the fluid temperature and the material the S030 sensor-fitting used is made of (see Fig. 3)
• with sensor-fitting S030 in plastic	PN10 <sup>1)</sup>
• with sensor-fitting S030 in metal	PN16 <sup>1)</sup> (PN40 <sup>1)</sup> on request)
Flow rate measurement	
• Measurement range	• 0.3...10 m/s
• Measurement deviation	
- with standard K-factor of the S030 sensor-fitting	- ±2.5 % of the measured value <sup>2)</sup>
- with K-factor determined with a teach-in procedure	- ±1 % of the measured value <sup>2)</sup> (at the value of the teach-in flow rate)
• Linearity	• ±0.5 % of the full scale (10 m/s)
• Repeatability	• ±0.4 % of the measured value <sup>2)</sup>

<sup>1)</sup> not evaluated by UL

<sup>2)</sup> Determined in the following reference conditions: medium = water, water and ambient temperatures 20 °C, min. upstream and downstream distances respected, appropriate pipe dimensions




Fig. 3: Fluid temperature/pressure dependency curves for the flowmeter 8035, depending on the material the S030 sensor-fitting is made of

#### 6.5.4 Material data of a flowmeter 8035

Part	Material
Housing / cover / lid / nut	PC
Frontfoil	Polyester
Screws	Stainless steel
Male fixed connector or cable glands	PA
Identification label	Polyester
<b>Wetted parts</b>	
• Sensor-fitting S030	• Refer to the Operating Instructions of the sensor-fitting

#### 6.5.5 Dimensions of a flowmeter 8035

→ Please refer to the technical data sheets regarding the flowmeter 8035, available at: [country.burkert.com](https://country.burkert.com)

#### 6.5.6 Electrical data of a flowmeter 8035

→ Please refer to the electrical data of the flow transmitter SE35, chapter 6.4.5, page 25.

## 6.6 Technical data of the flow transmitter SE35 associated with a sensor-fitting S070 or S077



The technical data of the flow transmitter SE35 associated with a sensor-fitting S070 or S077 may be restricted by the S070 or S077 sensor-fitting used.

► Refer to the Operating Instructions of the related sensor-fitting S070 or S077.

### 6.6.1 Conditions of use of a SE35 with sensor-fitting S070 or S077

<b>Ambient temperature</b>	
• 12...36 V DC version	• –10 °C...+60 °C
• 115/230 V AC version	• –10 °C...+50 °C
<b>Air humidity</b>	< 80 %, non condensated
<b>Height above sea level</b>	≤ 2000 m
<b>Operating conditions</b>	Continuous operation
<b>Mobility of the device</b>	Fixed device
<b>Use</b>	Indoor and outdoor (Protect the device against electromagnetic interference, ultraviolet rays and, when installed outdoors, against the effects of climatic conditions)
<b>Installation category</b>	Category I according to UL 61010-1 (UL device)
	Category II according to EN 61010-1 (non UL device)
<b>Degree of pollution</b>	Degree 2 according to UL/EN 61010-1
<b>Protection class according to IEC/EN 60529</b>	IP65 <sup>1)</sup> , device wired, cover lid screwed tight and cable glands tightened or female connector plugged in and secured with screws (depending on the version)

<sup>1)</sup> not evaluated by UL

### 6.6.2 Standards and directives

The device complies with the relevant EU harmonisation legislation. In addition, the device also complies with the requirements of the laws of the United Kingdom.

The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity/UK Declaration of Conformity.

#### Conformity to the Pressure Equipment Directive

→ Make sure the device materials are compatible with the fluid.

→ Make sure the pipe DN and the PN are adapted for the device.

The device conforms to Article 4, Paragraph 1 of the Pressure Equipment Directive 2014/68/EU under the following conditions:

- Device used on a piping (PS = maximum admissible pressure in bar; DN = nominal diameter of the pipe in mm)

Type of fluid	Conditions
Fluid group 1, Article 4, Paragraph 1.c.i	DN ≤ 25
Fluid group 2, Article 4, Paragraph 1.c.i	DN ≤ 32 or PSxDN ≤ 1000
Fluid group 1, Article 4, Paragraph 1.c.ii	DN ≤ 25 or PSxDN ≤ 2000
Fluid group 2, Article 4, Paragraph 1.c.ii	DN ≤ 200 or PS ≤ 10 or PSxDN ≤ 5000

### 6.6.3 Fluid data of an SE35 with sensor-fitting S070 or S077

Type of fluid	Please refer to the Operating Instructions of the concerned sensor-fitting S070 or S077	
Fluid temperature	The fluid temperature may be restricted by the fluid pressure and the material the S070 or S077 sensor-fitting used is made of. <ul style="list-style-type: none"><li>• Please refer to the Operating Instructions delivered with the sensor-fitting S070 or S077 or to the concerned technical datasheet.</li></ul>	
Fluid pressure	The fluid pressure may be restricted by the fluid temperature and the material the S070 or S077 sensor-fitting used is made of. <ul style="list-style-type: none"><li>• Please refer to the Operating Instructions delivered with the sensor-fitting S070 or S077 or to the concerned technical datasheet.</li></ul>	
Flow rate measurement		
• Measurement range		
- viscosity > 5 mPa.s	- S070: 2...1200 l/min	- S077: 2...1200 l/min
- viscosity < 5 mPa.s	- S070: 3...616 l/min	- S077: 3...616 l/min
• Measurement deviation		
- with standard K-factor of the sensor-fitting	- S070 : ±0.5 % of the measured value <sup>1)</sup>	- S077 : ±1 % of the measured value <sup>1)</sup>
- with K-factor determined with a teach-in procedure	- S070 : ±0.5 % of the measured value <sup>1)</sup> (at the value of the teach-in flow rate)	- S077 : ±0.5 % of the measured value <sup>1)</sup> (at the value of the teach-in flow rate)
• Repeatability	• ±0.03 % of the measured value <sup>1)</sup>	

<sup>1)</sup> Determined in the following reference conditions: medium = water, water and ambient temperatures 20 °C, min. upstream and downstream distances respected, appropriate pipe dimensions

### 6.6.4 Material data of an SE35 with sensor-fitting S070 or S077

Part	Material
Housing / cover / lid / nut	PC
Frontfoil	Polyester
Screws	Stainless steel
Male fixed connector or cable glands	PA
Identification label	Polyester
<b>Wetted parts</b>	
• Sensor-fitting S070	• Refer to the Operating Instructions of the concerned sensor-fitting

### 6.6.5 Dimensions of an SE35 with sensor-fitting S070 or S077

→ Please refer to the technical data sheets regarding the flowmeter 8035, available at: [country.burkert.com](https://country.burkert.com)

### 6.6.6 Electrical data of an SE35 with sensor-fitting S070 or S077

→ Please refer to the electrical data of the flow transmitter SE35, chapter 6.4.5, page 25.

## 7 INSTALLATION

### 7.1 Safety instructions



#### **DANGER**

**Risk of injury due to electrical voltage.**

- ▶ If a 12...36 V DC or a 14...36 V DC powered version is installed either in a wet environment or outdoors, all the electrical voltages must be of max. 35 V DC.
- ▶ Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- ▶ All equipment connected to the wall-mounted or to the panel versions of the flow transmitter 8025 must be double insulated with respect to the mains according to the standard UL/EN 61010-1.
- ▶ Observe all applicable accident protection and safety regulations for electrical equipment.

**Risk of injury due to high pressure in the installation.**

- ▶ Stop the circulation of fluid, cut off the pressure and drain the pipe before loosening the process connections.

**Risk of injury due to high fluid temperatures.**

- ▶ Use safety gloves to handle the device.
- ▶ Stop the circulation of fluid and drain the pipe before loosening the process connections.

**Risk of injury due to the nature of the fluid.**

- ▶ Respect the prevailing regulations on accident prevention and safety relating to the use of aggressive fluids.



#### **WARNING**

**Risk of injury due to nonconforming installation.**

- ▶ The electrical and fluid installation can only be carried out by qualified and skilled staff with the appropriate tools.
- ▶ Observe mounting instructions of the fitting or sensor-fitting.

**Risk of injury due to unintentional switch on of power supply or uncontrolled restarting of the installation.**

- ▶ Take appropriate measures to avoid unintentional activation of the installation.
- ▶ Guarantee a set or controlled restarting of the process subsequent to any intervention on the device.

**Risk of injury if the fluid pressure/temperature dependency is not respected.**

- ▶ Take account of fluid temperature-pressure dependency according to the nature of the materials the fitting is made of (see the technical data and the operating instructions of the fitting used).
- ▶ Comply with the Pressure Equipment Directive 2014/68/EU.



Protect this device against electromagnetic interference, ultraviolet rays and, when installed outdoors, the effects of the climatic conditions.



## 7.2 Fluid installation of the compact version of the flowmeter 8025

The compact version of the flowmeter 8025 is inserted into an S020 fitting mounted on the pipes:

1. Install the S020 fitting on the pipes,
2. Install the compact version of the flowmeter 8025 in the S020 fitting,
3. Finalise the installation of the 8025.

### 7.2.1 Install the S020 fitting on the pipes

→ Select an S020 fitting suitable for the speed of the fluid in the pipes



To select a fitting, refer to the calculation tables on the technical data sheet for the relevant fitting.

→ Choose a position for the fitting according to the design of the pipes, in such a way that:

- the upstream and downstream distances are respected according to the design of the pipes, see [Fig. 4](#) and norm EN ISO 5167-1,
- the pipes are always filled to the level of the sensor (see [Fig. 5](#)),
- when mounted vertically, the flow direction of the fluid is upwards (see [Fig. 5](#)),
- air bubbles do not form around the sensor (see [Fig. 5](#)).

→ If necessary, use a flow conditioner to improve measurement precision,

→ Install the fitting on the pipes according to the instructions in the relevant Operating Instructions.




Fig. 4: Upstream and downstream distances depending on the design of the pipes




Fig. 5: Filling of the pipe, flow direction of the fluid, Vertical mounting Air bubbles within the pipe

## 7.2.2 Installation of the flowmeter 8025 into the fitting S020




Fig. 6: Installation of the flowmeter 8025 compact version on the S020 fitting

## 7.2.3 Finalise the installation of the flowmeter 8025

- Wire the device and switch it on (see chapter 8.6).
- Set the K-factor or determine it with Teach-In (see chapter 9.6.3).

## 7.3 Installation of the flowmeter 8035

The flowmeter 8035 comprises a flow transmitter SE35 and a sensor-fitting S030. The flow transmitter SE35 is assembled on the sensor-fitting S030 by a quarter-turn rotation system:

1. Install the S030 sensor-fitting on the pipes,
2. Install the flow transmitter SE35 on the sensor-fitting S030,
3. Finalise the installation of the flowmeter 8035.

### 7.3.1 Install the S030 sensor-fitting on the pipes

→ Select a sensor-fitting S030 suitable for the speed of the fluid in the pipes



To select a sensor-fitting, refer to the calculation tables on the technical data sheet for the relevant sensor-fitting.


→ Choose a position for the sensor-fitting according to the design of the pipes, in such a way that:

- the upstream and downstream distances are respected according to the design of the pipes, see [Fig. 4](#), chapter [7.2.1](#) and norm EN ISO 5167-1,
- the pipes are always filled to the level of the sensor (see [Fig. 5](#), chapter [7.2.1](#)),
- when mounted vertically, the flow direction of the fluid is upwards (see [Fig. 5](#), chapter [7.2.1](#)),
- air bubbles do not form around the sensor-fitting (see [Fig. 5](#), chapter [7.2.1](#)).

→ If necessary, use a flow conditioner to improve measurement precision,

→ Install the sensor-fitting on the pipes according to the instructions in the relevant Operating Instructions.

### 7.3.2 Install the flow transmitter SE35 on the sensor-fitting S030



→ Install the flow transmitter [2] in the sensor-fitting [1].

→ Turn the flow transmitter [2] by a quarter turn.

→ Tighten the lateral screw or screws [3] to lock the flow transmitter in place on the sensor-fitting.

Fig. 7: Installation of the flow transmitter SE35 on the sensor-fitting S030

### 7.3.3 Finalise the installation of the flowmeter 8035

- Wire the flow transmitter SE35 and switch it on (see chapter 8.6).
- Set the K-factor or determine it with Teach-In (see chapter 9.6.3).

## 7.4 Installation of the flow transmitter SE35 on the sensor-fitting S070 or S077

The flow transmitter SE35 is installed on the pipes using the sensor-fitting S070 or S077. The flow transmitter SE35 is assembled on the sensor-fitting S070 or S077 by a quarter-turn system:

1. Install the sensor-fitting S070 or S077 on the pipes,
2. Install the flow transmitter SE35 on the sensor-fitting S070 or S077,
3. Finalise installation.

### 7.4.1 Install the sensor-fitting S070 or S077 on the pipes

- Select a sensor-fitting S070 or S077 suitable for the viscosity of the fluid.



To select a sensor-fitting, refer to the technical data sheet for the relevant sensor-fitting.



#### CAUTION

Risk of damage when installing the sensor-fitting.

- ▶ Follow the installation instructions given in the Operating Instructions for the sensor-fitting.

- Install the sensor-fitting S070 or S077 on the pipes in such a way that:

- the axles of the oval gears are set horizontally, as shown in Fig. 8,
- the installation instructions given in the Operating Instructions for the relevant sensor-fitting are respected.




Fig. 8: The axle of the oval gears must be horizontal

### 7.4.2 Install the flow transmitter SE35 on the sensor-fitting S070 or S077




Fig. 9: Installation of the flow transmitter SE35 on the sensor-fitting S070 or S077

### 7.4.3 Finalise installation of the flow transmitter SE35 with the sensor-fitting S070 or S077

- Wire the device and switch it on (see chapter [8.6](#)).
- Set the K-factor or determine it with Teach-In (see chapter [9.6.3](#)).

## 7.5 Installation of a flow transmitter 8025 in panel version



Install the panel version of the device in a cabinet with a protection class at least IP54 to ensure a degree of pollution 2 inside the cabinet.

→ Respect the dimensions indicated in [Fig. 10](#) to cut the opening in the cabinet door.




Fig. 10: Dimensions [mm] of the electrical cabinet frontage cutting plan




Fig. 11: Installation of a flow transmitter 8025 in panel version

- Insert the 4 screws in the housing (from the front). If the cabinet door is too thick use the 4 supplied M4\*25 screws.
- Insert the seal on the external threads of the 4 screws (rear of the housing).
- Put the assembly on the cutout, electronics turned to the inside of the cabinet.
- Put the 4 washers on the 4 screws.
- Put a nut on each of the 4 screws and tighten the nuts to secure the device to the cabinet.
- Wire according to the instructions in chapter [8.6](#), [8.6.3](#) or [8.7.3](#).
- Set the K-factor or determine it with Teach-In (see chapter [9.6.3](#)).

## 7.6 Installation of a flow transmitter 8025 in wall-mounted version

### NOTICE

**Risk of material damage if the cable glands are not tightly screwed on the housing**

- Before installing the wall-mounted housing on its support, tighten the nuts of the entry item of the cables glands at a torque of 1.5 Nm.

The flow transmitter in a wall-mounted version has 4 holes in the bottom of the housing.

→ Remove the blanking strips covering the screws (Fig. 12).




Fig. 12: Location of the fastening nuts and the covering strips

→ Loosen the 4 screws and open the cover to get access to the holes [1].




Fig. 13: Installation of a wall-mounted version

- Secure the housing to the support respecting the dimensions indicated in Fig. 13.
- Wire according to the instructions in chapter 8.6, 8.6.3 or 8.7.3.
- Close the housing and tighten the 4 screws of the cover.
- Set the K-factor or determine it with Teach-In (see chapter 9.6.3).

## 8 WIRING

### 8.1 Safety instructions



#### **DANGER**

**Risk of injury due to electrical voltage.**

- ▶ If a 12...36 V DC or a 14...36 V DC powered version is installed either in a wet environment or outdoors, all the electrical voltages must be of max. 35 V DC.
- ▶ Disconnect the electrical power for all the conductors and isolate it before carrying out work on the system.
- ▶ All equipment connected to the wall-mounted or to the panel versions of the flow transmitter 8025 must be double insulated with respect to the mains according to the standard UL/EN 61010-1.
- ▶ Observe all applicable accident protection and safety regulations for electrical equipment.



#### **AVERTISSEMENT**

**Risk of injury due to non-conforming installation.**

- ▶ The electrical and fluid installation can only be carried out by qualified and skilled staff with the appropriate tools.
- ▶ Fit a circuit breaker or a switch to the electrical installation in which the device is installed.
- ▶ Install the circuit breaker or switch in a place which is easy to reach.
- ▶ Identify the circuit breaker or switch as the electrical power cut-off system for the device.
- ▶ Install appropriate overload safety devices. For the versions fed at 115/230 V AC, insert the device protecting against overcurrents in the live conductor (L) and the neutral conductor (N).
- ▶ Do not power a device, version 12...36 V DC, with an alternating voltage or with a direct voltage higher than 36 V DC.
- ▶ Do not power a device, version 115/230 V AC, with an alternating voltage higher than 230 V AC, or with a direct voltage.



#### **AVERTISSEMENT**

**Risk of injury due to unintentional switch on of power supply or uncontrolled restarting of the installation.**

- ▶ Take appropriate measures to avoid unintentional activation of the installation.
- ▶ Guarantee a set or controlled restarting of the process subsequent to any intervention on the device.



Protect the device against electromagnetic interference, ultraviolet rays and, when installed outdoors, the effects of the climatic conditions.



For a correct operation of the device, respect the following recommendations for the electrical installation:

- Make sure the installation is equipotential. See chapter [8.3](#).
- Do not install the cables near high voltage or high frequency cables; if a combined installation cannot be avoided, a minimum space of 30 cm should be respected.





For a device fed at 12...36 V DC, respect the following recommendations for the electrical installation:

- Use a filtered and regulated 12...36 V DC power supply. The circuit has to be safety extra low voltage (SELV) or Protective Extra Low Voltage (PELV circuit), with a safe energy level.



The power supply of the device can be damaged if it is not protected.

- Protect the device power supply by means of a 300 mA slow blow fuse and a switch.



The power supply of a transistor output can be damaged if it is not protected.

- Protect the power supply of each transistor output by means of a 125 mA slow blow fuse.



The relays can be damaged if not protected.

- Protect the relays by means of a max. 3 A fuse and a circuit breaker (depending on the process).
- Do not apply both a dangerous voltage and a safety extra-low voltage to the relays.



The device can be damaged if it is not tight.

- Insert the supplied blanking plugs into the unused cable glands to ensure the tightness of the device.

## 8.2 Specifications of the connection cables

### 8.2.1 8025 compact version, 8035 and SE35

Specification of the cables and the conductors (not supplied)	Recommended value
Shielded cable	yes
Length of the cable	max. 50 m
External diameter of the cable	5...8 mm
Operating temperature, UL device	min. 90 °C
Operating temperature, non UL device	min. 80 °C
Cross section of the local earth conductor	min. 0.75 mm <sup>2</sup>
Cross section of the conductors, except the local earth conductor	0.2...1.5 mm <sup>2</sup>

Tab. 1: Specifications of the cables and wires for the female connector type 2518 with article number 00572264 (supplied), or the female connector type 2509 with article number 00162673 (not supplied)

Specification of the cables and the conductors (not supplied)	Recommended value
Shielded cable	yes
Length of the cable	max. 50 m
External diameter of the cable, if 1 cable per cable gland	6...12 mm
External diameter of a cable, if 2 cables per cable gland	3...5 mm, using the supplied multi-way seal
Operating temperature, UL device	min. 90 °C
Operating temperature, non UL device	min. 80 °C
Cross section of the local earth conductor	min. 0.75 mm <sup>2</sup>
Cross section of the conductors, except the local earth conductor	0.2...1.5 mm <sup>2</sup>

Tab. 2: Specifications of the cables and wires for the wiring through the M20x1.5 cable glands

## 8.2.2 8025 in panel version

Specification of the cables and the conductors (not supplied)	Recommended value
Shielded cable	yes
Length of the cable	max. 50 m
Operating temperature, UL device	min. 90 °C
Operating temperature, non UL device	min. 80 °C
Cross section of the conductors	0.2...1.5 mm <sup>2</sup>

Tab. 3: Specifications of the cables and wires for the direct wiring to the terminal blocks of a panel-mounted version

## 8.2.3 8025 in wall-mounting version


Specification of the cables and the conductors (not supplied)	Recommended value
Shielded cable	yes
Length of the cable	max. 50 m
External diameter of the cable, if 1 cable per cable gland	4...8 mm
Operating temperature, UL device	min. 90 °C
Operating temperature, non UL device	min. 80 °C
Cross section of the conductors	0.2...1.5 mm <sup>2</sup>

Tab. 4: Specifications of the cables and wires for the wiring through the M16x1.5 cable glands

## 8.3 Making the installation equipotential

To ensure the equipotentiality of the installation (power supply - device - fluid):

- Connect together the various earth spots in the installation to eliminate the potential differences that may occur between different earthes.
- Observe faultless earthing of the shield of the power supply cable, at both ends.
- Connect the negative power supply terminal to the earth to suppress the effects of common mode currents. If this connection cannot be made directly, a 100 nF/50 V capacitor can be fitted between the negative power supply terminal and the earth.
- Special attention has to be paid if the device is installed on plastic pipes because direct earthing is not possible. Proper earthing is performed by earthing together the metallic instruments such as pumps or valves, that are as close as possible to the device. If no such instrument is near the device, insert metallic earth rings inside the plastic pipes upstream and downstream from the device and connect these parts to the same earth. The earth rings must be in contact with the fluid.






Fig. 14: Flowmeter 8025 compact version, flowmeter 8035 and flow transmitter SE35 - Equipotentiality skeleton diagram with metal or plastic pipes




Fig. 15: Flow transmitter 8025 in panel or wall-mounted version - Equipotentiality skeleton diagram with metal or plastic pipes

## 8.4 Wiring of devices with a 4 pin male fixed connector




Fig. 16: Pin assignment of the 4 pin male fixed connector

→ Assemble and wire the female connector type 2518 (supplied) according to Fig. 17.




Fig. 17: Assembling and wiring the female connector type 2518 (supplied)

→ Wire the electrical supply and the current output using one of the wiring plans of Fig. 18.




Fig. 18: Possible wiring of the current output of a device with 4 pin male fixed connector

→ Wire the transistor output using one of the wiring plans of Fig. 19.




Fig. 19: Wiring of the pulse output in NPN or PNP mode, of a device with 4 pin male fixed connector

## 8.5 Configuring the selectors



Make sure the power supply is off before moving the selectors.



A device with 4 pin male fixed connector has no selectors to configure.

→ Before wiring the device, configure the selectors on the electronic board: see chapter 8.5.1 to 8.5.3.

### 8.5.1 FLOW SENSOR selector

The FLOW SENSOR selector makes it possible to configure the type of flow sensor: coil or Hall.



For the version with male fixed connector, the selector is factory-set depending on the output signal of the flow sensor mounted on the device.

► Do not modify the selector position on a device with male fixed connector.




Fig. 20: Position of the FLOW SENSOR connector on the electronic board

Tab. 5: Positioning of the FLOW SENSOR selector depending on the output signal of the flow sensor

Output signal of the remote sensor	Position of the FLOW SENSOR selector
Pulse, NPN (hall)	NPN
Sinus (coil)	COIL

## 8.5.2 SOURCE/SINK selector

On a device with relays, the SOURCE/SINK selector enables to set the 4...20 mA current output, in sourcing or in sinking mode.

→ Set the selector depending on the type of wiring.




Fig. 21: Position of the SOURCE/SINK selector on a device with relay

Tab. 6: Positioning of the SOURCE/SINK selector depending on the wiring of the current output on a device with relays

Wiring the 4...20 mA output	Position of the SOURCE/SINK selector on a device with relays
Not wired (jumper wire in place)	SOURCE
Sourcing mode	SOURCE
Sinking mode	SINK

## 8.5.3 115/230 V AC selector

The 115/230 V AC selector enables to configure the supply voltage of a device supplied with 115/230 V AC.




Fig. 22: Supply voltage selector on a device supplied with 115/230 V AC

## 8.6 Wiring the 8025 compact version, the 8035 and the SE35, with or without relays, with cable glands


### 8.6.1 Wiring instructions



Seal the unused cable gland using the blanking plug supplied to make sure the device is tight.

- Unscrew the nut of the cable gland.
- Remove the transparent disc inside the cable gland.
- Insert the blanking plug.
- Screw the nut back.

- Unfasten the screw and lift the transparent lid.
- Untighten the 4 screws and remove the cover from the device.
- For the versions with relays, insert the cable clip as shown [Fig. 23](#).



→ Insert the supplied cable clips into:

- the slots of the electronic board,
- and, if the device has such a board, the slots of the 115/230 V AC power supply board.

Fig. 23: Inserting the cable clips

- Unscrew the nuts of the cable glands.
- Pass the cables through a nut and through a cable gland.
- Set the selectors according to chapter [8.5](#).
- Connect the terminal block according to chapters [8.6.2](#) to [8.6.6](#).

## 8.6.2 Wiring of the relays (versions with relay output)



### DANGER

Danger due to the operation of the relay outputs of a UL device in a wet location.

► If a UL device is used in a wet location:

- energize the relay outputs with an alternating voltage of max. 16 Vrms and 22.6 Vpeak.
- or energize the relay outputs with a direct voltage of max. 35 V DC.




Fig. 24: Wiring of the relays

## 8.6.3 Wiring the power supply, the current output and the pulse output, version 12...36 V DC, without relays

→ Before wiring the device, configure the selectors on the electronic board (see chapter 8.5).

→ Obey the wiring instructions given in chapter 8.6.1.




Fig. 25: Terminal assignment of a version 12...36 V DC without relays, with cable glands







Fig. 26: Possible wiring of the current output of a version 12...36 V DC, without relays, with cable glands



*Fig. 27: Wiring, in NPN or PNP mode, of the pulse output of a version 12...36 V DC, without relays, with cable glands*

## 8.6.4 Wiring the power supply, the current output and the pulse output, version 12...36 V DC, with relays

→ Before wiring the device, configure the selectors on the electronic board (see chapter 8.5).

→ Obey the wiring instructions given in chapter 8.6.1.




Fig. 28: Terminal assignment of a version 12...36 V DC, with relays, with cable glands




Fig. 29: Wiring, in sourcing or sinking mode, of the current output of a 12...36 V DC version, with relays, with cable glands




Fig. 30: Wiring, in NPN or PNP mode, of the pulse output of a 12...36 V DC version, with relays, with cable glands






Fig. 32: Wiring of the current output of a 115/230 V AC version, without relays, with cable glands




Fig. 33: Wiring, in NPN or PNP mode, of the pulse output of a 115/230 V AC version, without relays, with cable glands

## 8.6.6 Wiring the power supply, the current output and the pulse output, 115/230 V AC, with relays

→ Before wiring the device, configure the selectors on the electronic board (see chapter 8.5).

→ Obey the wiring instructions given in chapter 8.6.1.




Fig. 34: Terminal assignment of a 115/230 V AC version with relays, with cable glands

→ Connect the relays according to chapter 8.6.2.




Fig. 35: Wiring in sourcing mode of the current output of 115/230 V AC version, with relays, with cable glands




Fig. 36: Wiring in sinking mode of the current output of a 115/230 V AC version, with relays, with cable glands




Fig. 37: Wiring, in NPN or PNP mode, of the pulse output of a 115/230 V AC version, with relays, with cable glands



## 8.7 Wiring the 8025 in panel or in wall-mounted version, 12...36 V DC, with or without relays

### 8.7.1 Wiring the power supply, the current output and the pulse output, 12...36 V DC, without relays

- For a wall-mounted version, follow the wiring instructions of chapter [8.8.1](#).
- Configure the FLOW SENSOR selector on the electronic board (see chapter [8.5.1](#)).
- Connect the flow sensor to the flow transmitter according to chapter [8.7.3](#).




Fig. 38: Terminal assignment of a flow transmitter 8025 in panel or wall-mounted version, 12...36 V DC, without relays

- Wire the current output according to [Fig. 39](#).




Fig. 39: Possible wiring of the current output of a version 12...36 V DC, without relays

→ Wire the pulse output according to Fig. 40.




Fig. 40: Wiring, in NPN or PNP mode, of the pulse output of a version 12...36 V DC, without relays, with cable glands

## 8.7.2 Wiring the power supply, the current output and the pulse output, 12...36 V DC, with relays

→ For a wall-mounted version, follow the wiring instructions of chapter 8.8.1.

→ Before wiring the device, configure the selectors on the electronic board (see chapter 8.5).

→ Connect the flow sensor to the transmitter according to chapter 8.7.3.




Fig. 41: Terminal assignment for the flow transmitter 8025 in panel or wall-mounted version, 12...36 V DC, with relays

- Insert the cable clips: see Fig. 23. chapter 8.6.1.
- Wire the relays according to chapter 8.6.2.
- Wire the current output according to Fig. 42.




Fig. 42: Wiring, in sourcing or sinking mode, of the current output of a 12...36 V DC version, with relays, with cable glands

- Wire the pulse output according to Fig. 43.




Fig. 43: Wiring in NPN or PNP mode, of the pulse output of a 12...36 V DC version, with relays, with cable glands

### 8.7.3 Connecting the flow sensor to the flow transmitter 8025 in panel version or in wall-mounted version

- Configure the FLOW SENSOR selector on the electronic board (see chapter 8.5).
- Connect the remote flow sensor to the FLOW SENSOR terminal block of the electronic board by respecting the pin assignment depending on the output type of the remote sensor, either sinus (COIL) or pulse output (NPN).




Fig. 44: Wiring of the remote flow sensor to the flow transmitter 8025

## 8.8 Wiring the 8025 in wall-mounted version, 115/230 V AC, with or without relays

### 8.8.1 Wiring instructions for a wall-mounted version



Seal the unused cable gland using the supplied blanking plug to make sure the device is tight.

- Unscrew the nut of the cable gland.
- Remove the transparent disc inside the cable gland.
- Insert the blanking plug.
- Screw the nut back.

- Connect the flow sensor to the flow transmitter 8025 according to chapter 8.7.3.
- Configure the selectors on the electronic board: see chapter 8.5.
- Loosen the nuts of the cable glands.
- Insert each cable through a nut then through the cable gland, using the cable glands as shown in Fig. 45.




Fig. 45: Using the cable glands

- Remove the two terminal blocks (marked [4] and [6] in Fig. 46, chapter 8.8.2 and Fig. 50, chapter 8.8.3) from the housing.

**For versions without relays:**

→ Wire the device according to chapter [8.8.2](#).

**For versions with relays:**

→ Insert the cable clips: see [Fig. 23](#), chapter [8.6.1](#).

→ Wire the device according to chapter [8.8.3](#).

→ Insert the two terminal blocks (marked [4] and [6] in [Fig. 46](#) chapter [8.8.2](#) and [Fig. 50](#) chapter [8.8.3](#)) into their original position.

→ Let the housing completely open.

→ Secure:

- the power supply cable with a cable clip,
- the flow sensor connection cable with a cable clip
- and (depending on the version) the relay connection cables with a cable clip.

→ Tighten the cable glands making sure the cable in the housing is long enough to allow complete opening of the housing.

→ Close the cover.

→ Tighten the 4 screws.

→ Put the blanking strips on the housing.

## 8.8.2 Wiring the power supply, the current output and the pulse output, 115/230 V AC, without relays

→ Before wiring the device, follow the instructions of chapter 8.8.1.




Fig. 46: Terminal assignment of a wall-mounted version, 115/230 V AC, without relays




Fig. 47: Wiring of the current output of a wall-mounted version, 115/230 V AC, without relays




Fig. 48: Wiring in NPN mode of the pulse output of a wall-mounted version, 115/230 V AC, without relays




Fig. 49: Wiring in PNP mode of the pulse output of a wall-mounted version, 115/230 V AC, without relays



### 8.8.3 Wiring the power supply, the current output and the pulse output, 115/230 V AC, with relays

→ Before wiring the device, follow the instructions of chapter [8.8.1](#).




Fig. 50: Terminal assignment of a wall-mounted version, 115/230 V AC, with relays

→ Refer to Fig. 48 and Fig. 49.



### 8.8.4 Connecting the flow sensor to the flow transmitter 8025 transmitter in wall-mounted version

- Configure the FLOW SENSOR selector on the electronic board (see chapter 8.5).
- Connect the remote flow sensor to the FLOW SENSOR terminal block of the electronic board by respecting the pin assignment depending on the output type of the remote sensor, either sinus (COIL) or pulse output (NPN).




Fig. 53: Wiring of the remote flow sensor to the 8025 transmitter

## 9 OPERATING AND COMMISSIONING

### 9.1 Safety instructions



#### WARNING

**Risk of injury due to nonconforming operating.**

Non-conforming operating could lead to injuries and damage the device and its surroundings.

- ▶ The operators in charge of operating must have read and understood the contents of these Operating Instructions.
- ▶ In particular, observe the safety recommendations and intended use.
- ▶ The device/installation must only be operated by suitably trained staff.



#### WARNING

**Danger due to non-conforming commissioning.**

Non-conforming commissioning could lead to injuries and damage the device and its surroundings.

- ▶ Before commissioning, make sure that the staff in charge have read and fully understood the contents of the Operating Instructions.
- ▶ In particular, observe the safety recommendations and intended use.
- ▶ The device / the installation must only be commissioned by suitably trained staff.
- ▶ Before commissioning, set the K-factor of the fitting used. See chapter 9.6.3.

### 9.2 Operating levels of the device

The device has two operating levels: the Process level and the Configuration level.

The Process level makes it possible:

- to read the flow rate measured by the device, the value of the current transmitted on the 4...20 mA analogue output, the values of both the daily and main totalizers;
- to reset the daily totalizer;
- to access the Configuration level.

The Configuration level has two menus (Parameters, Test) and makes it possible:

- to set the device parameters;
- to test some device settings.

Tab. 7: Default settings of the device

Function	Default value
LANGUAGE	English
UNIT of the flow rate	L/min, 1 decimal
UNIT of the totalizers	L
Number of decimal positions	1
4 mA current output	0.000
20 mA current output	100.0
K FACTOR	51.20

Function	Default value
FILTER	5
Value of a pulse (PU)	00.05
Unit of the pulse output	L
Relay 1–	40.0
Relay 1+	50.0
Relay 1 inverted	no
Relay 2–	80.0
Relay 2+	90.0
Relay 2 inverted	no




Fig. 54: Diagram of the levels of the device

## 9.3 Description of the navigation keys and the status LEDs




Fig. 55: Description of the display

## 9.4 Using the navigation keys

You want to ...	Press ...
move between parameters within a level or a menu.	<ul style="list-style-type: none"> <li> to go the next parameter.</li> <li> to go to the previous parameter.</li> </ul>
access the Parameters menu.	+  simultaneously for 5 s, in the Process level
access the Test menu.	+  +  simultaneously for 5 s, in the Process level
reset the daily totalizer, from the Process level.	+  simultaneously for 2 s, when the daily totalizer is displayed in the Process level
select the displayed parameter.	
confirm the displayed value.	
modify a numerical value.	<ul style="list-style-type: none"> <li> to increase the blinking digit.</li> <li> to select the digit at the left of the blinking digit.</li> <li> +  to move the decimal point.</li> </ul>

## 9.5 Details of the Process level

This level is active by default when the device is energized.






Fig. 56: Diagram of the Process level

## 9.6 Details of the Parameters menu

To access the Parameters menu, simultaneously press keys   for at least 5 s.

This menu comprises the following configurable parameters:




Fig. 57: Diagram of the Parameters menu

## 9.6.1 Choosing the display language

When the device is energized for the first time, the display language is English.





Fig. 58: Diagram of the "LANGUAGE" parameter of the Parameters menu

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press  to save the settings and go back to the Process level.

## 9.6.2 Choosing the flow rate units, the number of decimals and the units of the totalizers

The max. flow rate that can be displayed depends on the number of decimals chosen:

- 9999 if the number of decimals = 0.
- 999.9 if the number of decimals = 1.
- 99.99 if the number of decimals = 2.
- 9.999 if the number of decimals = 3.



The max. flow rate that can be displayed by the totalizers depends on the volume unit chosen:

- 9999999 if the volume unit chosen is "litre";
- 999999 if the volume unit chosen is "m<sup>3</sup>" or "gallon".



- When the flow rate unit is changed convert the flow rate values set within the "CURRENT", "PULSE" and "RELAYS" parameters of the Parameters menu.



The "UNIT" parameter makes it possible to choose:

- the flow rate units;
- a fixed number of decimals (choice 0, 1, 2 or 3) to display the flow rate in the Process level;
- the volume units of the totalizers if the unit previously chosen is in litres, in m<sup>3</sup> or in gallons.







Fig. 59: Diagram of the "UNIT" parameter of the Parameters menu

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press  to save the settings and go back to the Process level.

### 9.6.3 Entering the K-factor of the fitting used

The device determines the flow rate in the pipe using the fitting K-factor.

The K-factor of the fitting used can be entered here. The device may also determine the K-factor using a teach-in procedure: see Fig. 61.



The K-factor of the fitting used is in the Operating Instructions of the fitting.

The Operating Instructions of the Bürkert fittings is available on the internet at: [country.burkert.com](http://country.burkert.com).




Fig. 60: Entering the K-factor of the fitting used

The teach-in is done depending on a known volume.

→ Prepare a tank with a known volume.

→ Stop the fluid circulation.

→ Confirm "TEACH Y.": "FILL END." is displayed.





Fig. 61: Teach-in procedure depending on a volume

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings and go back to the Process level.

## 9.6.4 Configuring the current output

The 4...20 mA output provides an electrical current, the value of which reflects the flow rate measured by the device.

Example of relation between the measuring range and the current output:



- To invert the output signal, give a lower flow rate value to the 20 mA current value than to the 4 mA current value.
- To disable the current output, set both range bounds, 4 and 20 mA, to zero. In this case the output delivers a constant current of 4 mA.



The units and number of decimal digits are those set within the "UNIT" parameter for the display of the current output values.





Fig. 62: Configuration of the current output

- If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press  to save the settings and go back to the Process level.

## 9.6.5 Configuring the pulse output

This parameter makes it possible to enter the volume of liquid related to a pulse.




Fig. 63: Configuration of the pulse output

! If the message "PU H LIM" or "PU L LIM" is displayed, see chapter 10.3.

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings and go back to the Process level.

## 9.6.6 Configuring the relays

This parameter makes it possible to set the switching thresholds and to invert or not the operating behaviour of each relay.

Both relays work in an hysteresis operating. The output status changes when a threshold is reached:

- by increasing flow rate, the output status changes when the threshold X+ is reached.
- by decreasing flow rate, the output status changes when the threshold X- is reached.

Operating behaviour, not inverted	Operating behaviour, inverted
<p>Diagram showing Contact ON/OFF vs Flow rate. The hysteresis loop is labeled "Inverted NO".</p>	<p>Diagram showing Contact ON/OFF vs Flow rate. The hysteresis loop is labeled "Inverted YES".</p>
<p>X- = low switching threshold (1-, 2-)</p> <p>X+ = high switching threshold (1+, 2+)</p>	

Fig. 64: Hysteresis operating, inverted or not inverted

→ Enter values such as 1- ≤ 1+ and/or 2- ≤ 2+.




Fig. 65: Configuration of the thresholds of the relays

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings and go back to the Process level.

### 9.6.7 Configuring the filter of the measured flow rate

This parameter makes it possible to dampen the fluctuations:

- of the display;
- of the current output.

Ten filters are available.

The following table gives the response time for each filter (10 %...90 %):

FILTER	Response time		FILTER	Response time
0	0.15 s		5	6 s
1	0.7 s		6	10 s
2	1.4 s		7	19 s
3	2.5 s		8	33 s
4	3.5 s		9	50 s




Fig. 66: Diagram of the "FILTER" parameter of the Parameters menu

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings and go back to the Process level.

### 9.6.8 Resetting both totalizers

This parameter makes it possible to reset both totalizers.






Fig. 67: Diagram of the "TOTAL" parameter of the Parameters menu

The daily totalizer can be reset from the Process level. See chapter [9.4](#).

→ If you do not want to adjust another parameter, go to the "END" parameter of the Parameters menu and press to save the settings and go back to the Process level.

## 9.7 Details of the Test menu

To access the Test menu, simultaneously press keys    for at least 5 s.

This menu comprises the following configurable parameters:




Fig. 68: Diagram of the Test menu

### 9.7.1 Adjusting the OFFSET of the current output

This parameter makes it possible to adjust the 4 mA current value transmitted on the 4...20 mA output.

→ Connect a multimeter into the measurement loop.






Fig. 69: Adjustment of the OFFSET

→ Adjust the default 20 mA current value: see chapter 9.7.2.

 The adjusted value of the default 4 mA value (parameter "OFFSET") is taken into account when leaving the parameter "SPAN".

→ If you do not want to adjust another parameter, go to the "END" parameter of the Test menu and press  to save the settings and go back to the Process level.

## 9.7.2 Adjusting the SPAN of the current output

This parameter makes it possible to adjust the 20 mA current value transmitted on the 4...20 mA output.

→ Connect a multimeter into the measurement loop.




Fig. 70: Adjustment of the SPAN

→ If you do not want to adjust another parameter, go to the "END" parameter of the Test menu and press



to save the settings and go back to the Process level.

## 9.7.3 Reading the rotational frequency of the paddle wheel




Fig. 71: Diagram of the "FREQUENC." parameter of the Test menu

→ If you do not want to adjust another parameter, go to the "END" parameter of the Test menu and press



to save the settings and go back to the Process level.

## 9.7.4 Checking the outputs behaviour

This parameter makes it possible to simulate a flow rate in order to check that the outputs are behaving as expected by the configuration made.




Fig. 72: Diagram of the "FLOW" parameter of the Test menu

→ If you do not want to adjust another parameter, go to the "END" parameter of the Test menu and press



to save the settings and go back to the Process level.



## 10 MAINTENANCE AND TROUBLESHOOTING

### 10.1 Safety instructions



#### **DANGER**

**Danger due to electrical voltage.**

- ▶ Shut down the electrical power source of all the conductors and isolate it before carrying out work on the system.
- ▶ Observe all applicable accident protection and safety regulations for electrical equipment.

**Risk of injury due to high pressure in the installation.**

- ▶ Stop the circulation of fluid, cut off the pressure and drain the pipe before loosening the process connections.

**Risk of injury due to high fluid temperatures.**

- ▶ Use safety gloves to handle the device.
- ▶ Stop the circulation of fluid and drain the pipe before loosening the process connections.

**Risk of injury due to the nature of the fluid.**

- ▶ Respect the prevailing regulations on accident prevention and safety relating to the use of dangerous fluids.



#### **WARNING**

**Risk of injury due to nonconforming maintenance.**

- ▶ Maintenance must only be carried out by qualified and skilled staff with the appropriate tools.
- ▶ Guarantee a defined or controlled restarting of the process after a power supply interruption.

### 10.2 Cleaning the device

The device can be cleaned with a cloth dampened with water or a detergent compatible with the materials the device is made of.

Please feel free to contact your Bürkert supplier for any additional information.

## 10.3 Problem solving

Message displayed	Possible cause	Recommended action
ERROR 3	Memory read error: the user settings are lost.	→ Switch the device off. → Switch the device on. → If the message is still displayed, press the ENTER key to acknowledge the error: the device operates with the default settings. → Adjust the device again. → If the message appears frequently, send the device back to your supplier.
ERROR 4	Memory read error: the totalizer values are lost.	→ Press the ENTER key to acknowledge the error: the values of the totalizers are set to those of the last start of the device. → Check the values of the totalizers.
ERROR 5	Memory read error: the user settings and the totalizer values are lost.	→ Press the ENTER key to acknowledge the error: the device operates with the default settings and the values of the totalizers are set to those of the last start of the device. → Adjust the device again. → Check the values of the totalizers. → If the message appears frequently, send the device back to your supplier.
ERROR 6	Memory read error: the totalizer values are lost.	→ Press the ENTER key to acknowledge the error: the totalizers are reset.
ERROR 7	Memory read error: the user settings and the totalizer values are lost.	→ Press the ENTER key to acknowledge the error: the totalizers are reset. → Send the device back to your supplier.
PWR FAIL	The supply voltage is too low. <ul style="list-style-type: none"> <li>• The voltage at the device terminals is lower than 12 V.</li> <li>• The impedance of the current measurement loop is too high (see chapter 6.1.6).</li> </ul>	→ Adjust the supply voltage so that the voltage at the device terminals is between 12 V and 36 V.
PU H LIM	The pulse value times the K-factor of the device is > 1000000.  The entered volume for a pulse is too high.	→ Enter a lower volume / pulse. See chapter 9.6.5. → Check the K-factor value. See chapter 9.6.3.
PU L LIM	The pulse value times the K-factor of the device is < 1.  The entered volume for a pulse is too low.	→ Enter a higher volume / pulse. See chapter 9.6.5. → Check the K-factor value. See chapter 9.6.3.

## 11 SPARE PARTS AND ACCESSORIES



### CAUTION

Risk of injury and/or damage caused by the use of unsuitable parts.

- ▶ Incorrect accessories and unsuitable replacement parts may cause injuries and damage the device and the surrounding area.
- ▶ Use only original accessories and original replacement parts from Bürkert.



The defective electronic board or housing of your device can be replaced.

- ▶ Contact the local Bürkert office.

### 11.1 Spare parts of the 8025 compact version




Fig. 73: Exploded view of the spare parts of a 8025, compact version

Position Fig. 73	Designation	Article number
1	115/230 V AC supply voltage board + replacement instructions	553 168
2	Female connector with cable gland (type 2518)	572 264
3	Female connector type 2509 with NPT 1/2" reduction	162 673
4+6+7+9	Set including: <ul style="list-style-type: none"> <li>• 2 M20*1.5 cable glands</li> <li>• 2 neoprene flat seals for cable gland or plug</li> <li>• 2 M20*1.5 screw plugs</li> <li>• 2 2*6 mm multi-way seals</li> </ul>	449 755
5+6+7	Set including: <ul style="list-style-type: none"> <li>• 2 M20*1.5 / NPT1/2" reductions (with mounted seals)</li> <li>• 2 neopren flat seals for the screw plug</li> <li>• 2 M20*1.5 screw plugs</li> </ul>	551 782
8+9+14	Set including: <ul style="list-style-type: none"> <li>• 1 M20*1.5 cable gland blanking plug</li> <li>• 1 2*6 mm multi-way seal for a cable gland</li> <li>• 1 black EPDM seal for the flow sensor</li> <li>• 1 mounting instruction sheet</li> </ul>	551 775
10 + 2	Housing with female connector type 2518, snap ring and nut	425 524
11	Housing for 2 M20*1.5 cable glands, snap ring and nut	425 526
12	Snap ring	619 205
13	Nut	619 204
14	Set including: <ul style="list-style-type: none"> <li>• 1 FKM green seal</li> <li>• 1 EPDM black seal</li> </ul>	552 111
15	Flow sensor (coil) for DN15 to DN100 (1/4"...4") pipes + replacement instructions	633 366
	Flow sensor (Hall) for DN15 to DN100 (1/4"...4") pipes + replacement instructions	418 316
16	Flow sensor (coil) for DN ≥ 100 (≥ 5") + replacement instructions	634 757
	Flow sensor (Hall) for DN ≥ 100 (≥ 5") + replacement instructions	418 324
	Set with 8 FLOW foils	553 191

## 11.2 Spare parts of the 8035 or of the SE35




Fig. 74: Exploded view of the spare parts of a flowmeter 8035 or a flow transmitter SE35

Position Fig. 74	Designation	Article number
1	115/230 V AC supply voltage board + replacement instructions	553 168
2	Female connector with cable gland (type 2518)	572 264
3	Female connector type 2509 with NPT 1/2" reduction	162 673
4+6+7+9	Set including: <ul style="list-style-type: none"> <li>• 2 M20*1.5 cable glands</li> <li>• 2 neoprene flat seals for cable gland or plug</li> <li>• 2 M20*1.5 screw plugs</li> <li>• 2 2*6 mm multi-way seals</li> </ul>	449 755
5+6+7	Set including: <ul style="list-style-type: none"> <li>• 2 M20*1.5 / NPT1/2" reductions (with mounted seals)</li> <li>• 2 neopren flat seals for the screw plug</li> <li>• 2 M20*1.5 screw plugs</li> </ul>	551 782
8+9	Set including: <ul style="list-style-type: none"> <li>• 1 M20*1.5 cable gland blanking plug</li> <li>• 1 2*6 mm multi-way seal for a cable gland</li> <li>• 1 black EPDM seal</li> <li>• 1 mounting instruction sheet</li> </ul>	551 775
10+2	Housing with female connector type 2518, coil function	425 246
11	Housing for 2 M20*1.5 cable glands, coil function	425 247
11	Housing for 2 M20*1.5 cable glands, Hall function	425 248
	Set with 8 FLOW foils	553 191

### 11.3 Spare parts of a 8025 in panel version




Fig. 75: Exploded view of the spare parts of a flow transmitter 8025 in panel version

Position Fig. 75	Designation	Article number
1	Mounting set (screws, washers, nuts, cable clips)	554 807
2	Seal	419 350
	Set with 8 FLOW foils	553 191

### 11.4 Spare parts of a 8025 in wall-mounted version

Designation	Article number
115/230 V AC supply voltage board + replacement instructions	555 722

## 12 PACKAGING, TRANSPORT

### NOTICE

#### Damage due to transport

Transport may damage an insufficiently protected device.

- ▶ Transport the device in shock-resistant packaging and away from humidity and dirt.
- ▶ Do not expose the device to temperatures outside the admissible storage temperature range.
- ▶ Protect the electrical interfaces using protective plugs.

## 13 STORAGE

### NOTICE

Poor storage can damage the device.

- ▶ Store the device in a dry place away from dust.
- ▶ Storage temperature of the device: see [Tab. 8](#).
- ▶ Storage temperature of the fitting or sensor-fitting:  
refer to the Operating Instructions of the corresponding fitting or sensor-fitting.

Tab. 8: Storage temperature of the versions of the device

Device	Power supply	Storage temperature
Flowmeter 8025 compact version	12...36 V DC	–10 °C...+60 °C
	115/230 V AC	–10 °C...+50 °C
Flow transmitter 8025 in panel version	12...36 V DC	–10 °C...+60 °C
Flow transmitter 8025 in wall-mounted version	12...36 V DC	–10 °C...+60 °C
	115/230 V AC	–10 °C...+60 °C
Flowmeter 8035 / Flow transmitter SE35	12...36 V DC	–10 °C...+60 °C
	115/230 V AC	–10 °C...+50 °C

## 14 DISPOSAL OF THE DEVICE

### Environmentally friendly disposal



- ▶ Follow national regulations regarding disposal and the environment.
- ▶ Collect electrical and electronic devices separately and dispose of them as special waste.

Further information: [country.burkert.com](https://country.burkert.com)







