

# Type 8652 AirLINE

Modular valve island for pneumatics



Operating Instructions

We reserve the right to make technical changes without notice.

© Bürkert Werke GmbH & Co. KG, 2017 - 2023

Operating Instructions 2312/19\_EUen\_00810541 / Original DE



# Valve island AirLINE Type 8652

## **CONTENTS**

1		RATING INSTRUCTIONS	
	1.1	Symbols	
	1.2	Definition of terms	
2	INTE	NDED USE	8
3	BASI	C SAFETY INSTRUCTIONS	9
4	GENE	ERAL NOTES	.11
	4.1	Contact address	.11
	4.2	Warranty	
	4.3	Information on the Internet	
5	PROI	DUCT DESCRIPTION	
	5.1	Product structure	
	5.2	External safety-related shutdown of valves	
6		INICAL DATA	
	6.1	Standards and directives	_
	6.2 6.3	Operating conditions  Pneumatic data	
	6.4	General electrical data	
	6.5	Electrical data of electronic module with digital inputs	
	6.6	Pneumatic slide valve type 6534	
	6.7	Circuit function (CF)	
	6.8	Standard type label (example)	
	6.9	Type label UL (example)	
	6.10 6.11	Industrial Ethernet specifications	
	-	CC-Link specifications	
7		ALLATION OF THE VALVE ISLAND IN THE CONTROL CABINET	
•	7.1	Installation on the control cabinet floor or the control cabinet wall with AirLINE Quick	
	7.2	Standard rail installation	
8	ELEC	TRICAL CONNECTION	.33
	8.1	Cabling of büS networks	.33
	8.2	Fieldbus gateway ME43	
	8.3	24 V supply voltage for pneumatic valves	
	8.4	Electronic module with digital inputs  Electrical connection assignment	
	8.5 8.6	Valves type 6534 for safety-related shutdown, variant SIA	
	8.7	Modular safety-related shutdown	
9	PNFI	JMATIC CONNECTION	
	9.1	Assignment of the pneumatic ports	
	9.2	Pneumatic connection assignment	
10	INTE	GRATION INTO THE CONTROL ENVIRONMENT	.47
	10.1	Start-up files and description of the process data and parameters	
	10.2	PLC compatibility	
	10.3	Commissioning a PROFINET device with Siemens TIA Portal	
	10.4	Commissioning a PROFIBUS DPV1 device with Siemens TIA Portal	
	10.5	Commissioning an EtherNet/IP device with Rockwell Logix Designer	. ၁၁



	10.6 Bit-wise composition of the inputs and outputs	
11	CONFIGURATION WITH WEB SERVER	
••	11.1 Establishing a connection to the web server	
	11.2 Logging onto the web server	
	11.3 Passwords	60
	11.4 Finding the device	
	11.5 Disabling web server access with Bürkert Communicator	
	11.6 Information in the web server	
	11.7 Setting options in the web server	
	11.8 Industrial communication of web server	
12	CONFIGURATION WITH FIELDBUS GATEWAY	
	12.1 Operating the fieldbus gateway	
	12.2 Selecting the protocol	
	12.4 Converting compatibility mode	
	12.5 Valve configuration	
	12.6 Configure pressure sensor(s)	
	12.7 Display: contrast, brightness, installation position, language	65
	12.8 Configuration provider	
	12.9 Error diagnostics	
	12.10 Restarting the valve island	
	12.11 Factory reset	
	12.12 Reset the switching cycle counters	
13	MENU STRUCTURE FIELDBUS GATEWAY	
14	FIELDBUS GATEWAY DISPLAY ELEMENTS14.1 LEDs for indicating the network connection to Industrial Ethernet	
	14.1 LEDs for indicating the network connection to industrial Ethernet	
15	BÜRKERT COMMUNICATOR BASICS	
	15.1 User levels	
	•	
16	CONFIGURATION WITH BÜRKERT COMMUNICATOR	
	16.1 Base valve island settings	
	16.3 Base settings CANopen/büS	
	16.4 Active pressure sensor	
	16.5 Disable or enable module supply monitoring	
	16.6 Change "error" report status	
	16.7 Reset device to factory settings	
	16.8 Restart device	
	16.9 Switch time monitoring of actuators	
	16.10 Disabling access to web server	
	16.11 Using Extension Modules (EM)	
17	BÜRKERT COMMUNICATOR MENU STRUCTURE	
18	START-UP	
	18.1 Safety instructions	
	18.2 Commissioning via manual override	85



	18.3 Identification of the valve positions	86
19	DISPLAYS	87
	Valve status display on fieldbus gateway	
20	COMBINE VALVE ISLAND WITH EXTERNAL DI MODULES	
	20.1 Assign position feedback sensor source in the automation software	
	<ul><li>20.2 Assign position feedback sensor source in Bürkert Communicator</li><li>20.3 Network configuration in the Bürkert Communicator</li></ul>	
	20.4 Show errors from büS partners on the display	
	20.5 Configure external DI modules using a wizard	
21	SWITCH TIME MONITORING FUNCTION	97
	21.1 What exactly is being measured?	
	21.2 Settings for the actuator switching time	
	21.3 Start switching time measurement	
	21.4 Error messages for the function of the switching time monitoring	99
22	MICRO SD CARD	100
23	BACKUP BATTERY	102
24	REPLACING SPARE PARTS	103
	24.1 Connection module with compressed air supply	
	24.2 Connection module with pressure sensor	
	24.3 Electronic module	
	24.4 Pneumatic valves	
25	REPLACE THE ME43 FIELDBUS GATEWAY	112
26	MAINTENANCE, TROUBLESHOOTING	
	26.1 Safety instructions	
	26.2 Replace filter for auxiliary pilot air	
	26.3 Troubleshooting	
	26.4 Error messages on the LC display of the electronic modules	
~7	•	
27	DISASSEMBLY	
	•	
28	ACCESSORIES	
29	PACKAGING AND TRANSPORT	
30	STORAGE	124
31	ENVIRONMENTALLY FRIENDLY DISPOSAL	124



#### 1 OPERATING INSTRUCTIONS

The operating instructions describe the entire life cycle of the device.

→ Keep these instructions ready to hand at the operation site.

#### Important safety information!

- ► Carefully read these instructions.
- ▶ Observe in particular the safety instructions, intended use and operating conditions.
- ▶ Persons who work on the device must read and understand these instructions.

#### 1.1 Symbols



#### **DANGER**

Warns of an immediate danger.

► Failure to observe will result in death or serious injuries.



#### WARNING

Warns of a potentially hazardous situation.

► Failure to observe these instructions may result in serious injuries or death.



#### **CAUTION**

Warns of a potential danger.

► Failure to observe may result in moderate or minor injuries.

#### **CAUTION**

Warns of damage.

► Failure to observe may result in damage to the device or the system.



Indicates important additional information, tips and recommendations.



Refers to information in these operating instructions or in other documentation.

- Designates instructions to avoid danger.
- → Designates a procedure which you must carry out.
- Designates a result.

MENU Symbol for software interface texts.



## 1.2 Definition of terms

Term	In these instructions stands for
Actuator, process valve	Pneumatic consumer controlled by the valve island
büS	Bürkert system bus; a communication bus developed by Bürkert, based on the CANopen protocol
EVS	External valve voltage shut-off
	Valves can be de-energised irrespective of the control signals from the bus master. This safety shutdown can be applied to individual valves, valve units or the entire valve block.
Device, valve island	Valve island AirLINE Type 8652
SIA variant	Variant for safety-related shut-off (see "EVS")
Pneumatic valve, pilot valve	Pneumatic slide valve that can be integrated into the valve block



Information on cabling büS networks can be found in the " *Cabling Guide for büS / EDIP* ". You can find the " *Cabling Guide for büS / EDIP* " in the "Operating Instructions" area for type 8652 on the Bürkert homepage country.burkert.com.



#### 2 INTENDED USE

The AirLINE type 8652 valve island is designed to control and record the switching states of pneumatically operated process valves.

- ▶ Use the device only as intended. Non-intended use of the device may be dangerous to people, nearby equipment and the environment.
- ▶ In the potentially explosive atmosphere, only use devices that are approved for this purpose. These devices are identified by a separate "Ex" type label. When used in potentially explosive atmospheres, always observe the details on the separate Ex type label and the supplementary Ex instructions included in the scope of delivery.
- ▶ Prerequisites for safe and trouble-free operation are correct transportation, correct storage, installation, start-up, operation and maintenance.
- ▶ To use the device, observe the permitted data, operating conditions and application conditions. These specifications can be found in the contract documents, the operating instructions and on the type label.
- ▶ Use the device only in conjunction with third-party devices and components recommended or approved by Bürkert.
- ▶ In the outdoor area, make sure that the device is installed in a control cabinet with at least a degree of protection IP 65.
- ▶ In the interior, ensure that the device is installed in a control cabinet with at least a degree of protection IP 20.
- ▶ Do not place the device under mechanical stress, e.g. by placing objects on it or standing on it.
- ▶ Use the device only when it is in perfect condition.



The valve island is intended exclusively for use in the industrial sector.

The valve island is only permitted in applications where there is a danger to life and limb if the SIA and EVS functions provided for this purpose are used with appropriate, approved equipment (safety relays, etc.).



#### 3 BASIC SAFETY INSTRUCTIONS

These safety instructions do not take into account any unforeseen circumstances or events that occur during installation, operation and maintenance. The operator is responsible for observing the location-specific safety regulations, also with reference to personnel.



Risk of injury from high pressure and uncontrolled movement of the actuators.

- ► Secure the actuators against shifting before working on the device or plant.
- ► Switch off the pressure before working on the device or plant. Vent or empty the lines.

#### Risk of injury from electric shock.

- ▶ Switch off the power supply before working on the device or system. Secure it against reactivation.
- ► Observe any applicable accident prevention and safety regulations for electrical devices.

#### Risk of burns from hot device parts.

► Keep the device away from highly flammable substances and media.

#### Risk of injury due to improper installation, maintenance or operation.

- ▶ Only trained technicians may perform installation and maintenance work.
- ▶ Only trained personnel may operate the device.
- ▶ Perform installation work and maintenance work using suitable tools only.

#### Risk of injury due to unintentional activation of the device and system and uncontrolled restart.

- ▶ Secure the device and system against unintentional activation.
- ▶ Ensure that the system starts up in a controlled manner only.

#### Risk of injury due to heavy device.

During transportation or installation work, a heavy device may fall down and cause injuries.

- ► Heavy equipment must only be transported, assembled and disassembled with the help of a second person.
- ▶ Use suitable tools.

#### General hazardous situations.

To prevent injuries, observe the following:

- Install the device according to the regulations applicable in the respective country.
- ▶ Do not feed any aggressive or combustible media into the media connections of the device.
- ▶ Do not feed any liquids into the device's media connections.
- ► Following interruption of the process, ensure that the process is restarted in a controlled manner. Observe the sequence:
  - 1. Apply electrical supply.
  - 2. Apply pneumatic supply (in case of external pressure supply, first the external auxiliary pilot air [X / 12/14], then the medium pressure [P / 1]).
- ▶ Do not modify the device.
- ▶ Do not mechanically load the device.
- ▶ Observe the general rules of technical equipment.



#### **CAUTION**

Electrostatically sensitive components and assemblies.

The device contains electronic components that are susceptible to the effects of electrostatic discharging (ESD). Components that come into contact with electrostatically charged persons or objects are at risk. In the worst case scenario, these components will be destroyed immediately or fail after start-up.

- ▶ Meet the requirements specified by EN 61340-5-1 to minimise or avoid the possibility of damage caused by a sudden electrostatic discharge.
- ▶ Do not touch electronic components when the supply voltage is connected.



#### 4 GENERAL NOTES

#### 4.1 Contact address

#### Germany

Bürkert Fluid Control Systems Sales Centre Christian-Bürkert-Straße 13–17 D-74653 Ingelfingen Tel. +49 (0) 7940 - 10 91 111 Fax +49 (0) 7940 - 10 91 448 Email: info@burkert.com

#### International

The contact addresses can be found on the back pages of the printed Quickstart.

They are also available online at: country.burkert.com

#### 4.2 Warranty

A precondition for the warranty is that the device is used as intended in consideration of the specified operating conditions.

#### 4.3 Information on the Internet

Operating instructions and data sheets for the Bürkert products can be found on the Internet at:

country.burkert.com



#### 5 PRODUCT DESCRIPTION

Thanks to its compact and modular structure with regard to pneumatic and electrical interfaces, the AirLINE type 8652 valve island is suitable for solving diverse and complex control tasks.

The structure of the valve island is optimised for use in control cabinets. The AirLINE Quick adapter plate is already part of the valve island in the basic configuration (Basic variant). With AirLINE Quick, the valve island can be placed on an opening in the control cabinet floor or the control cabinet wall. Alternatively, it can also be installed on the rear wall of the control cabinet using a standard rail.

In the maximum expansion stage, the valve island enables the use of up to 48 valve functions. A clear operating concept and a clear display concept help with installation and maintenance work. The supply manifold is made of aluminium and provides the necessary stability. Both the fluidic elements such as pneumatic slide valves and the electronic modules are attached to it.

Electrical connection occurs via the ME43 fieldbus gateway, thereby allowing the use of a wide range of fieldbus protocols.




Figure 1: Maximum extension of valve island Type 8652: 6 valve units with a maximum of 8 valve functions per unit



#### Basic variant




Figure 2: Example of a valve island type 8652 Basic variant

The Basic variant is the basic version of the modular valve island. This variant is designed for standard control and automation technology tasks. The Basic variant has no electronic modules and no digital inputs.



#### 5.1 Product structure




Figure 3: Structure of the valve island type 8652

#### 5.1.1 Fieldbus gateway ME43

Electrical connection occurs via ME43 fieldbus gateway, thereby allowing the use of a wide range of fieldbus protocols. The gateway serves as a fieldbus converter between büS / CANopen and Industrial Ethernet, PROFIBUS DPV1 or CC-Link.

#### 5.1.2 Interface board




Figure 4: Connections for EVS on the interface board

The interface board has a 2-pole spring-loaded terminal to which the supply voltage for the pneumatic slide valves is connected. This allows the voltage for all pneumatic slide valves of the valve island to be shut down irrespective of the communication to the superordinate controller (PLC). If the voltage is shut down or interrupted, the message "EVS active" appears on all valve island displays.



#### Interface board with module-based shutdown

The 12-pole spring-loaded terminal is bridged upon delivery. If the bridge is removed, module-based safety shutdown can be performed by means of a connection to a safety relay. All 4 valve slots of a valve unit (see "Figure 1" on page 12) can therefore be shut down without impacting on further functions of the valve island. If the voltage is shut down or interrupted, the message "EVS active" appears on the display of the respective valve unit.

#### 5.1.3 Connection module

The connection module is used to internally distribute the pilot pressure to the pilot valves. The position of a seal in the connection module can be used to switch to internal or external pilot pressure supply.

#### Connection module with compressed air supply

Connection modules with a compressed air supply enable the additional compressed air supply of medium pressure and pilot pressure.

#### Connection module with compressed air supply and integrated pressure sensor

This variant of the connection module is equipped with an integrated pressure sensor. The pressure sensor monitors the medium pressure of the unit and reports the current pressure to the controller. The current medium pressure can be indicated on the valve unit displays.

Minimum values and maximum values for the issuance of warning and error alerts can be specified with the web server (for PROFINET, EtherNet/IP or Modbus TCP) or the software Bürkert Communicator.

#### 5.1.4 Protection cover

In the Basic variant, the protective cover replaces the electronic modules. Protective covers are without display and without digital inputs. They protect the electrical contacts of the backplane from dirt and damage.

#### 5.1.5 Electronic module

The electronics module shows the status of the valves on an LC display.

#### Electronic module with digital inputs

The digital inputs are used to supply electrical power to the position feedback sensors. The position feedback sensors can be used to show error messages, maintenance intervals or other information on the device status on the LC display of the electronics module.

Standard position feedback sensors (3-wire sensors and 2-wire sensors as well as mechanical limit switches) can be connected to the digital inputs.

Depending on the position feedback sensor used, the following data can be output:

Possible data	3-wire sensors	2-wire sensors	Mech. Limit switches
Position feedback sensor activated	Х	Х	Х
Position feedback sensor not activated	X	X	Х
Short circuit	X	_	_
Wire break	_	X	_

#### Examples of usable position feedback sensors

3-wire sensors: 2-wire sensors: Mechanical limit switch:

Bürkert type 8697 (3-wire) Bürkert type 8697 (c-wire) Bürkert type 8697 (micro switch)



#### 5.1.6 Pneumatic slide valves type 6534

The functioning of the pneumatic slide valves is based on a soft-sealing slide principle. The individual technical values and the various circuit functions of the pneumatic slide valves are described on the data sheet for the valve island type 8652 (see <a href="mailto:country.burkert.com">country.burkert.com</a>).

Pneumatic slide valves type 6534 are equipped with manual override. The manual override works without voltage being applied to the valve island and allows manual valve switching (see chapter "18.2").

The standard manual override is spring return and latching. By using the additional element "Manual override locking", the function of the manual override is restricted (purely tentative or blocked).

SIA variant (for safety-related shutdown)

Valves Type 6534 "SIA variant" are equipped with additional connection terminals. The circuit of a valve can therefore be interrupted by an external switch. Manual override is not required for these valve variants.

#### 5.1.7 Supply manifold

The supply manifold is used for the pneumatic supply of the individual valves. The supply manifold is available with and without check valves. By using P shutoff (hot swap), individual valves can be exchanged during operation. The check valves in the ventilation ducts prevent the actuators from being switched unintentionally (e.g. due to uncontrolled pressure peaks).

The supply manifold is designed so that the valve island can be used on the standard rail or directly on the control cabinet floor or the control cabinet wall as AirLINE Quick.

#### 5.1.8 Adapter plate AirLINE Quick

The adapter plate AirLINE Quick in stainless steel enables, for example, the use of the valve island in hygienic applications without great installation effort. The adapter plate allows simple and safe installation in the control cabinet floor or the control cabinet wall.

When the valve island is installed correctly in the control cabinet base or control cabinet wall as specified in chapter <u>"7.1" on page 28</u>, degree of protection IP65 is achieved at the interface between adapter plate AirLINE Quick and the control cabinet.

#### 5.1.9 Terminating resistor

When delivered, each valve island type 8652 contains 1 terminating resistor (see <u>"Figure 3"</u>). If several valve islands are connected in a line, only the last device within this line may contain a terminating resistor. The terminating resistors of the other devices must be removed by pulling them off to the right of the device.



#### 5.2 External safety-related shutdown of valves

There are several ways to de-energise valves irrespective of the control signals from the bus master.

#### · Single valves only

Pneumatic slide valves Type 6534 "SIA variant" are equipped with additional connection terminals. The circuit of a valve can therefore be interrupted by an external switch. An external shutdown of the valves is not shown on the associated display. Shutdown takes place via the connection terminal of the valve regardless of the state of the valve island.

#### · All the valves of a valve unit (module-based safety shutdown):

If the interface board is additionally equipped with a 12-pole spring-loaded terminal, module-based safety shutdown is possible.

The spring-loaded terminal is bridged upon delivery. If the bridge is removed, all 4 valve slots of a valve unit can be shut down by means of a connection to a safety relay without impacting on further functions of the valve island.

If a valve unit is shut down, the message "EVS active" appears on the display of the valve unit.

#### All valves of the valve block:

By shutting down the supply voltage of the valve block (via the 2-pole spring-loaded terminal), all valves are immediately de-energised (the energy contained in the energy packs of the valve block is negligible). The message "EVS active" is displayed on all displays of the valve island.

The latter two options have the advantage that the logic, display and diagnostics continue unaffected, thus remaining available.



## 6 TECHNICAL DATA

#### 6.1 Standards and directives

The device complies with the relevant EU harmonisation legislation. In addition, the device also complies with the requirements of the laws of the United Kingdom.

The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity/UK Declaration of Conformity.

## 6.2 Operating conditions

Ambient temperature	−10+55 °C
Storage temperature	−10+60 °C
Altitude	For UL approved versions limited to max. 2000 m above sea level
Degree of protection	IP20

#### 6.3 Pneumatic data

Control medium	Compressed air quality ISO 8573-1: 2010, class 7.4.4
Pressure range	See chapter <u>"6.6"</u>
Connections:	
Pressure port (P/1)	Plug-in coupling Ø 10 mm or Ø D3/8
Exhaust ports (S / 3, R / 5)	
Pressure port auxiliary pilot air (X / 12/14) <sup>1</sup>	
Exhaust port auxiliary pilot air (R' / 82/84) <sup>1</sup>	Plug-in coupling Ø 6 mm or Ø D1/4
Working ports	

<sup>1)</sup> With the Basic variant, the equipment of the connections for auxiliary pilot air (X / 12/14 and R' / 82/84) can vary.



#### General electrical data 6.4

#### **CAUTION**

▶ Use safety extra-low voltage according to protection class III EN 61140, VDE 0140.

Nominal operating mode	Continuou	Continuous operation (100% duty cycle)		
Operating voltage	24 V== ± 10%, residual ripple with fieldbus interface max. 1 Vss²			
Current consumption	The currer	nt consumption depends	on the configuration of the valve island.	
	The total current for the fieldbus interface is calculated according to the formula: $I_{tot} = I_{basic} + (n \times I_{valve}) + (m \times I_{feedback}) + (k \times I_{electr. mod.})$			
	I tot:	Total current		
	I basic:	Basic current depending	g on the fieldbus system	
		PROFINET IO:	135 mA	
		EtherNet/IP:	135 mA	
		Modbus TCP:	135 mA	
		EtherCat:	135 mA	
		CC-Link IE Field Basic:	135 mA	
		PROFIBUS DPV1:	120 mA	
		BüS /CANopen:	70 mA	
		CC-Link:	120 mA	
	n:	Number of valves (max 2-way)	. 48 when using 24 double valves 2x3 /	
	I <sub>Valve</sub>	Nominal current of the	valve (30 mA)	
	m:	Number of position fee	dback sensors (max. 48)3	
I feedback: Current consumption of		f position feedback sensor (max. 30 mA)		
	k:	Number of electronic r	modules (Max. 6) <sup>3</sup>	
	l electr.	Current consumption o	f electronic modules ((21 mA)	

<sup>2)</sup> UL approved versions must be supplied in one of the following ways:

a. "Limited Energy Circuit" (LEC), according to UL / IEC61010-1b. "Limited Power Source" (LPS), according to UL / IEC60950

c. SELV / PELV with UL-approved overcurrent protection, designed according to UL / IEC61010-1, Table 18

d. NEC Class 2 power supply unit

<sup>3)</sup> Basic variant: Electronic modules and digital inputs are not included in the scope of delivery. When calculating the total current, enter the value "0" for the variables "m" and "k"



# 6.5 Electrical data of electronic module with digital inputs

Module properties				
Diagnostics	Wire break detection for 2-wire sensors			
	Short circuit detection for 3-wire sensors			
Safety	Protection against overvoltage			
Electrical data				
Electrical connection (position feedback	2-wire sensors			
sensor)	3-wire sensors			
	Mechanical limit switches			
Input type	Type 1 and type 3 according to IEC 61132-2			
Conductor cross-section	≤ 1.5 mm <sup>2</sup>			
Max. Cable length	<30 m			
Sensor supply (position feedback sensor)				
Current consumption	8 x max. 30 mA			
Voltage	24 V ± 10 %			
Input current for V <sub>ON</sub> = type 24 V DC	Type 5.8 mA			
Input impedance	> 3 kΩ			
Switching threshold	V <sub>OFF</sub> = 05 V			
	V <sub>ON</sub> = 1030 V			
Electrical isolation	No			



## 6.6 Pneumatic slide valve type 6534

Circuit function (CF)	2 x CFC <sup>4</sup> NC (normally closed) 2 x 3/2-way	CF H <sup>4</sup> 5/2-way monostable CFZ	CFL <sup>4</sup> 5/3-way blocked CFM	
	2 x CFD		5/3-way pressurised	
	NO (normally open) 2 x 3/2-way	5/2-way bistable	CFN 5/3-way vented	
Flow rate Q <sub>Nn</sub> up to 310 I <sub>N</sub> / min (for exact flow values for the different circuit functions, see data sheet)			, see data sheet)	
Medium pressure⁵	0 10 bar			
Control pressure <sup>6</sup>	3 10 bar			
Electr. Power before / after power reduction	2 x 0.7 W / 2 x 0.175 W	0.7 W/0.175 W	0.7 W/0.175 W	
Current before / after power reduction	2 x 29 mA / 2 x ≤ 10 mA	29 mA / ≤ 10 mA		

- 4) Also available as the SIA variant (see chapter "8.6" on page 40)
- For pressure values from vacuum to 3 bar, observe the pilot pressure diagram and set the supply of auxiliary pilot air to "external" (take chapter <u>"9.1.1 External and internal auxiliary pilot air" on page 45</u> into consideration here).
- 6) For the "External auxiliary pilot air" variant, select the pilot pressure according to the pilot pressure diagram.

## 6.6.1 Control pressure diagram




Figure 5: Control pressure diagram for pneumatic slide valve type 6534



# 6.7 Circuit function (CF)

Circuit function (CF)	Symbol according to ISO 1219-1	Description
2 x CFC <sup>7</sup>	12 14 14 15	Outlet 2 and outlet 4 vented when idle.
2 x CFD	12 14 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Outlet 2 and outlet 4 aerated when idle.
CF H <sup>7</sup>	14 T T W 12	Pressure port 1 connected to outlet 2 when idle, outlet 4 vented.
CFZ		5/2-way valve bistable; Depending on the switch position, either output 2 is vented and output 4 is vented or output 2 is vented and output 4 is aerated.
		For CFZ *:
CFZ *	14 12 112 5   1   3	With regard to valves with circuit function Z*, the valve island software ensures that the newly installed valve adopts the switch setting of the original valve in the event that a valve is replaced (hot swap).
		For valves with circuit function Z*, manual override is disabled after the first electrical activation.
CFL <sup>7</sup>	14 PM T 12 12 5 113	All connections blocked in the idle position.
CFM	14 PM T T V T T T V T T T V T T V T T T V T T T V T T T V T T T V T	In the idle position, output 2 and output 4 are pressurised.
CFN	14 PW T V V V T V V V T V V V T V V V T V V V T V V T V V V T V V V V T V V V T V V V V V T V	Outlet 2 and outlet 4 vented when idle.

<sup>7)</sup> Type 6534 variant SIA (variant for safety-related shutdown) The type 6534 valves can optionally be equipped with a second electrical connection (connection terminal). Safety-related shut-off is therefore possible for each channel individually. The valve variants are without manual override. See also chapter "8.6" on page 40



## 6.8 Standard type label (example)




Figure 6: Type label standard valve island type 8652

## 6.9 Type label UL (example)




Figure 7: Type label UL valve island type 8652



## 6.10 Industrial Ethernet specifications

#### 6.10.1 PROFINET IO

Topology recognition	LLDP, SNMP V1, MIB2, Physical Device
Minimum cycle time	10 ms
IRT	not supported
MRP media redundancy	MRP client is supported
Other supported functions	DCP, VLAN Priority Tagging, Shared Device
Transmission speed	100 Mbit/s
Data transport layer	Ethernet II, IEEE 802.3
PROFINET IO specification	V2.42
Application Relations (AR)	The device can simultaneously process up to 2 IO ARs, 1 Supervisor AR, and 1 Supervisor DA AR.

#### 6.10.2 EtherNet/IP

Pre-defined standard objects	Identity Object (0x01)	
	Message Router Object (0x02)	
	Assembly Object (0x04)	
	Connection Manager (0x06)	
	DLR Object (0x47)	
	QoS Object (0x48)	
	TCP/IP Interface Object (0xF5)	
	Ethernet Link Object (0xF6)	
DHCP	supported	
ВООТР	supported	
Transmission speed	10 and 100 MBit/s	
Duplex modes	Half duplex, full duplex, auto-negotiation	
MDI modes	MDI, MDI-X, Auto-MDI-X	
Data transport layer	Ethernet II, IEEE 802.3	
Address Conflict Detection (ACD)	supported	
DLR (ring topology)	supported	
CIP reset service	Identity Object Reset Service Type 0 and Type 1	



#### 6.10.3 Modbus TCP

Modbus function codes	1, 3, 6, 15, 16
Transmission speed	10 and 100 MBit/s
Data transport layer	Ethernet II, IEEE 802.3

#### 6.10.4 EtherCAT



Ethernet interface X1, X2	X1: EtherCAT IN	
	X2: EtherCAT OUT	
Acyclic communication (CoE)	SDO	
Туре	Complex Slave	
FMMUs	8	
Sync Managers	4	
Transmission speed	100 Mbit/s	
Data transport layer	Ethernet II, IEEE 802.3	

EtherCAT ® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

#### 6.10.5 CC-Link IE field basic

Number of occupied stations	116	
Acyclic communication	SLMP Server	
Data transport layer	Ethernet II, IEEE 802.3, 100 MBit/s	
CC-Link interface	Cyclic data 61450 (UDP)	
	Discovery and SLMP Server 61451 (UDP)	
	SLMP Communication 20000 (UDP)	

## 6.11 Specifications PROFIBUS DPV1

Acyclic communication	DPV1 Class 1 Read/Write	
	DPV1 Class 2 Read / Write / Data Transport	
Transmission speed	fixed values from 9.6 kbit / s to 12 Mbit / s	
	Autodetect mode is supported	



# 6.12 CC-Link specifications

CC-Link version 2.0	
Number of stations	Up to 4 occupied stations
Extended cycles	1
Input data	32 bytes (RWw)
Output data	32 bytes (RWr)
Transmission speeds	156 kbit / s, 625 kbit / s, 2500 kbit / s, 5 Mbit / s, 10 Mbit / s
CC-Link version 1.1	
Number of stations	Up to 4 occupied stations
Input data	8 bytes (RWw) per occupied station
Output data	8 bytes (RWr) per occupied station
Transmission speeds	156 kbit / s, 625 kbit / s, 2500 kbit / s, 5 Mbit / s, 10 Mbit / s



# 7 INSTALLATION OF THE VALVE ISLAND IN THE CONTROL CABINET



#### **WARNING**

Risk of injury due to improper installation.

- ▶ Only trained technicians may perform installation work.
- ▶ Perform installation work using suitable tools only.



#### **CAUTION**

Risk of injury due to heavy device.

During transportation or installation work, a heavy device may fall down and cause injuries.

- ► Heavy equipment must only be transported, assembled and disassembled with the help of a second person.
- ▶ Use suitable tools.



The AirLINE type 8652 valve island is supplied as a fully assembled device. Modifications are only permitted to be carried out by Bürkert.

The valves are excluded from this and may be exchanged by the user for valves of the same variant.

There are 2 options for placing the valve island in the control cabinet:

#### 1. On the control cabinet floor or the control cabinet wall with AirLINE Quick

The AirLINE Quick adapter plate is a standard part of the valve island. The AirLINE Quick adapter plate enables the valve island to be positioned on a cutout on the control cabinet floor or on the control cabinet wall. This means that the pneumatic connection of the valve island can be made outside the control cabinet.

When the valve island is installed correctly in the control cabinet base or control cabinet wall as specified in chapter <u>"7.1" on page 28</u>, degree of protection IP65 is achieved at the interface between adapter plate AirLINE Quick and the control cabinet.

#### 2. On the rear wall of the control cabinet with a standard rail

The valve island is mounted on the rear wall of the control cabinet using a standard rail.




Figure 8: Options for placing the valve island in the control cabinet



# 7.1 Installation on the control cabinet floor or the control cabinet wall with AirLINE Quick



#### **WARNING**

Danger due to electromagnetic disruptions.

If the functional earth (FE) is not connected, then the requirements of the EMC protection are not met and malfunctions may occur on the unit.

- ► Connect the control cabinet housing to the functional earth (FE) using a **short** cable with a **large** cross-section.
- ► Only use shielded cables.

For installation with AirLINE Quick, a cutout must first be provided on the control cabinet floor or the control cabinet wall and holes for the fastening screws. The recess can be done with a laser or a punch (see <u>"7.1.1</u> <u>Dimensions of the flange pattern AirLINE Quick"</u>).

#### **CAUTION**

The recess on the control cabinet must be burr-free so that the seal between the AirLINE Quick and the control cabinet is not damaged.

#### When measuring the excavation, note:

To be able to use the Hot-Swap function (valve replacement during operation), there must be a minimum distance from the front edge of the control cabinet when installing the valve island in the control cabinet (see <u>"Figure 10"</u>). The valves can only be pulled out of the valve island to the front if the minimum distance is observed.




Figure 9: Make the cut-out in the control cabinet floor close to the rear wall of the control cabinet.

The minimum distances to the left, right, front and top depend on the position of the valve island in the control cabinet:

Position in the control cabinet	front	left	right	Тор	Bottom
Installation on the control cabinet floor	60.5 mm	30 mm	50 mm	50 mm	_
Installation on the right of the control cabinet wall	60.5 mm	50 mm	_	50 mm	30 mm
Installation on the control cabinet wall on the left	60.5 mm	_	50 mm	30 mm	50 mm

Table 1: The minimum distances refer from the outer edge of the valve island to the inner edge of the control cabinet






Figure 10: To be able to use the Hot-Swap function, there must be a minimum distance from the front edge of the control cabinet when installing the valve island in the control cabinet.

### 7.1.1 Dimensions of the flange pattern AirLINE Quick




Figure 11: Flange pattern AirLINE Quick - for dimensions, see table 2



Number of valves	M [mm]	N1 [mm]	N2 [mm]	Number of holes
4	85.8 ±0.3	66 ±0.3	_	4
8	129.8 ±0.4	37 ±0.3	111 ±0.4	8
12	173.8 ±0.4	77 ±0.3	154 ±0.4	10
16	244 ±0.4	112 ±0.3	224 ±0.4	10
20	288 ±0.4	134 ±0.3	268 ±0.4	10
24	332.1 ±0.4	156 ±0.3	312 ±0.4	10

Table 2: Dimensions of the flange pattern AirLINE Quick

#### 7.1.2 Install the valve island in the control cabinet

- → Check whether the seal between the AirLINE Quick and the control cabinet is free of damage.
- ightarrow Place the valve island in the control cabinet in the prepared recess.
- $\rightarrow$  Fasten from the outside with M5x10 screws (tightening torque 2.5 Nm).



#### 7.2 Standard rail installation



#### **WARNING**

Danger due to electromagnetic disruptions.

If the functional earth (FE) is not connected, then the requirements of the EMC protection are not met and malfunctions may occur on the unit.

- ► Connect the standard rail to the functional earth (FE) using a short cable with a large cross-section or a copper tape.
- ► Only use shielded cables.



The valve island must be freely accessible from above. Ensure good heat dissipation.




Figure 12: Recommended minimum clearances when installing on a standard rail in the control cabinet

#### Recommended minimum distances [mm]

	Α	В	С	D
Standard	50	30	30	50
Basic variant8	80			

- → Install the standard rail firmly in the control cabinet.
- → Establish a short, wide PE connection between the standard rail and the control cabinet.
- → Hook the valve island onto the upper guide of the standard rail.
- $\rightarrow$  Fasten the valve island to the standard rail with the two fastening screws (tightening torque 1.5 Nm).






Figure 13: Fastening screws for valve island on standard rail



#### **ELECTRICAL CONNECTION** 8



#### **CAUTION**

Risk of injury from electric shock.

- ► Switch off the power supply before working on the device or system. Secure against reactivation.
- Observe any applicable accident prevention and safety regulations for electrical devices.

Risk of injury if the electrical connection is incorrect.

- ▶ Only trained specialists are allowed to make the electrical connection.
- ▶ Make the electrical connection only with a suitable tool.

#### 8.1 Cabling of büS networks



Information on cabling büS networks can be found in the " Cabling Guide for büS / EDIP ". You will find the "Cabling Guide for büS / EDIP" in the "Operating Instructions" area for type 8652 on the Bürkert homepage country.burkert.com.

#### 8.2 Fieldbus gateway ME43

#### 8.2.1 Gateway with CANopen / büS interface

→ Connect 5-pin spring-loaded terminal according to the assignment. Possible cable cross-section: ≤ 1.5 mm<sup>2</sup> (see also Chapter<u>"28 Accessories"</u>)

Assignment 5-pin spring-loaded terminal			
Plug view	Terminal colour	Description	
24V H Shield L GND	Red	Supply voltage 24 V ===	
	White	CAN_H (büS connection)	
	Green	Shielding	
	Blue	CAN_L (büS connection)	
	Black	GND	

Table 3: Assignment 5-pin spring-loaded terminal



#### 8.2.2 Gateway with Industrial Ethernet interface

The following protocols are supported:

- EtherCAT
- EtherNet/IP
- · Modbus TCP
- PROFINET
- · CC-Link IE field basic
- → Connect 5-pin spring-loaded terminal according to the assignment. Possible cable cross-section: ≤ 1.5 mm<sup>2</sup> (see also Chapter<u>"28 Accessories"</u>)
- → Plug the Ethernet cables into the sockets of interfaces X1 and X2. The interfaces X1 and X2 for RJ45 push-in connectors are equivalent.

Assignment 5-pin spring-loaded terminal			
Plug view	Terminal colour	Description	
24V H Shield L GND	Red	Supply voltage 24 V ===	
	White	CAN_H (büS connection) <sup>8</sup>	
	Green	Shielding	
	Blue	CAN_L (büS connection) <sup>8</sup>	
	Black	GND	

Table 4: Assignment 5-pin spring-loaded terminal




Figure 14: Allocation of interfaces X1 (EtherCAT IN) and X2 (EtherCAT OUT); Connection to the fieldbus



#### 8.2.3 Gateway with PROFIBUS DPV1 interface

- → Connect 5-pin spring-loaded terminal according to the assignment.
  Possible cable cross-section: ≤ 1.5 mm<sup>2</sup> (see also Chapter<u>"28 Accessories")</u>
- ightarrow Connection of a 9-pin D-Sub plug to the PROFIBUS DPV1 interface according to the assignment.

Assignment 5-pin spring-loaded terminal			
Plug view Terminal colo		Description	
24V H Shield L GND	Red	Supply voltage 24 V ===	
	White	CAN_H (büS connection) <sup>9</sup>	
	Green	Shielding	
	Blue	CAN_L (büS connection) <sup>9</sup>	
	Black	GND	

Table 5: Assignment 5-pin spring-loaded terminal

Allocation of push-in connector D-Sub, 9-pin							
D-Sub, 9-pin		Signal	Function	Connection			
6 1 2 3 3 4 9 5 5	1	Not used					
	2	Not used					
	3	RxD/TxD-P	Data line P (B conductor)	Duty			
	4	CNTR-P	Repeater directional control	optional			
	5	DGND	Weight	optional			
	6	VP	+5 V	optional			
	7	Not used					
	8	RxD/TxD-N	Data line N (A conductor)	Duty			
	9	Not used					

Figure 15: PROFIBUS DPV1, assignment of D-Sub 9-pin push-in connector



#### 8.2.4 Gateway with CC-Link interface

- → Connect 5-pin spring-loaded terminal according to the assignment.
  Possible cable cross-section: ≤ 1.5 mm<sup>2</sup> (see also Chapter<u>"28 Accessories"</u>)
- → Connection of a D-sub 9-pin plug to the CC-L ink interface according to the assignment.

Assignment 5-pin spring-loaded terminal							
Plug view	Terminal colour	Description					
24V	Red	Supply voltage 24 V ===					
24V	White	CAN_H (büS connection) <sup>10</sup>					
Shield	Green	Shielding					
L	Blue	CAN_L (büS connection) <sup>10</sup>					
GND GND	Black	GND					

Table 6: Assignment 5-pin spring-loaded terminal

Allocation of push-in connector D-Sub, 9-pin							
D-Sub, 9-pin	Pin	Signal	Function	Connection			
6 1 2 2 3 4 4 9 5 5	1	Not used					
	2	Not used					
	3	DA	Data line A	Duty			
	4	DG	Data ground	Duty			
	5	Not used					
	6	Not used					
	7	Not used					
	8	DB	Data line B	Duty			
	9	Not used					

Figure 16: CC-Link, pin assignment D-Sub 9-pin push-in connector

<sup>10)</sup> Only occupied when using several Bürkert devices (EDIP) or in connection with the communicator.



# 8.3 24 V supply voltage for pneumatic valves

The interface board has a 2-pole spring-loaded terminal to which the supply voltage for the pneumatic valves is connected. This allows the voltage for all pneumatic valves of the valve island to be shut down irrespective of the communication to the superordinate controller (PLC).




Figure 17: Assignment of the 2-pole spring-loaded terminal



# 8.4 Electronic module with digital inputs

- → Switch off the supply voltage.
- → Connect the position feedback sensors to the electronics module according to the assignment. Possible cable cross-section: ≤ 1.5 mm<sup>2</sup> Maximum cable length: <30 m</p>

The electrical supply to the position feedback sensors (24 V) is provided by the electronic module.

→ Limit the current consumption of position feedback sensors to 30 mA!




Figure 18: Assignment of the digital inputs of the electronic module

Standard position feedback sensors (3-wire sensors and 2-wire sensors as well as mechanical limit switches) can be used.

Depending on the position feedback sensor used, the following data can be output:

Possible data	3-wire sensors	2-wire sensors	Mech. Limit switches
Position feedback sensor activated	X	X	Х
Position feedback sensor not activated	Х	Х	Х
Short circuit	X	_	_
Wire break	_	X	ı



# 8.5 Electrical connection assignment

### 8.5.1 Upper end position




Figure 19: Example of upper end positions for a valve unit with 4 2x3 / 2-way valves

#### 8.5.2 Lower end position




Figure 20: Example of lower end positions for a valve unit with 4 2x3 / 2-way valves

# 8.5.3 Changing end positions

Changing end positions only affect the 5/2-way valves, since 8 bits are sufficient for the transmission of all values for the entire valve unit. With the changing end position, the 8 inputs are used alternately for the upper and lower end positions (see "Figure 21").




Figure 21: Example of changing end positions for a valve unit with 4 5/2-way valves



# 8.6 Valves type 6534 for safety-related shutdown, variant SIA



#### **DANGER**

Risk of injury due to unintentional movement of the actuators.

If the shut-off function is required to control safety-critical processes, hazardous movements of the actuators may be triggered when the switch-off function is faulty.

► Make sure the shut-off function is working properly before start-up.



#### **WARNING**

Risk of injury and property damage due to electrical faults.

If the connections for the safety-related shut-off are not connected correctly, there is a risk of injury due to uncontrolled behaviour of the plant.

- ▶ When using several SIA variant valves, connect each connection to an individual potential-free contact (mechanical switch or relay). Never connect several contacts together under any circumstances!
- ▶ Do not apply voltage to the connections (risk of damage to the valves).

#### Risk of injury due to sharp edges.

Sharp edges on the connection or on the contacts of the screw-type terminal can cause cuts.


Wear suitable protective gloves.

Type 6534 valves for safety-related shut-off (SIA variant) are equipped with additional connection terminals. The circuit of a valve can therefore be interrupted by an external switch. Manual override is not required for these valve variants.

The technical data of the Type 6534 SIA variant valves corresponds to the data of the standard device.

To use the shut-off function, connect the connection to a potential-free contact (mechanical switch or relay).

The contact must be in the same control cabinet as the valve island; restrict the maximum cable length to 2 m.



The yellow connection terminals are pluggable and can be removed to facilitate connection of a cable. With the exception of CF H, there are always 2 connection terminals. To avoid confusing the connections, the connection terminals are coded.

On delivery, the connection terminals are provided with a bridge to ensure the valve can be put into operation immediately. Remove the bridge before connecting a cable.



Connection terminals:	Pluggable screw-type terminal, 2-pole, coded wire cross-section (rigid or flexible) 0.14 mm <sup>2</sup> 1.5 mm <sup>2</sup> (AWG 2816)
Labelling connection terminals:	21 → connection terminal 2, pole 1 22 → connection terminal 2, pole 2 41 → connection terminal 4, pole 1 42 → connection terminal 4, pole 2
Required switching capacity of the contact:	0.5 A / 24 V DC




Figure 22: Connection designation and circuit diagram of all circuit functions available as variant SIA except for circuit function H (CF H see "Figure 23")




Figure 23: Connection designation and circuit diagram, variant SIA, circuit function H (CF H)

The labels 2 and 4 refer to the assignment to the respective working port.



# 8.7 Modular safety-related shutdown



#### **DANGER**

Risk of injury due to unintentional movement of the actuators.

If the shutdown function "Module-based safety shutdown" is required to control safety-critical procedures, hazardous movements of the actuators may be triggered if the shutdown function is faulty.

▶ Make sure the shut-off function is working properly before start-up.

In spite of the activated shutdown function, actuators can be moved by manual override of the valves. If the shutdown function is used to control safety-critical procedures:

► Take suitable measures against unintentional actuation of the valves, e.g. by means of a lockable control cabinet or by blocking the manual overrides with the additional element "Locking HB" (see chapter "18.2.1 Additional element "Lock Manual Override" on page 86).



#### **WARNING**

Risk of injury and property damage due to electrical faults.

If the connections for module-based safety shutdown are not connected correctly, there is a risk of injury due to uncontrolled behaviour of the plant.

- ▶ If several valve units are to be shut down in a safe manner, connect each connection to an individual potential-free contact (mechanical switch or relay). Never connect several contacts together under any circumstances!
- ▶ Do not supply voltage to the connections for module-based safety shutdown (risk of damaging the valves).

#### Risk of injury due to sharp edges.

Sharp edges on the connection or on the contacts of the 12-pole spring-loaded terminal can cause cuts.

► Wear suitable protective gloves.



Figure 24: Port for module-based safety shutdown

The interface boards for module-based safety shutdown are additionally equipped with a 12-pole spring-loaded terminal. As a result, the electric circuit of a valve unit (4 pneumatic valves) can be interrupted by an external switch, e.g. to implement functions such as "Central system off" or to deactivate actuators group by group.

The interruption will immediately cause a single-pole interruption of the common supply to all valves of the valve unit (see <u>"Figure 25"</u>).






Figure 25: Schematic representation of a valve unit with shutdown function "Module-based safety shutdown"

To use the shut-off function, connect the connection to a potential-free contact (mechanical switch or relay).

The contact must be in the same control cabinet as the valve island; restrict the maximum cable length to 2 m.

Connection	Pluggable screw-type terminal <sup>11</sup> , 12-pole cable cross-section (rigid or flexible) 0.14 mm <sup>2</sup> 1.5 mm <sup>2</sup> (AWG 2616)
Required switching capacity of the contact	1.5 A / 24 V DC

On delivery, the spring-loaded terminal is provided with a bridge so that the electronic basic module can be put into operation immediately. Remove the bridge before connecting a cable.



#### PNEUMATIC CONNECTION 9

#### **DANGER**

Risk of injury from high pressure.

- ▶ Secure the actuators against shifting before working on the device or plant.
- ▶ Switch off the pressure before working on the device or plant. Vent or empty the lines.

#### Risk of injury if the pneumatic connection is incorrect.

- ▶ Only trained specialists are allowed to make the pneumatic connection.
- ▶ Make the pneumatic connection only with a suitable tool.

### CAUTION

Danger due to loud noises.

► Seal unused connections with sealing plugs (e.g. for 5/2-way valves).



#### Recommendation

- Only use Bürkert sealing plugs (see chapter <u>"28 Accessories" on page 121)</u>. These sealing plugs are tested under laboratory conditions. If plugs from other manufacturers are used, the service life of the device may be limited.
- We recommend the use of original Bürkert accessories only (see chapter <u>"28 Accessories" on</u> page 121).

#### Synthetic hoses for pneumatics

When using hoses from other manufacturers, make sure the hose diameter remains within the tolerance of ± 0.1 mm.

#### 9.1 Assignment of the pneumatic ports




Figure 26: Pneumatic connections valve island

Connection	Assignment	
18	Valve slots	
P/1	Pressure port	
S/3	Expense posts	
R/5	Exhaust ports	
R' / 82/84	Exhaust port for auxiliary pilot air	With the Basic variant, the equipment of the
X / 12/14	Pressure port for auxiliary pilot air	connections for auxiliary pilot air can vary.

Figure 27: Terminal assignment valve island






Figure 28: Pneumatic connections connection module

### 9.1.1 External and internal auxiliary pilot air

The seals of the connection module are already installed in the delivery state. Should it be necessary to change the supply of the auxiliary pilot air, this can be done by turning the seal. It is essential to observe the following note!

#### **NOTE**

Internal short circuit between the auxiliary pilot air and the pilot pressure.

To avoid an internal short circuit, the seals of the connection modules must be positioned the same (external or internal supply of auxiliary pilot air). Mixing the external or internal supply is not permitted.

► Never mix the external or internal supply.



The X port always has to be connected for an external supply.




Figure 29: The valves are set to external or internal supply of auxiliary pilot air by turning (sliding over) the seal by 180°. The type of feed must always be the same within the valve island!



# 9.2 Pneumatic connection assignment

#### Valve unit with 4 double valves

	BM1_Valves						
Bit 0	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5	Bit 6	Bit 7
Valve 1	Valve 2	Valve 3	Valve 4	Valve 5	Valve 6	Valve 7	Valve 8
Pneumatic connection							
2	4	2	4	2	4	2	4

Table 7: Example for the assignment of the bits for double valves

If there are single valves in a valve unit, the next bit is skipped after a single valve (see following example).

#### Valve unit with 2 single valves and 2 double valves

BM1_Valves					
2 single valves		2 double valves			
Bit 0	Bit 2	Bit 4	Bit 5	Bit 6	Bit 7
Valve 1	Valve 3	Valve 5	Valve 6	Valve 7	Valve 8
Pneumatic connection					
4	4	2	4	2	4

Table 8: Example for the assignment of the bits for 2 single valves and 2 double valves

# 9.2.1 Allocation of the valve outputs to the pneumatic connections of the valve island

Valve type	Pneumatic connection		
	Valve outlet	AirLINE Quick	
2x3/2-way	Position of valve outputs	1 2 3 4 5 6 7 8	
5/2-way	2x3/2 + 5/2 + 5/3 way	<b></b>	
5/3-way	Ŏ4————————————————————————————————————		



# 10 INTEGRATION INTO THE CONTROL ENVIRONMENT

# 10.1 Start-up files and description of the process data and parameters

The start-up files required by the project planning software are available on the Internet.



Download the start-up files from:

 $\underline{country.burkert.com} \rightarrow \text{Type 8652} \rightarrow \text{Software} \rightarrow \text{Device Description Files.zip}$ 

You will also find the descriptions of the start-up files in the zip file.

→ Use the latest start-up file from the "01 Standard" folder (exception: see Chapter "10.2").



The description of the CANopen standard objects can be found under:

 $\sqrt{\text{country.burkert.com}} \rightarrow \text{Type } 8652 \rightarrow \text{Operating instructions} \rightarrow \text{"CANopen network configuration"}$ 

# 10.2 PLC compatibility

If new devices are to be operated with the start-up files of an older software version, e.g. because a replacement device is to be used in an existing automation system, this can be done without issue by converting the PLC compatibility.



The currently installed software is shown under Maintenance > SW version on the display of the fieldbus gateway.

Convert compatibility mode via the display of the fieldbus gateway:

"12.4 Converting compatibility mode" on page 64

Convert the compatibility mode via the Bürkert Communicator:

"16.2.6 Converting compatibility mode" on page 75

### 10.2.1 Compatibility mode and start-up files



Download the start-up files from:

country.burkert.com → Type 8652 → Software → Device Description Files.zip

In "Device Description Files.zip" there are sub-folders "01\_Standard" and "02\_Extension\_Modules" in each fieldbus folder (see Chapter "16.11 Using Extension Modules (EM)").

Please note the release notes in the respective folder in order to use the appropriate version of the start-up file.




# 10.2.2 Error alerts concerning PLC compatibility

Error code	Description	Troubleshooting
51/103	No or incorrect mapping file present.	If extension modules were used, perform the Extension module settings wizard again.  General settings > Parameter > Extension module settings
		Use a separate gateway configuration if one has been created.
51/400	The master attempted to connect a faulty module/	The version of the start-up file does not match the device (see chapters "10.2.1").
	sub-module.	The controller settings do not match the device.




# 10.3 Commissioning a PROFINET device with Siemens TIA Portal

→ Import the start-up file into the hardware catalogue of the tool. The start-up files of version V2.0 were used in the illustrations shown.




ightarrow Select the device in the hardware catalogue and drag and drop it into the work area.



- → Assign a PROFINET interface to the device.
- ightarrow Double-click the device in the work area. This opens the device overview.





On the right, in the "Catalogue" menu, you will find the modules:




→ Assign the modules to the respective slot by double-clicking or by drag and drop. <u>Map the real structure of the valve island from left</u> <u>to right</u>. Pressure measuring modules\* (if available) and valve units must be assigned.

In the screenshot below, the modules of a valve island with 1 pressure measurement module and 3 subsequent valve units are assigned to the slots as an example.









→ Then configure the position feedback sensor source for each valve unit.

To do this, drag the position feedback sensor source used from the submodules to the corresponding position in the device overview.

In the device overview, Subslot 1 corresponds to the valve,

Subslot 2 to the position feedback sensor source of the upper end position, Subslot 3 to the feedback source of the lower end position.

If no position feedback sensor source is dragged into the device overview, the feedback source on the valve units is deactivated.





Figure 30: The example shows the real structure of a valve island with 1 pressure sensor and 6 connected valve units, including position feedback sensor sources.

ightarrow Restart the valve island after the first connection has been established in order to apply the settings.




# 10.4 Commissioning a PROFIBUS DPV1 device with Siemens TIA Portal

→ Import the start-up file into the hardware catalogue of the tool. The start-up files of version V2.0 were used in the illustrations shown.




ightarrow Select the device in the hardware catalogue and drag and drop it into the work area.



- ightarrow Assign a PROFIBUS DPV1 interface to the device.
- → Double-click the device in the work area. This opens the device overview.



On the right, in the "Catalogue" menu, you will find the modules:



→ Assign the modules to the respective slot by double-clicking or by drag and drop. <u>Map the real structure</u> of the valve island from left to right. Pressure measuring modules (if present) and valve units must be assigned.


A connection module with an integrated pressure sensor is referred to as a "pressure measurement module".


#### Example for the assignment of the modules:

The valve island shown on the right has been configured in the following screenshot. From left to right, this valve island has 1 pressure measurement module (Pressure module\_1) and 3 valve units.

In our example, the valve units are equipped with digital inputs. The digital inputs report the upper end position of the actuator, the lower end position is reported via the controller.

The "ValveUnit FB up-term. down-plc" is therefore assigned to the corresponding slot for each valve unit (see also "Table 9").





→ Restart the valve island after the first connection has been established in order to apply the settings.




Module in the catalogue of the TIA Portal	Set position feedback sensor source
ValvesUnit	No position feedback sensor sources are set
ValveUnit FB up-term.	Upper end position: digital inputs valve island Lower end position: not used
ValveUnit FB down-term.	Lower end position: digital inputs valve island Upper end position: not used
ValveUnit FB up/down-term.	Upper / lower end position: digital inputs valve island (changing end position, single valve)
ValveUnit FB up-bus	Upper end position: via büS network Lower end position: not used
ValveUnit FB down-bus	Lower end position: via büS network Upper end position: not used
ValveUnit FB up-plc	Upper end position: via PLC Lower end position: not used
ValveUnit FB down-plc	Lower end position: via PLC Upper end position: not used
ValveUnit FB up-term. down bus	Upper end position: digital inputs valve island Lower end position: via büS network
ValveUnit FB up-bus down-term.	Upper end position: via büS network Lower end position: digital inputs valve island
ValveUnit FB up-term. down-plc	Upper end position: digital inputs valve island Lower end position: via PLC
ValveUnit FB up-plc down-term.	Upper end position: via PLC Lower end position: digital inputs valve island
ValveUnit FB up-bus down-plc	Upper end position: via büS network Lower end position: via PLC
ValveUnit FB up-plc down-bus	Upper end position: via PLC Lower end position: via büS network
ValveUnit FB up / down bus	Upper and lower end position: via the büS network
ValveUnit FB up/down-plc	Upper and lower end position: via PLC

Table 9: Modules for valve units in the catalogue of the TIA portal




# 10.5 Commissioning an EtherNet/IP device with Rockwell Logix Designer

- → Install EDS file. To do this, click on the EDS Hardware Installation Tool command in the Tools menu.
- → In the window that opens, click on Register an EDS file.




→ Right-click on Ethernet in the Controller Organiser window and select the New Module command. This opens the window Select Module Type.





- → Select the device in the Catalogue tab.
  - To simplify the search for the device:
  - select the filter "Buerkert Werke GmbH & Co. KG" or
  - enter the term "Airline" in the search field at the top left.
- → Confirm with Create. This opens the New Module window.








- → In the New Module window, choose the command Change. The Module Definition window opens.
- → Set the Connections in the Module Definition window:
  - First the number of valve units used,
  - then the number of pressure measurement modules \* (if available).

The valve island shown on the right was configured in the following screenshots. This valve island has 3 valve units and 1 pressure measurement module.


 $^{\star}\,)$  A connection module with an integrated pressure sensor is referred to as a "pressure measuring module".







- $\rightarrow$  Confirm with OK.
- → The acyclic values of the valve island are displayed online in the New Module > Parameters window. The position feedback sensor source can also be set online here. The position feedback sensor source can also be set via the control program via acyclic access.
- → If the position feedback sensor source changes, restart the valve island.





# 10.6 Bit-wise composition of the inputs and outputs




Figure 31: Valve units

The valve island is divided into valve units. A maximum of 8 valves (= 4 double valves!) are possible per unit. Depending on the configuration, each valve unit can have the following inputs and outputs (from the point of view of the PLC):

1 byte cyclic input	for feedback of upper end position via digital inputs, valve island or büS network
1 byte cyclic input	for feedback of the lower end position via digital inputs, valve island or büS network
1 byte cyclic output	for valves
1 byte cyclic output	for feedback upper end position via PLC
1 byte cyclic output	for feedback lower end position via PLC

The coding of the individual bits is always the same. Valve unit 1 is arranged on the left, valve unit 2 on the right, etc.

Further information can be found in the following chapters:

"8.5 Electrical connection assignment" on page 39

"9.2 Pneumatic connection assignment" on page 46

# 10.7 Advanced gateway functionalities



Information on:

Control mode (communication settings) and Object Route Function (access to other büS objects)

can be found at:

 $\underline{country.burkert.com} \ \to \text{Type 8652} \to \text{Operating instructions} \to \text{"Definition fieldbus"}$ 



### 11 CONFIGURATION WITH WEB SERVER

The valve island AirLINE Type 8652 has an integrated web server via which the device can be configured.

The web server can be used for the following protocols:

- PROFINET
- EtherNet/IP
- Modbus TCP

For access via web server, the device has a separate IP address.

# 11.1 Establishing a connection to the web server



Configuring multiple devices:

Because the devices have the same IP address upon delivery, there can only be 1 as yet unconfigured device in the network so that the device can be identified.

- ► Connect to the network and configure the devices individually in sequence.
- → Connect the PC to the device via a network cable.
- → Enter the IP address in the address line of the web browser.

With Ethernet/IP and Modbus TCP, the IP address of the device upon delivery is 192.168.0.100.

With PROFINET, the IP address is preset to 000.000.000.000. First, an IP address must be issued with a suitable tool, as otherwise there will be no connection to the web server. The IP address can be set with the display of the fieldbus gateway:

Parameters > Ind. Comm. > IP settings

If the IP address has been changed to an unknown value, the current IP address can be read in the Bürkert Communicator software or the display of the fieldbus gateway.




Figure 32: Web server view



### 11.2 Logging onto the web server

- → On the home page, click on Login on the top left.
- → Enter your user name and password: User name: admin Password: admin
- $\rightarrow$  Click on Login.

### 11.3 Passwords

#### **CAUTION**

Security risk due to standard passwords.

Unauthorised persons can log in to the web server and make changes to the system.

- ▶ Please change standard passwords.
- ▶ If the web server is not needed, disable access via Bürkert Communicator (see chapter <u>"16.10" on page 77</u>).

The following user names and passwords are active by default and are reactivated when the passwords are reset:

User name	admin	installer
Standard password	admin	admin

All user names have the same rights.

#### 11.3.1 Change password

- $\rightarrow$  Log in to the web server.
- → Enter and confirm the new password in the menu General settings.

#### 11.3.2 Reset passwords to factory settings

- → Click on Login.
- → On the bottom right of the login window, click on Reset passwords.

The device must be rebooted within 3 minutes so that the passwords can actually be reset. A restart can be triggered via the fieldbus gateway display, the Bürkert Communicator software or via a voltage reset.

# 11.4 Finding the device



In order to localise the currently selected device in the web server when using multiple devices, click the button Locate device in the "Device information" menu.

The status LED of the selected fieldbus gateway flashes for a few seconds.



# 11.5 Disabling web server access with Bürkert Communicator

The web server is enabled upon delivery. Web server access can be disabled via the Bürkert Communicator software (see chapter "16.10" on page 77).

### 11.6 Information in the web server

#### 11.6.1 Device information

Common	Displayed name
	Identification number of device
	Device serial number
	Software identification number
	Product type number
	Manufacture date
Versions	Software version
	Hardware version
	büS version
	EDS version
Diagnosis	Device status

#### 11.6.2 Messages

Messages are shown in the order of type, time and message text.

# 11.7 Setting options in the web server

Configuration of the valve unit	Valve configuration
	Fault action
	Fault state
	Switching cycle counter
	Position feedback sensor source
	Wire break detection active
	Signal inversion
Switching time monitoring	For information, see chapter <u>"21 Switch time monitoring function"</u> on page 97
Maintenance	Channel maintenance
	Reset switching cycle counter of pneumatic slide valve
	Reset switching cycle counter of actuators
	Set the date for routine maintenance
Status of the valve unit	



Pressure measurement configuration	Alarm limits
	Pressure indicators on internal displays
	Cyclical output of pressure value
Pressure measurement diagnostics	Display of the measured values:
	Current pressure
	Maximum pressure
	Minimum pressure
Installation of pressure measurement	Enabling/disabling pressure sensors

# 11.8 Industrial communication of web server

Configuration	• Protocol
	• IP settings
Information	Protocol
	Communication status
	Temporary IP address
	MAC address
Indication of process values	Process name
	Process value



# 12 CONFIGURATION WITH FIELDBUS GATEWAY

If the fieldbus gateway is equipped with display and operating elements, settings can be made via the fieldbus gateway.

#### Basic variant

By pressing one of the two arrow keys, the display shows the valve status (see also chapter <u>"19.2" on page</u> 89




Figure 33: Overview of operating elements of fieldbus gateway ME43

# 12.1 Operating the fieldbus gateway

Element	Function	
Menu button	<ul><li>Open main menu (double-click)</li><li>Confirm inputs</li></ul>	
△ ▼ Arrow keys	Scroll in menu     Change values	

Table 10: Function of the keys

# 12.2 Selecting the protocol

With PROFIBUS DPV1 and CC-Link, the protocol does not have to be selected. It is pre-set by the manufacturer.

For all other protocols:

- $\rightarrow$  Press the  $\bigcirc$  menu button twice.
- → Parameter > Ind. Comm. > Protocol
- → Select and confirm desired protocol.
- → Enable settings with Maintenance > Restart > Yes.



### 12.3 Enter PROFIBUS address or CC-Link address

- → Press the menu button twice.
- → Select Parameter > Ind. Comm. > Address.
- → Use menu button to enable processing.
- → Set, confirm and save the address with the arrow keys.



The Address menu is only available for PROFIBUS or CC-Link devices.

# 12.4 Converting compatibility mode

For information on the compatibility mode, see Chapter "10.2" on page 47.

- → Press the menu button twice.
- → Select Parameter > Ind. Comm. > Comp. Mode.
- → Select Specific or one of the available compatibility modes and confirm.

# 12.5 Valve configuration

The valve configuration is performed if pneumatic valves are later used on valve slots occupied by blind valves. Or when valves of different types are alternated.

- → Press the menu button twice.
- → Select Parameter > AirLINE > Valve cnf > Module 1/2/... > Slot 1/2/...
- $\rightarrow$  Select new valve type.
- → If necessary, configure other slots of this module.
- → Scroll down within this module, select Save.
- → If necessary, select other modules and configure valve slots.
- → Use Exit to navigate to the highest menu level.
- → Enable settings with Maintenance > Restart > Yes.

# 12.6 Configure pressure sensor(s)

- → Press the menu button twice.
- → Select Parameter > AirLINE > P.sens.conf > Left, Right or Middle 12 > Inactive or Active.
- → Use Exit to navigate to the highest menu level.
- → Enable settings with Maintenance > Restart > Yes.



# 12.7 Display: contrast, brightness, installation position, language

- → Press the menu button twice.
- → Select Parameter > Display.
- → Select the value to be changed.
- → Use menu button to enable processing.
- → Set the desired value with the arrow keys.
- $\rightarrow$  Confirm the value with the  $\bigcirc$  menu button.
- → Use Exit to navigate to the highest menu level.
- → Enable settings with Maintenance > Restart > Yes.

# 12.8 Configuration provider

Specify whether the valve island will compile the configuration from other devices in the büS network (config clients) and saves it on the SD card.

This function is only possible if an SD card is present in the device (SD card, see chapter <u>"28 Accessories"</u> on page 121)

- → Press the menu button twice.
- → Select Parameter > CfgProvid. > Off or On, confirm.

# 12.9 Error diagnostics

- → Press the menu button twice.
- → Select Diagnosis, confirm.

The error type and error code are displayed.

See chapter <u>"26.5" on page 116</u> for the description of error codes.

# 12.10 Restarting the valve island

Some settings require a reboot of the valve island.

→ Maintenance > Restart > Yes

# 12.11 Factory reset

- → Maintenance > Fact. reset > Yes
- The factory reset starts, and can take a few seconds.



# 12.12 Reset the switching cycle counters

The switching cycle counters can be reset for the complete valve island (all switching cycle counters of the pilot valves) or for each valve unit (modules).

- → Press the menu button twice.
- → Select Maintenance > Reset SCC.
- → Select All SCC or Module 1/2/... > Yes.

# 12.13 Replacing devices (config clients)

- → Press the menu button twice.
- → Select Maintenance > DevReplace.
- → Select serial number of original device.
- → Select serial number of replacement device.
- → Do Replace



# 13 MENU STRUCTURE FIELDBUS GATEWAY

ro = read only, rw = read / write

Ind Comm	
Ind. Comm  IP setting (with Industrial Ethernet)	n
Address	rv rv
Network	rv
Gateway	rv
Address (for PROFIBUS DPV1 and CC-Link)	11
Profibus address / CC-Link address	rv
Protocol (preset at factory for PROFIBUS and CC-Link	
Profibus	,
CC-Link	
EtherCAT	
Profinet	
EthIP	
Modbus	
CC-Link IE	
Comp. mode	rv
Specific	
V2.0	
Comp. V1.0	
BüS	
Baud rate	
500 kbit/s (can be set via PLC or Communi	cator) ro
NodelD Fixed uses	
	rv
Valve conf	
Module 1	
Slot 1	
Dummy valve	rv
2x3/2 C	rv
2x3/2 C SIA	rv
2x3/2 D	rv
5/2 H	rv
5/2 H SIA	rv
5/2 Z	rv
5/2 Z	rv
5/3 M	rv
5/3 L	rv
5/3 L SIA	rv
5/3 N	rv
Slot 2	
see Slot 1	
Slot 3 see Slot 1	
Slot 4	
Slot 4	
P.Sens.cnf	
Left	
Inactive	rv
Active	rv
Middle	



Righ	 nt		
Tilgi	Inactive	rw	
	Active	rw	
Display			
Contrast	rw		
Brightness			
Mounting			
Rev		rw	
Nor		rw	
Auto	)	rw	
Language			
Geri		rw	
Eng	lish	rw	
CfgProvid.			
Off		rw	
On		rw	
Diagnosis			
Desc	type is "Error", the error code is displayed. ription of the error codes: Page 116	ro	
/laintenance			
Restart			
	No		
Yes		rw	
Fact. reset			
No		rw	
Yes		rw	
Reset SCC			
All SCC		rw	
Modul 1		rw	
ID number		ro	
Serial number		ro	
SW version		ro	
HW version		ro	
büS version		ro	
	IComm-Ver.		
DevReplace			
Select S /	N from orig. Ger.	rw	
	evices	rw	
	of S / N of replacement device	rw	
	evices	rw	
Do Replac	e	rw	



# 14 FIELDBUS GATEWAY DISPLAY ELEMENTS




Figure 34: Overview of the display elements

# 14.1 LEDs for indicating the network connection to Industrial Ethernet

LED state		Description and cause of fault	Measure
Link LED active		Connection to network active	-
(yellow)	Not active	No connection to the network available.	Check cable.
Link/act LED (green)	active	Rapid flashing: Connection to the higher protocol layer (PRO-FINET, EtherNet/IP or Modbus-TCP) is established. Data being transmitted	
		Slow flashing, approx. 20 seconds after restart.  No connection to the protocol layer available.	
	Not active	No connection to the network available.	Check cable.

Table 11: Description: LEDs for the network connection



# 14.2 LED for displaying the device status

The LED for displaying the device status changes colour and status similar to NAMUR NE 107.

If various alerts are present, the LED always shines in the colour of the highest prioritised alert (red = outage = highest priority).

Indicators in NAMUR operation mode:

Status LED in line with NE 107, issue 2006-06-12			
Colour	Colour code	Description	Meaning
red	5	Failure, error or fault	Due to a malfunction in the device or its periphery, standard operation is not possible.
Orange	4	Function control	The device is searching for a büS participant. This status ends after a few seconds.
Yellow	3	Outside the specification	The environment conditions or process conditions for the device are not within the specified range.
			Internal device diagnostics indicate problems within the device or with the process properties.
			Data sheet values cannot be complied with.
Blue	2	Maintenance required	The device has detected a deviation during ongoing diagnostics and has implemented a correction. Device functionality limited.
			The device is in standard operation, but function will soon be restricted.
			→ Perform device maintenance.
green	1	Diagnostics active	Device is in error-free operation. Status changes are highlighted in colour.  Messages are sent via any fieldbus that may be connected.
white	0	Diagnostics inactive	Device is switched on. Status conditions are not displayed. Messages are not listed in the message list or transmitted via any connected fieldbus.
			Device is running within its specifications.

Table 12: Indication of the device status in NAMUR operation mode



The LED flashes while settings are made with Bürkert Communicator.



# 15 BÜRKERT COMMUNICATOR BASICS

The Bürkert Communicator software allows the comfortable configuration and monitoring of application-specific parameters.



The software can be downloaded free of charge from the Bürkert homepage. In addition to the software, the USB-büS-interface, available as an accessory, is required (see chapter <u>"28 Accessories"</u>).



The operating instructions for the basic functions of the software can be found on the Bürkert homepage: <u>country.burkert.com</u> → Type 8920




Figure 35: Example of a Bürkert Communicator user interface

When a device is connected to the Bürkert Communicator, it is displayed in the navigation section of the Communicator. Each device has configuration sections that are used to configure the device.

An overview of the menu structure can be found in chapter <u>"17 Bürkert Communicator menu structure" on page 80.</u>

#### Configuration section "Unit"

In the Communicator, a valve unit is referred to as a "unit" (1 valve unit = 1 electronic module with 4 valve slots).

The navigation section of the Communicator lists as many units as there are valve units in the valve island. The units are numbered consecutively, this corresponds to the sequence from left to right within the valve island.



#### 15.1 User levels

Bürkert Communicator is operated within user levels. There are 3 user levels, and each one has certain reading rights and writing rights.

The active user level is indicated by an icon on the upper left margin of the program window.

Icon	User level	Description	Standard password
Ω	User	Standard user	
		often only reading right, can change a few values	no password
		not all menus/values are displayed	
Ω	Advanced user	can change certain values	
		can perform simple calibrations	5678
		not all menus/values are displayed	
Ω	Installer	has all rights to operate the Communicator	
		all menus/values are displayed	1946

Table 13: User levels in ascending order from top to bottom

#### 15.1.1 Change user level

- → Click on the user levels icon on the upper left margin of the program window. The User password window appears.
- → Enter the password for the desired user level in the input field. The standard passwords are listed in "Table 13".

### 15.1.2 Changing user password

Required user level: "Installer"

Options > Password manager ...

- → If necessary, enter the installer password.
  The Change user passwords window appears.
- $\rightarrow$  Enter desired password.

With the Password manager, passwords can also be reset to the standard settings.

#### 15.1.3 Disabling user password

Required user level: "Installer"

### Options > Password manager ...

- → If necessary, enter the installer password.
  The Change user password window appears.
- → Disable the password at the desired user level.

User password	Active user level during program start
No user password disabled	User
"Advanced user" disabled	Advanced user
"Installer" disabled	Installer



## 15.2 Connecting the device to the Bürkert Communicator

- → Install Bürkert Communicator on the PC.
- → Set the terminating resistor (on the büS stick or external terminating resistor).
- → Use the USB-büS-interface to establish the connection between the device and the PC.
- → Start Bürkert Communicator.
- $\rightarrow$  In the menu bar, click the icon +3 for Add interface.
- → Select the büS stick.
- $\rightarrow$  Finish
- The connection between the device and Bürkert Communicator is established, the device is displayed in the navigation area.

The LED for indicating the device status on the fieldbus gateway display flashes while settings are made with Bürkert Communicator.



# 16 CONFIGURATION WITH BÜRKERT COMMUNICATOR



If a menu is missing or cannot be set:

→ Check the version and the active user level (see chapter "15.1 User levels" on page 72). Some views / settings are only available with the appropriate rights.

## 16.1 Base valve island settings

Settings for the valve islands such as valve configuration, troubleshooting or position feedback sensor source are made in this menu via a wizard.

General settings > Parameter > Setup

A wizard guides you through the base device settings.

## 16.2 Base Industrial Communicator settings

The protocol (protocol name) used is indicated in the configuration area of the Communicator. The protocol-specific settings on parameters, diagnostics and maintenance can be entered in this menu.

#### 16.2.1 Starting the start-up wizard

The start-up wizard can perform protocol-specific settings and check them for accuracy. The start-up wizard is only available for Industrial Ethernet protocols.

(Protocol name) > Parameter > (Protocol name) settings > IP parameter settings

#### 16.2.2 Change protocol

For devices with an Industrial Ethernet interface, the protocol can be changed. If devices feature a PRO-FIBUS interface or CC-Link interface, the fieldbus protocol has been preset at the factory and cannot be changed.

(Protocol name) > Parameter > Change protocol

- → In the drop-down menu on the right, select the protocol.
- → Restart the device.

#### 16.2.3 Configuring the fieldbus gateway

The device description file must first be loaded in the corresponding projection tool (e.g. TIA portal, RSLogix) for the fieldbus configuration. The corresponding protocol-specific settings can then be made in the configuration area (protocol name).



The description of the gateway configuration can be found in the fieldbus gateway Type ME43 operating instructions at: <a href="https://www.burkert.com">www.burkert.com</a>

If additional büS devices are connected to the valve island and are to be connected to a controller through them, the valve island can also be configured as a gateway.

**Note!** This generates a new description file, and functions such as PROFINET alarms or generally acyclic data of the valve island are no longer accessible to the controller. That is why this function is only conditionally recommended.



#### 16.2.4 Enter PROFIBUS address

#### PROFIBUS > Parameter > PROFIBUS Settings > PROFIBUS Address

→ Enter address. Valid addresses: 0–126 (factory setting value: 3)

If an address outside the valid range has been set, the device will issue an error message.

#### 16.2.5 Entering CC-Link address

#### CC-Link > Parameter> CC-Link Settings > CC-Link Address

→ Enter address. Valid addresses: 1–64 (factory setting value: 64)

#### 16.2.6 Converting compatibility mode

For information on compatibility mode, see chapter "10.2" on page 47.

#### (Protocol Name) > Parameter > PLC Connection Compatibility

→ Use the wizard in the drop-down menu to select the required version of the start-up data for the device.

#### 16.2.7 Read current IP address

If the IP address has been changed to an unknown value, the current IP address can be read in Bürkert Communicator.

(Protocol name) > Parameter > (Protocol name) settings

#### 16.2.8 Settings of the Industrial Ethernet protocols

#### (Protocol name) <mark>> Parameter > Protocol settings</mark>

Protocol	EtherCAT	PROFINET	EtherNet/IP	Modbus TCP
Fixed IP address	_	X	X	X
Network interface	_	X	X	X
Standard gateway	_	Х	X	X
Temporary IP address	_	Х	Х	_
DNS-compatible name (no special characters _ () / \ * are allowed in the name)	-	X	-	-

#### **Factory settings:**

Protocol	EtherCAT	PROFINET	EtherNet/IP	Modbus TCP
Default IP address		000.000.0000	192.168.0.100	192.168.0.100
Default name	_	AirLINE-8652	_	_



## 16.3 Base settings CANopen/büS

If devices feature CANopen/büS communication, the "CANopen" bus operation mode has been preset at the factory.

#### 16.3.1 Switching over bus operation mode

Bus operation mode can be switched over to "büS" using Bürkert Communicator.

General settings > Parameter > büS > Advanced > Bus mode

→ Select the bus operation mode in the drop-down menu on the right.

## 16.4 Active pressure sensor

When the connection modules of the valve island are equipped with integrated pressure sensors, the corresponding pressure sensors on the device are enabled by the factory and the diagnostic function Pressure measurement is displayed in the Communicator.

If connection modules with pressure sensors are subsequently integrated into the valve island, these pressure sensors must be enabled via the Bürkert Communicator.

During activation, make sure that only the sensors that are actually present in the valve island are enabled. If sensors that are not present are enabled, the device displays an error message.

General settings > Parameter > Configuration of pressure sensors

### 16.5 Disable or enable module supply monitoring

The supply voltage monitoring is enabled on the device by the factory. If the supply voltage for the valve block, valve units or individual valves is interrupted, an error message is sent to the controller.

The monitoring of the supply voltage can be disabled in the Bürkert Communicator if required.

General settings > Parameter > Configuration of module supply monitoring

## 16.6 Change "error" report status

With the Configuration of error status function, reports with the "error" status can be converted to a lower status in order to influence the effects of an error on the system.

General settings > Parameter > Configuration of error status

#### **Troubleshooting**

If the "error status" option is enabled, the valve assume the status that has been set in the Unit X > Fault handling menu.

When the "bueS pre-operational" option is enabled, no more cyclical data is sent to the büS network. This is detected by consumers in the büS network, which then generate an error.

## 16.7 Reset device to factory settings

Select General settings > Maintenance > Reset device > Reset to factory settings

#### 16.8 Restart device

Some settings require a restart of the valve island.

Maintenance > Reset device > Restart



## 16.9 Switch time monitoring of actuators

Monitoring the switching time duration of process valves. For further information, see chapter <u>"21 Switch time monitoring function" on page 97.</u>

Unit X > Actuator switching time > Measurement

A wizard starts measuring the actuator run time.

## 16.10 Disabling access to web server

The valve island has an integrated web server via which the device can be configured. The web server is enabled upon delivery. Web server access can be disabled via the Bürkert Communicator software.

Web server > Parameter > Activate web server

See also chapter "11" on page 59.

## 16.11 Using Extension Modules (EM)



This function is available for backward compatibility purposes and does not contain any of the new functions.

The description of how to connect other devices with the controller can be found in the fieldbus gateway Type ME43 operating instructions at: <a href="https://www.burkert.com">www.burkert.com</a>.

Extension modules are installed on a valve island with a fieldbus connection. This means that additional valve islands can be controlled via this valve island without a fieldbus connection.



1 extension module corresponds to 1 valve unit (4 valves and 1 electronic module).




Figure 36: Schematic structure of a bus system with extension modules



#### 16.11.1 Configuring the fieldbus

If the valve island is operated with extension modules, the corresponding start-up files must be used. These start-up files do not contain any acyclic objects. The configuration of valve islands with extension modules must be done via the Bürkert Communicator.

The start-up files required by the respective project planning software, such as EDS files, GSD and GSDML files, are available on the Internet.



Download the start-up files from: country.burkert.com  $\rightarrow$  Type 8652  $\rightarrow$  Software  $\rightarrow$  Device Description Files.zip



There are 2 variants of the start-up files available for download for each protocol. The variants differ in whether the valve island is operated with extension modules or not.

Start-up files for valve islands with extension modules have the designation "EM" in the file name.

Please refer to the documentation of your project design software for instructions regarding the installation of the start-up files.

#### 16.11.2 Configuring the valve island with extension modules

General settings > Parameter > Extension module settings

A wizard will guide you through the settings.

 $\rightarrow$  Finish

A restart is triggered. There are 9 extension modules available.

#### 16.11.3 Configuring the büS network

→ Select - 📜 büS in the navigation area, activate the detailed view of the Network Configuration.




Figure 37: Configuring the büS network in the "Network configuration" detail view

The network can be configured in 2 ways:



#### 1. Per Drag-and-drop

→ Connect the inputs and output via drag-and-drop. (Compatible connection points are highlighted in blue. Dashed connections do not yet represent an active connection between devices.)

#### 2. Via selection list

- → Click on the + in front of the respective entrance. Possible connections are offered as a selection list.
- → Click on the desired connection. The connection is created automatically.

#### With both types:

→ Once all connections have been made, select Apply changes.

All configured devices are re-started.

The büS network is configured.



## 17 BÜRKERT COMMUNICATOR MENU STRUCTURE



Bürkert Communicator is operated within user levels. There are 3 user levels, and each one has certain reading rights and writing rights.

See also chapter "User levels" on page 72.

The number of menus depends on the configuration of the device. It is therefore possible that not all menus are displayed in your application.

ro = read only, rw = read/write

Configuration section "Unit"				Ω	8
Parameter					
Valve configuration		r	W	rw	rw
Fault handling		r	W	rw	rw
Diagnostics		r	w	rw	rw
Position feedback sensor		r	W	rw	rw
Actuator switching time					
	Measurement	r	w	rw	rw
	Settings	r	W	rw	rw
Diagnostics					
Channel maintenance		r	O.	ro	ro
Channel fault		r	o	ro	ro
Maintenance					
Actuator		r	W	rw	rw
Pilot valve		r	w	rw	rw
Routine maintenance		r	W	rw	rw

Configuration area "(protoco	Configuration area "(protocol name)"			$\Omega$	$\mathcal{E}$
Parameter					
(Protocol name) setting	S				
(PROFIBUS DPV1)	PROFIBUS address		rw	ro	ro
	Set baud rate		rw	ro	ro
	Current baud rate	(visible, if baud rate "Auto" is read-	only)		
	Advanced settings				
		Internal cycle time	rw	ro	ro
		Control mode settings	rw	_	_
		Firmware update protocol	rw	_	_
(CC-Link)	Address		rw	ro	ro
	Transmission speed	'	rw	ro	ro
	Number of stations		ro	_	_
	Number of cycles		ro	_	_
	CC-Link version		ro	_	-
	Advanced settings				
		Internal cycle time	rw	ro	ro
		Control mode settings	rw	_	_
		Firmware update protocol	rw	_	_
(EtherCAT)	Start startup wizard	•	rw	_	-
	Station alias		rw	ro	ro
	MAC address		ro	ro	ro
	Advanced settings				
	J J-	Internal cycle time	rw	ro	ro
		Control mode settings	rw	_	_



guration area "(protocol n	ame)"			
		Firmware update protocol	rw	_
(PROFINET)	Start startup wizard		rw	_
	IP parameter settings		rw	_
	DNS compatible name		rw	ro
	Fixed IP address		rw	ro
	Network interface		rw	ro
	Standard gateway		rw	ro
	Temporary IP address		rw	ro
	MAC address		ro	ro
	Advanced settings			
		Alarm settings	rw	ro
		Internal cycle time	rw	ro
		Control mode settings	rw	_
		Firmware update protocol	rw	-
(EtherNet/IP)	IP parameter settings	· ·	rw	_
	IP settings		rw	ro
	Fixed IP address		rw	ro
	Network interface		rw	ro
	Standard gateway		rw	ro
	Temporary IP address		rw	ro
	MAC address		ro	ro
	Advanced settings			
		Internal cycle time	rw	ro
		Control mode settings	rw	-
		Firmware update protocol	rw	T -
(Modbus TCP)	Start startup wizard		rw	_
(**************************************	IP parameter settings		+	
	Fixed IP address		rw	ro
	Network interface		rw	ro
	Standard gateway		rw	ro
	MAC address		ro	ro
	Advanced settings		+	
	/ tavarious settings	Internal cycle time	rw	ro
		Timeout communication	rw	ro
		Control mode settings	rw	10
		Firmware update protocol	rw	<del>  _</del>
(CC-Link IE field basic)	Start startup wizard	Tilliware apacte protocor	rw	-
(CC LITIC IE HEIG BUSIC)	IP parameter settings		100	
	Fixed IP address		rw	ro
	Network interface		rw	ro
	Standard gateway		rw	ro
	MAC address		ro	ro
	Advanced settings		10	10
	Advanced Settings	Internal cycle time	r)A/	ro
		Control mode settings	rw	ro –
			rw	-
Cataviani appliani		Firmware update protocol	rw	-
Gateway configuration	Downland a set	figuration file	10000	-
	Download a gateway con		rw	Η-
I Balancia and a second	Create a gateway configu	ration	rw	-
Hide process values			+	1
	Edit values to be hidden		rw	-
	Reset hidden values		rw	-
Change protocol			rw	-
onango protocor	Protocol			_



configuration area "(protocol name)"			2	Ω	
PLC connection compatibili	ty				
•	Select:		rw	ro	ro
	Start-up file version V01 or	version V02			
Diagnostics					
Protocol			ro	ro	ro
Communication status			ro	ro	ro
Control mode settings			ro	ro	ro
Established connections to	PLC		ro	ro	ro
Current internal cycle time			ro	ro	ro
Advanced					
	Last status code		ro	_	_
Maintenance					
Version number					
	Stack name		ro	ro	ro
	Stack version		ro	ro	ro
	Stack build		ro	ro	ro
	Stack revision		ro	ro	ro
	Stack date		ro	ro	ro
	ICom version		ro	ro	ro
Hardware reset			rw	_	_

"Web	server" configuration area		S	2	3
Paran	neter				
	Activate web server		ro	_	_

'Pressure measurement" configuration area				$\Omega$	8
Parameter					
Pressure sensor (left /	middle / right)				
	Alarm limits				
		Maximum pressure	ro	ro	ro
		Error high	rw	ro	ro
		Error low	rw	ro	ro
		Warning high	rw	ro	ro
		Warning low	rw	ro	ro
		Hysteresis	rw	ro	ro
		Enter fault state	rw	ro	ro
	Presentation				
		Display number	rw	rw	rw
		Unit	rw	rw	rw
	Cyclic output active		rw	ro	ro
Diagnostics					
Pressure sensor (left /	middle / right)				
	Status of pressure inlet				
	Pressure		ro	ro	ro
	Maximum pressure		ro	ro	ro
	Minimum pressure		ro	ro	ro
	Resetting the max./min. va	alues	rw	rw	ro



figuration section "Ge	neral settings"		<b>6</b>		
ameter					Ť
Status LED					I
	Operation mode		rw	ro	
		then the "Fixed colour" operation mode	rw	ro	
	is activated)				1
büS	5: 1				+
	Displayed name		rw	rw	1
	Location		rw	ro	+
	Description		rw	ro	+
	Advanced				1
		Unique device name	rw	ro	+
		Baud rate	rw	ro	+
		Fixed CANopen address	rw	ro	+
		CANopen address	ro	ro	+
NA	"OANI"'IIIIIII	Bus operation mode	rw	ro	4
ivienu only appears who	en "CANopen" is selected as the bus opera	cation CANopen status	rw	ro	
Menu only appears when	"büS" is selected as the bus operation mo		rw	ro	+
World only appears who		partners	1 00	10	
		Deallocation delay	rw	ro	+
Alarm limits		Deallocation delay	IVV	ro	+
Alaitti iiitiits	supply voltage				+
	Supply voltage	Error below	ro	ro	+
		Error above	ro	ro	1
		Hysteresis	ro	ro	$\frac{1}{1}$
	Device temperature	Hysteresis	10	10	1
	Device temperature	Error below	ro	ro	1
		Error above	ro	ro	+
		Hysteresis	ro	ro	+
	Warning battery voltage I		ro	ro	+
Diagnostics	warning battery voltage i	below	rw	ro	+
PDO configuration			rw	rw	+
Demo mode			rw		+
Configuration provide	er e		I VV		+
Configuration provide	Status		rw	ro	+
	Delete all device configu	rations	rw	ro	$\frac{1}{1}$
	Force reconfiguration of a		rw	ro	1
	Ignore offline devices		rw	ro	+
Display	ignore omine devices		1 00	10	+
Display	Brightness		rw	rw	+
	Contrast		rw	rw	+
	Installation position fields	ous gateway	rw	rw	1
	Screen saver	gatoway	1 00		†
	Corcon daver	Delay	rw	rw	1
		Brightness	rw	rw	†
	Language (German /	Brightness	rw	rw	†
	English)		' **	' ' '	
	Re-initialisation		rw	_	+
Setup	TIO IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII		rw	<u> </u>	+
Configuration of pres	SUIRE SENSORS		rw	<del>-</del>	1
	lule supply monitoring		rw		1
Configuration of erro			rw		+
Configuration of exte			rw		1
Extension module se				_	1
nostics	illigo		rw	<del>-</del>	1
Device status					
Device status					1



onfiguration section "Genera	l settings"			1	2
	Operating duration		ro	ro	r
	Operating duration since las	t boot	ro	ro	r
	Device temperature		ro	ro	ı
	supply voltage		ro	ro	
	Voltage drops		ro	ro	
	Min./max. values		ro	ro	T
		Min. temperature	ro	ro	
		Max. temperature	ro	ro	T
		Min. supply voltage	ro	ro	
		Max. supply voltage	ro	ro	
	Device start counter		ro	ro	
	Removable storage		ro	ro	
	medium status		.0		
	Current system time		ro	ro	+
	Battery voltage		ro	ro	
büS status	Battery voitage		10	10	
buo status	Receive error			ro	+
			ro	ro	-
	Receive error max.		ro	ro	$\perp$
	Send error		ro	ro	-
	Send error max.		ro	ro	$\perp$
	Reset error counter		rw	ro	
	CANopen status		ro	ro	
Logbook			ro	ro	-
Configuration provider			$\longrightarrow$		
	Status		ro	ro	_
	Number of managed device		ro	ro	L
	- Number of which offline co		rw	rw	
	- Number of which authorise		rw	rw	
	Number of reconfigured dev		rw	rw	
	Number of loaded device co	onfigurations	rw	rw	
	Number of missing devices		rw	rw	
	Number of faulty configuration		rw	rw	
	Number of faulty reconfigura	ations	rw	rw	
	Managed devices		ro	ro	
aintenance					
Device information					
	Displayed name		ro	ro	
	ID number		ro	ro	
	Serial number		ro	ro	
	Software ident. number		ro	ro	T
	Software version		ro	ro	T
	büS version		ro	ro	Ť
	Hardware version		ro	ro	
	Product type		ro	ro	+
	Manufacture date		ro	ro	+
	eds version		ro	ro	t
	Device driver				t
	201100 011101	Driver version	ro	ro	$\dagger$
		Firmware group	ro	ro	+
		DLL version		ro	+
		Place of origin	ro		+
Depart devices		riace of origin	ro	ro	+
Reset device	Daadad				+
	Restart		rw	ro	-
	Factory reset		rw	ro	



## 18 START-UP

## 18.1 Safety instructions



#### WARNING

Risk of injury due to improper operation.

Improper operation may result in injuries as well as damage to the device and the surrounding area.

- ▶ Before start-up, ensure that the operating personnel are aware of and have completely understood the contents of the operating instructions.
- ▶ Observe the safety instructions and information on intended use.
- ▶ Only adequately trained specialists are allowed to put the device into operation.

#### **NOTE**

Internal short circuit between the auxiliary pilot air and the pilot pressure.

To avoid an internal short circuit, the seals of the connection modules must be positioned the same (external or internal supply of auxiliary pilot air). Mixing the external or internal supply is not permitted.

▶ Before start-up, check whether all seals on the connection modules are positioned in the same way (external or internal, see "Figure 29" on page 45).

## 18.2 Commissioning via manual override

Manual override is ideal for starting up the device and system. The manual override works without voltage being applied to the valve island and allows manual valve switching.

Depending on the circuit function (CF) of the valves, the manual overrides are labelled differently:

CF C, CF Z, CF H (for CF H only 1 manual override):

Labelling	Effect of the switched manual override
12	Supply channel 1 connected to working port 2
14	Supply channel 1 connected to working port 4

#### CFD:

Labelling	Effect of the switched manual override	
10 (12)	Connection between supply channel 1 and working port 2 interrupted	
10 (14)	Connection between supply channel 1 and working port 4 interrupted	




Figure 38: Manual override of the valves



The standard manual override is spring return and latching.

#### Spring return:

If the sliding mechanism is moved to a first resistor, the manual override returns to the unswitched state after release.

#### Latching:

If the resistor is exceeded, the manual override stops in the switched state after release. Slide mechanism must be pushed back manually over the locking point to reset the manual override to the unswitched state

#### 18.2.1 Additional element "Lock Manual Override"




Figure 39: Additional element "MO locking"

The additional element "Lock Manual Override" enables manual override to be restricted.

Depending on the rotational position (rotated  $0^{\circ}$  or  $180^{\circ}$ ) of the clipped-in additional element, manual override is only tentative or locked.

The additional element is available as an accessory (see "Other accessories" on page 123).

## 18.3 Identification of the valve positions

Device markers in MultiCard format are included in the scope of delivery of the valve island:

Inscription label ESG 5/10 MC NE WS

The device markers are fixed to a sprue and can be printed in this form using standardised industrial printers (e.g. from Weidmüller). After printing, the device markers can be removed from the sprue and clipped onto the valve.




Figure 40: Labelling of the valve positions with device markers in MultiCard format: After printing, the device markers can be removed from the sprue and clipped onto the valve.



## 19 DISPLAYS

## 19.1 Status displays on the electronic module



Figure 41: Display elements on the electronic module


The electronic modules are equipped with an LC display for status display. The switch position and possible error states of the outputs are shown graphically on the display. Depending on the configuration of the module, additional information can be displayed, e.g.

- Position of the actuator that is assigned to the output,


Any messages (information, warnings, errors) appear as text on the LC display. The text message is displayed alternating cyclically with the graphical display of the channel status.

Display view with 4 valve positions (e.g. 5/2-way valves)
Display view with 4 valve positions (Double valves, e.g. 2x3 / 2-way valves)
Mixed display view (double and single valves)
Valve 1 actuated
Valve 1 actuated, Feedback: "Upper end position reached"
Valve 1 actuated, Feedback: "Lower end position reached"
Valve 1 + 2 each have 1 valve slot Valve 3 + 4 each have 1 empty slot (blind valve)









# 19.2 Basic variant:Valve status display on fieldbus gateway

With the Basic variant, the valve status can be shown on the display of the fieldbus gateway.

By pressing one of the two arrow keys, you can switch between the standard display and the valve status display.




Figure 42: Basic variant, display options

#### Description valve status display




Figure 43: Basic variant, valve status display



# 20 COMBINE VALVE ISLAND WITH EXTERNAL DI MODULES

If the number of digital inputs (DIs) on the valve island is insufficient or the valve island does not have DIs, external DI modules can be added as position feedback sensor sources.

External DI modules can, for example, be B. 8DI modules of type ME44 or 16DI modules of type ME64.

The start-up files of the valve island already contain the settings of the external DI modules.



Download the start-up <u>files from: country.burkert.com</u>  $\rightarrow$  Type 8652  $\rightarrow$  Software  $\rightarrow$  Device Description Files.zip

#### Steps required:

- 1. Assign position feedback sensor source in the automation software (see "20.1").
- 2. Assign position feedback sensor source in Bürkert Communicator (see "20.2").
- 3. Carry out network configuration in the Bürkert Communicator (see "20.3").
- 4. Set the display of error messages in the Bürkert Communicator (see "20.4").

These settings must be made separately for each valve unit.

#### Alternatively: required steps via a wizard:

If the configuration is identical for each valve unit, it is recommended to use a wizard in the Bürkert Communicator. The procedure is described in Chapter <u>"20.5 Configure external DI modules using a wizard"</u>.

## 20.1 Assign position feedback sensor source in the automation software

#### **CAUTION**

With PROFIBUS and PROFINET, the settings in the automation software overwrite the settings in the Bürkert Communicator.

▶ Make sure that the settings are identical in both programs.



For the external DI modules, the position feedback sensor source is always "büS" or "büS network".

Information on start-up with automation software can be found in Chapter <u>"10 Integration into the control environment" on page 47</u>.

## 20.2 Assign position feedback sensor source in Bürkert Communicator

The position feedback sensor source must be assigned to each valve unit separately.

In the valve island configuration area ::

User level: Installer

- $\rightarrow$  Choose unit.
- → Select the source for the upper end position and the lower end position under Parameter > Position feedback sensor.




## 20.3 Network configuration in the Bürkert Communicator

This chapter describes the configuration of valve island / DI module combinations using 3 examples.

#### Where is the network configuration done?


User level: Installer

- → Click in the configuration area on the büS interface □
- → Select the "Network configuration" tab in the work area.



## 20.3.1 Example 1: Valve island with 6 valve units and 6 internal DI modules in combination with 8DI modules ME44

A maximum of 2 DI modules (each with 8 DIs) are possible per valve unit. In the case of a valve island with 6 valve units and 6 internal DI modules, a maximum of 6 external 8DI modules can be used.





#### Network configuration of example 1 in the Communicator:


In the example, the following position feedback sensor sources are assigned:

Upper end position "External DI module (büS)"

lower end position "Integrated DI module"



The assignment of the position feedback sensor sources to the upper and lower end positions is arbitrary <u>.</u>



- → Connect the ME44-DIs to a position feedback sensor input.
- ightarrow Once all connections have been made, select Apply changes .

All configured devices are re-started.




The assignment of the position feedback sensor inputs must be created separately for each valve unit!




## 20.3.2 Example 2: Valve island with 6 valve units without internal DI modules in combination with 8DI modules ME44

A maximum of 2 DI modules are possible per valve unit. In the case of a valve island with 6 valve units without internal DI modules, a maximum of 12 external 8DI modules can be used.



#### Network configuration in the communicator:

In the figure below, the following position feedback sensor sources are assigned to the end positions: Upper end position "External DI module (büS)" Lower end position "External DI module (büS)"



- → Connect the ME44-DIs with the position feedback sensor inputs.
- → Once all connections have been made, select Apply changes .

All configured devices are re-started.




The assignment of the position feedback sensor inputs must be created separately for each valve unit!




## 20.3.3 Example 3: Valve island with 6 valve units without internal DI modules in combination with 16DI modules ME64

A maximum of 2 DI modules with 8 DIs each (= 16 DIs per valve unit) are possible per valve unit.

In the case of a valve island with 6 valve units without internal DI modules, 6 16DI modules of type ME64 can be used.



#### Network configuration in the communicator:



- ightarrow Connect the ME64-DIs to a position feedback sensor input.
- → Once all connections have been made, select Apply changes.

All configured devices are re-started.



The assignment of the position feedback sensor inputs must be created separately for each valve



## 20.4 Show errors from büS partners on the display

If the valve island with a DI module Type ME64 or ME44 is used, wire break or short circuit alerts can be indicated on the valve unit display as though it were an internal module.



The settings for this can be made with the Bürkert Communicator software.

In the valve island configuration area :: ::

User level: Installer

- → Select General settings.
- → Select Menu Parameter > büS > Advanced > Show errors from büS partners.
- → In the drop-down menu on the right, select Only Producers.

In the configuration area ME44 or ME64!

User level: Installer

- $\rightarrow$  Select Inputs.
- → Switch off Mark bus-outputs as invalid.
- $\rightarrow$  If desired, activate Wire break detection active .



## 20.5 Configure external DI modules using a wizard

If the configuration is identical for each valve unit, it is recommended to use a wizard in the Bürkert Communicator.

→ Assign the position feedback sensor sources in the automation software (see <u>"20.1"</u>).

In the Bürkert Communicator, valve island configuration area <sup>‡C</sup>: User level: Installer

- → Select General settings.
- → Select Menu Parameter > Configuration of external DI modules.
- A wizard guides you through the settings:

#### Page 1 of the wizard

→ In the selection field on the right, select the end position that is transferred from the external DI module. The assignment to the end position and the setting for wire break detection apply to all valve units (see also Chapter "8.5 Electrical connection assignment" on page 39).

#### Page 2 of the wizard

In the selection field on the right, select the value for each valve unit that is reported by the external DI module.



### 21 SWITCH TIME MONITORING FUNCTION

With this function, wear or possible defects in the process valves (actuators) can be detected early by monitoring the switching time duration, e.g. to optimise maintenance intervals.

The valve island can record and permanently monitor the switching times of individual or all actuators in the ongoing process. Once a process parameter changes and this affects the switching time of the actuators, this is recorded and a maintenance notification is sent to the controller. The device changes the Namur Status to blue. The display shows the channel on which the deviation is present.

The set-up operation takes place in the background and has no impact on the process.

## 21.1 What exactly is being measured?

The time from switching the pneumatic valve to the end position feedback is measured.



Figure 44: Time span of the switching time measurement

## 21.2 Settings for the actuator switching time

## 21.2.1 Tolerance (permissible deviation of the actuator switching time)

An average value is determined from 20 consecutive actuator switching times.

The permissible range in which this average value may be exceeded or not reached can be set by the user as a percentage. The default value of the tolerance is 50%.

If values outside the permissible range are determined 3 times in succession, a maintenance message is issued.

#### Example:

The average value determined is 5 s.

With a 50% tolerance, this results in a permissible range of 2.5 s to 7.5 s.

If 3 measurements <2.5 s or >7.5 s are determined in succession, a maintenance message is issued.

Exceeding the permissible tolerance range can indicate the beginning of wear on the actuator, a leak in the pneumatic supply branch from the valve island to the actuator or fluctuations in the compressed air network.

#### 21.2.2 Timed out

The default value for the timeout is 60 s.

If the switching time measurement has been carried out, 3 times the value of the determined average value applies to the timeout instead of the default value.

If this value is exceeded once, a maintenance message is issued.



#### Example:

The average value determined is 5 s, resulting in a timeout of 15 s.

If a switching time >15 s is measured, a maintenance message is issued immediately.

A timeout indicates a malfunction of the actuator, e.g. due to a loose hose or a seizure of the actuator.

### 21.3 Start switching time measurement

The switching time measurement can be started using the Bürkert Communicator software, the web server or an external controller.

#### 21.3.1 Requirements for correct switching time measurement

- · Position feedback sensor units are connected and working
- · Measurements take place under standard process conditions
- Compressed air supply is stable

#### 21.3.2 Start switching time measurement via Bürkert Communicator

- → Make sure that the "Installer" user level is active (see chapter "15.1 User levels")
- → Select Unit X (the switching time measurement must be started / stopped separately for each valve unit).
- → Select Parameter > Actuator switching time > Measurement.
- → Mark the desired feedback inputs.
- → Start of measurement: Yes
- → Finish

The valve island measures the actuator switching time.

#### Measurement information

During the measurement, the message Actuator runtime measurement active is displayed in the Communicator.

The progress of the measurement can be read under Parameter > Actuator switching time > Measurement > Finish. Inputs for which the measurement has been completed are no longer marked.

After the measurement, the values can be read under Unit X > Diagnostics > Channel maintenance.

#### 21.3.3 Start switching time measurement via web server

- → Select Menu Switching time monitoring.
- → Select unit (the switching time measurement must be started / stopped separately for each valve unit).
- → Select the desired position feedback sensor inputs.
- → Start measurement.

The valve island measures the actuator switching time.



#### Measurement information

While the measurement is running, the Start measurement button is greyed out in the Switching time monitoring menu.

After the measurement, the values can be read in the Maintenance menu.

#### 21.3.4 Switching time measurement start via external controller

The objects for starting the switching time measurement via an external controller can be found in the "Device Description files" on the Bürkert homepage under:



 $\underline{country.burkert.com}$  → Type 8652 → Software → Device Description files

# 21.4 Error messages for the function of the switching time monitoring

If the tolerance value of the actuator switching time is exceeded, a maintenance message is sent to the controller. The display of the corresponding valve unit shows the channel on which the deviation is present (see also "19.1 Status displays on the electronic module" on page 87).

As soon as 1 correct measurement is taken again, the error message on the display disappears and the controller is informed.



## 22 MICRO SD CARD

A micro SD card is available as an accessory for the valve island. The micro SD card can be used to store device-specific values and user settings and transfer them to another device.



If the micro SD card of the device is re-inserted at a later stage, the data last saved are not restored. The micro SD card will not transfer the stored data to the same device.

#### Note!

By resetting the device to the factory settings, the data saved on the SD card are also reset.

A newly created micro SD card is checked for the presence of existing data when the device is re-started. This data will be transferred or overwritten accordingly:

- The micro SD card does not contain any data.
   The existing device-specific values and user settings are saved to the micro SD card.
- The micro SD card contains data compatible with the device.
   The data on the micro SD card are transferred by the device. The existing device-specific values are saved to the micro SD card.
- The micro SD card contains data that are not compatible with the device.
   The device overwrites the data on the micro SD card with its own device-specific values and user settings.

#### CAUTION

The micro SD card used is a special industrial version that offers additional durability and temperature-resistance.

▶ Do not use a standard micro SD card for the device. Only purchase the micro SD card for the device from your Bürkert sales department.

#### Replacing the micro SD card




Figure 45: Change micro SD card

#### NOTE!

Do not remove the SD card while the supply voltage is applied.

If the SD card is removed while the supply voltage is applied, data may be lost and the SD card may be damaged.



The SD card can be inserted while the device is connected to the supply voltage. A restart is required to ensure that the device detects the SD card.

#### Removing the micro SD card:

→ Pull the cover out of the recess and turn it to the top left.



 $\rightarrow$  To unlock, press on the edge of the engaged micro SD card, Remove micro SD card.

Insert the micro SD card into the replacement device:

- ⚠ Observe the direction of insertion when inserting the card.
- ightarrow Slide the micro SD card into the card slot. Make sure that the micro SD card locks into position.
- → Close card slot with bonnet.



## 23 BACKUP BATTERY

The device is equipped with a backup battery. The function of the battery relates exclusively to the time recording in the logbook.

If the battery is empty, it will not cause a fault in the device. There is only a message in the Bürkert Communicator software.



### 24 REPLACING SPARE PARTS



#### **WARNING**

Risk of injury due to improper installation work.

- ► Only trained technicians may perform installation work.
- ▶ Perform installation work using suitable tools only.

The following modules are available as spare part kits or for retrofitting for the valve island AirLINE Type 8652 under the type SV04:

- · Connection module
- · Electronic module
- · Pneumatic valves

If modules with modified functions are used, the modifications must be adapted accordingly in the device configuration. This can be achieved via the Bürkert Communicator software or via the web server, in some cases also via the display of the fieldbus gateway ME43 (pressure sensor and valve configuration).

### 24.1 Connection module with compressed air supply

Connection module with compressed air supply can be equipped with an additional port for the compressed air supply. This additional port is advantageous, e.g., for easier tubing when the compressed air source is located in the control cabinet.

Variant	Port size	Order no.
With an additional port for the compressed air supply	Plug-in coupling Ø 6 mm and Ø 10 mm	384863
	Plug-in coupling Ø 1/4" and Ø 3/8"	384864
Without an additional port for the compressed air supply		384866

Table 14: Overview of the "connection module without pressure sensor" variants

### 24.1.1 Replacing the connection module



#### DANGER

Danger due to high pressure, escaping medium and uncontrolled movement of the actuators.

- ▶ Secure the actuators against shifting before working on the device or plant.
- ► Switch off the pressure before working on the device or plant. Vent or empty the lines.

#### **NOTE**

Internal short circuit between the auxiliary pilot air and the pilot pressure.


To avoid an internal short circuit, the seals of the connection modules must be positioned the same (external or internal supply of auxiliary pilot air). Mixing the external or internal supply is not permitted.

- ▶ Never mix the external or internal supply.
- ▶ Note chapter <u>"9.1.1 External and internal auxiliary pilot air" on page 45</u>.



The X port always has to be connected for an external supply.





- $\rightarrow$  lacktriangle Observe the safety instructions.
- ightarrow Use a screwdriver (TX 20) to undo the fastening screw of the connection module.
- → Extract the connection module from the front.
- → Insert the new connection module and screw it into position (tightening torque 2 Nm).



#### 24.2 Connection module with pressure sensor

The connection modules with pressure sensor are always equipped with an additional port for the compressed air supply. The following variants are available:

Variants	Order no.
Port for the compressed air supply: Plug-in coupling Ø 6 mm and Ø 10 mm	
Port for the compressed air supply: Plug-in coupling Ø 1/4" and Ø 3/8"	384868

Table 15: Overview of the "connection module with pressure sensor" variants



Due to technical reasons, a connection module with pressure sensor cannot be used with devices purchased before 1 July 2020.

#### 24.2.1 Replacing the connection module



#### **⚠** DANGER

Danger due to high pressure, escaping medium and uncontrolled movement of the actuators.

- Secure the actuators against shifting before working on the device or plant.
- Switch off the pressure before working on the device or plant. Vent or empty the lines.



#### **CAUTION**

Risk of injury due to electrical voltage.

- ► Switch off the power supply before working on the device or system. Secure against reactivation.
- ► Observe the applicable accident prevention and safety regulations for electrical devices.

#### CAUTION

Electrostatically sensitive components and assemblies.

The device contains electronic components that are susceptible to the effects of electrostatic discharging (ESD). Components that come into contact with electrostatically charged persons or objects are at risk. In the worst case scenario, these components will be destroyed immediately or fail after start-up.

- ▶ Meet the requirements specified by EN 61340-5-1 to minimise or avoid the possibility of damage caused by a sudden electrostatic discharge.
- ▶ Do not touch electronic components when the supply voltage is connected.

#### **NOTE**

Internal short circuit between the auxiliary pilot air and the pilot pressure.


To avoid an internal short circuit, the seals of the connection modules must be positioned the same (external or internal supply of auxiliary pilot air). Mixing the external or internal supply is not permitted.

- Never mix the external or internal supply.
- ▶ Note chapter "9.1.1 External and internal auxiliary pilot air" on page 45.



The X port always has to be connected for an external supply.





- ightarrow Observe the safety instructions.
- → Ensure the PCB and the pins of the new connection module are not damaged during all stages of the assembly process.
- ightarrow Use a screwdriver (TX 20) to undo the fastening screw of the connection module.
- → Extract the connection module from the front.
- → Insert the new connection module into a free slot and screw it into position (tightening torque 2 Nm).
- → Adapt the modified device configuration (pressure sensor), if necessary (via Bürkert Communicator software, ME43 display or web server).



#### 24.3 Electronic module

The electronic module is available in the following variants:

Variants	Order no.
Electronic module with digital inputs	384872
Electronic module without digital inputs	384873

Table 16: Overview of "electronic module" variants


#### 24.3.1 Replacing the electronic module

#### **CAUTION**

Irreparable damage to the fieldbus gateway.

If an electronic module is detached from an energised valve island, the electronics of the fieldbus gateway may be destroyed.

► Therefore, always switch off the voltage before unscrewing the electronic module from the valve island. Secure it against reactivation.



- $\rightarrow$  A Observe the safety instructions.
- → Use a screwdriver (TX 20) to undo the fastening screws of the electronic module.
- → Extract the electronic module from the top.
- → Insert the new electronic module into a free slot and screw it into position (tightening torque 2 Nm).
- → Adapt the modified device configuration (digital inputs), if necessary (via Bürkert Communicator software or web server).



#### 24.4 Pneumatic valves

Pneumatic valves are available in the following variants:

Variants		Order no.
2x CFC	(2x 3/2-way normally closed)	301374
2x CFD	(2x 3/2-way normally open)	301375
CF H	(5/2-way monostable)	301376
CFZ	(5/2-way bistable)	301377
CFM	(5/3-way pressurised)	301379
CFL	(5/3-way blocked)	301380
CFN	(5/3-way vented)	301381
Blind valve		335779
2x CFC	SIA (2x 3/2-way normally closed)	338802
CF H	SIA (5/2-way monostable)	338805
CFL	SIA (5/3-way blocked)	346830

Table 17: Overview of "pneumatic valve" variants

#### 24.4.1 Replacing a pneumatic valve

## **DANGER**

Risk of injury due to high pressure and escaping medium at valve islands without hot swap function.

- ► At valve islands without hot swap function, secure the actuators against shifting before working on the device or plant.
- ► At valve islands without hot swap function, switch off the pressure before working on the device or plant. Vent or empty the lines.

Risk of injury due to high pressure and escaping medium at valve islands with hot swap function.

When dismantling a valve, lines and actuators may still be pressurised, which can cause uncontrolled movement of the actuator.

► At valve islands with hot swap function, secure the actuators against shifting before working on the device or plant.

At valve islands with hot swap function, the valves can be replaced under pressure.



To ensure safe dismantling of the valve from the valve island, there must be sufficient space to extract the valve from the front. In this case, the minimum distance between the valve island and the front edge of the control cabinet must be taken into account (see chapter "7.1" on page 28).

If there is not sufficient space to the front edge of the control cabinet, proceed as specified in chapter "24.4.2 Replacing a pneumatic valve (without minimum distance)" on page 110 when replacing a valve. In this case, the hot swap function is disabled!






Figure 46: Replacing a valve.



Observe the safety instructions.

- $\rightarrow$  Use a screwdriver to undo the fastening screw of the valve.
- → Extract the valve from the valve island.



If the device is used for a longer period of time, the seal of the valves may stick to the supply manifold. An increased amount of force may, therefore, be required to release the valves from the valve island.

- → Insert a new valve into the valve slot.
- → Tighten the fastening screw (tightening torque 2 Nm).
- → Adapt the valve configuration, if necessary (via Bürkert Communicator software, ME43 display or web server).



# 24.4.2 Replacing a pneumatic valve (without minimum distance)

# A

#### **DANGER**

Danger due to high pressure, escaping medium and uncontrolled movement of the actuators.

- ► Secure the actuators against shifting before working on the device or plant.
- ▶ Switch off the pressure before working on the device or plant. Vent or empty the lines.

#### CAUTION

Irreparable damage to the fieldbus gateway.

If an electronic module is detached from an energised valve island, the electronics of the fieldbus gateway may be destroyed.

► Therefore, always switch off the voltage before unscrewing the electronic module from the valve island. Secure it against reactivation.




Figure 47: Replacing a valve without minimum distance to the front edge of the control cabinet

If the minimum distance to the front edge of the control cabinet is too small to extract a pneumatic valve from the front of the valve island, a pneumatic valve can also be extracted from the top of the valve island if the electronic module has been dismantled in advance. In this case, the hot swap function is disabled.

- $\rightarrow$   $\Lambda$ 
  - Observe the safety instructions.
- ightarrow Use a screwdriver to undo the fastening screws of the electronic module and the valve.
- → Extract the electronic module from the top.
- → Extract the valve from the top of the valve island.
- → Insert a new valve into the valve slot.
- → Re-insert the electronic module into the valve island.
- → Tighten the fastening screws of the electronic module and the valve (tightening torque 2 Nm).
- → Adapt the valve configuration, if necessary (via Bürkert Communicator software, ME43 display or web server).



# 24.4.3 Replacing valves CFZ or CFZ\*



#### WARNING

Danger due to uncontrolled movement of the actuators.

→ For valves with hot swap function, secure the actuators against shifting before working on the device or plant.

For valves with circuit function Z and circuit function Z\*, depending on the switch position, either

Output 2 is aerated and Output 4 is vented

OI

Output 2 is vented and Output 4 is aerated.

#### Valves with circuit function Z\*

The valve island software ensures that the newly installed valve adopts the switch setting of the original valve in the event that a valve is replaced (hot swap).

For valves with circuit function Z\*, manual override is disabled after initial electrical activation.

#### Valve with circuit function Z

Replaced valves with circuit function Z take on an undefined switch position.



# 25 REPLACE THE ME43 FIELDBUS GATEWAY

# Λ

# WARNING

Danger due to uncontrolled movement of the actuators.

- ► Secure the actuators against shifting before working on the device or plant.
- ► Switch off the pressure before working on the device or plant. Vent or empty the lines.
- ▶ Switch off the power supply before working on the device or system. Secure against reactivation.




Figure 48: Replacing the fieldbus gateway

- $\rightarrow$ 
  - Observe the safety instructions.
- → Loosen the electrical connections.
- → Loosen the fastening screws of the gateway with a screwdriver.
- → Detach the gateway to the left from the valve island.
- $\rightarrow$  Remove the micro SD card.
- → Insert the micro SD card in the new gateway (note the direction of insertion!).
- → Place the new gateway on the standard rail and push it onto the valve island so that the gateway is connected to the valve island.
- → Tighten the fastening screw (tightening torque 1 Nm).
- → Connect the gateway electrically.



#### MAINTENANCE, TROUBLESHOOTING 26

#### Safety instructions 26.1



#### **WARNING**

Risk of injury due to improper maintenance work.

▶ Maintenance may be carried out by authorised technicians only and with the appropriate tools!

Risk of injury due to unintentional activation of the system and uncontrolled restart.

- ► Secure the system against unintentional activation.
- ► Ensure a controlled restart after maintenance is completed.

#### 26.2 Replace filter for auxiliary pilot air

# **DANGER**

Risk of injury due to high pressure and escaping medium.

- Secure the actuators against shifting before working on the device or plant.
- Switch off the pressure before working on the device or plant. Vent or empty the lines.



The filter is available as an accessory from Bürkert (see chapter<u>"28 Accessories" on page 121</u>).




Figure 49: Replacing the filter

- → Use a screwdriver to undo the fastening screw of the connection module.
- → Extract the connection module from the front.
- → Pull out the filter with a slotted screwdriver
- → Insert a new filter. Make sure that the cone of the filter hits the hole provided.
- → Insert the connection module and screw it into position (tightening torque 2 Nm).



# 26.3 Troubleshooting

Fault	Possible cause	Remedy		
Valves do not	no or too low load voltage	Check the electrical connection		
switch		ensure correct load voltage		
	Manual override of the valves not in neutral position	Bring the manual override into the neutral position		
	Pressure supply insufficient or not available	Set up the largest possible volume of pressure supply (also for upstream devices such as pressure regulators, maintenance units, on/off valves, etc.)		
		for valves without auxiliary pilot air: Ensure a minimum operating pressure of 3.0 bar and observe the ratio of pilot pressure to medium pressure in accordance with the pilot pressure diagram (see Chapter "6.6.1" on page 21)		
	wrong configuration	Configure the system according to the hardware structure		
	Channel not released for use	Changing the setting of the parameters (Communicator)		
	24 V supply not connected or incorrectly contacted	Make sure the 24 V supply is connected correctly		
	for SIA variant: Connection terminal with bridge or connected cable not connected	Connect connection terminal with bridge or connected cable		
Valves switch with a delay or blow off at the exhaust ports	Pressure supply insufficient or not available	Set up the largest possible volume of pressure supply (also for upstream devices such as pressure regulators, maintenance units, on/off valves, etc.)		
		for valves without auxiliary pilot air: Ensure a minimum operating pressure of 3.0 bar and the ratio of pilot pressure to medium pressure in accordance with the pilot pressure diagram (see Chapter "6.6.1" on page 21)		
	Pressure build-up of pilot pressure insufficient	With 5/2-way valves (CF H) and 2x3 / 2-way valves (CF D, open when de-energised), operate the valve island with an external pilot pressure supply		
	Valves are not in home position (de- energised) during pressure build-up	Apply pressure to the valve block before switching the valves		
	Insufficient ventilation of the exhaust air ducts due to too small	Use suitably sized silencers or expansion vessels		
	or dirty silencers (back pressure)	Clean the dirty silencers		
	Impurities or foreign bodies in the pilot valve	Change valve		
	Impurities or foreign bodies in the filter	Clean the filter by blowing it out with compressed air or replace the filter		



# 26.4 Error messages on the LC display of the electronic modules

An overview of the possible display contents is given in Chapter <u>"19 Displays" on page 87.</u>

Message	Possible cause	Remedy
no message, LC	no or too low load voltage	Check the electrical connection
display off		ensure correct load voltage
	Voltage interruption during firmware update	Carry out the firmware update again
Pilot SCC Limit Ch. X or Act. SCC limit Ch. X	Maintenance limit for pilot valve / actuator channel X reached	Replace the pilot valve or service the actuator and reset the switching cycle counter
		or
		Deactivate switching cycle counter
		or
		Increase warning limit switching cycle counter
Short Circuit Ch. X	Short circuit on input x of the position feedback sensor unit (position	Check position position feedback sensor sensor / plug connection
	feedback sensor or plug connection	or
	defective)	Replace position feedback sensor
Wire Break Ch. X	Wire break on input x of the position	Check position position feedback
	feedback sensor unit (position feedback sensor or plug connection	sensor sensor / plug connection
	defective)	or
	,	Replace position feedback sensor
EVS active	24 V supply not connected or incorrectly contacted	Check correct connection
	Electric circuit of a valve unit inter- rupted due to the shutdown function "Module-based safety shutdown"	
Act Sw. Time	The tolerance value of the actuator switching time has been exceeded.	Maintain actuator (see chapter "21.4")



# 26.5 Description of the error code

Error code	Description
1/3	Overload detected.
2/1	Overvoltage detected.
2/2	Undervoltage detected.
2/3	Voltage warning limit exceeded.
2/4	Voltage warning limit undershot.
2/5	Battery voltage warning limit undershot.
2/6	Voltage drop detected.
3/1	Excess temperature detected.
3/2	Low temperature detected.
3/3	Temperature warning limit exceeded.
3/4	Temperature warning limit undershot.
18/4	SD card is defective.
18/7	Removable storage present.
18/8	No access to the removable storage possible.
18/9	Configuration is being successfully managed by another device.
18/10	Configuration is NOT being successfully managed by another device.
18/11	Unable to load device configuration via the configuration provider.
18/12	At least 1 device is missing.
18/13	Bürkert Communicator is required.
18/14	Device must be replaced.
18/15	Device cannot be replaced as there are two many options present. Reduce the number of compatible devices.
18/16	Problems when replacing device.
18/17	Problems when replacing device. Unable to write to at least 1 object.
18/18	Device replacement failed.
18/19	Device replacement completed successfully.
18/20	Configuration provider is not active as no memory card has been detected.
18/21	More than 1 configuration provider is active! Switch off the other provider functions.
19/1 19/6	Unit 1 Unit 6: Limit of switching cycle counter for pilot valve reached. Replace pilot valve.
19/7 19/12	Unit 1 Unit 6: Maintenance limit for actuator reached.
19/13 19/18	Unit 1 Unit 6: Short circuit on the upper position feedback sensor unit.
19/19 19/24	Unit 1 Unit 6: Short circuit on the lower position feedback sensor unit.
19/25 19/30	Unit 1 Unit 6: Wire break on the upper position feedback sensor unit.
19/31 19/36	Unit 1 Unit 6: Wire break on the lower position feedback sensor unit.
19/37 19/42	Unit 1 Unit 6: Maintenance required for actuator (routine maintenance).
19/45 19/50	Unit 1 Unit 6: Switching time of the upper feedback position of a valve outside the valid range.
19/51 19/56	Unit 1 Unit 6: Switching time of the lower feedback position of a valve outside the valid range.



Error code	Description
19/57	EVS (external valve shutdown) is active on one unit.
19/58	EVS (external valve shutdown) is active on a unit or the device has no power supply (24 V) for pneumatic valves.
19/59 19/64	Unit 1 Unit 6: Short circuit on an input of the position feedback sensor unit.
19/65 19/70	Unit 1 Unit 6: Wire break on an input of the position feedback sensor unit.
31/1 31/6	Unit 1 Unit 6: Overload detected.
31/7 31/8	Electronic module defective.
31/9	Valve control defective.
31/10 31/15	Unit 1 Unit 6: Internal connection to the digital inputs of the electronic module interrupted.
31/16 31/21	Unit 1 Unit 6: Internal connection to the display of the electronic module interrupted.
31/28	Internal connection to the display of the fieldbus gateway interrupted.
31/29	EVS status cannot be read
31/31	Internal connection to the left pressure sensor interrupted.
31/32	Internal connection to the middle / right pressure sensor interrupted.
31/33	Internal connection to the right pressure sensor interrupted.
31/34	Left infeed - pressure limit exceeded.
31/35	Middle/right Infeed - pressure limit exceeded.
31/36	Right Infeed - pressure limit exceeded.
31/37	Left infeed - pressure limit undercut.
31/38	Middle/Right Infeed - pressure limit undercut.
31/39	Right Infeed - pressure limit undercut.
32/1	Capacity of the internal message storage exceeded.
32/130	Initialisation of the device.
32/200	Error in expansion configuration.
32/201	Syntax problem (s) in the extension configuration
33/1	Switch to "Operation" state
33/2	Switch to "Diagnostics active" state.
33/3	Switch to "Maintenance" state
33/4	Switch to "Out of specification" state.
33/5	Switch to "Check function" state.
33/6	Switch to "Error" state
33/7	Switch to AUTO operating state.
33/8	Switch to MANUAL operating state.
33/9	Switch to special operation mode: LED flashing.
33/11	Switch to "off" state.
33/12	Input value simulation active for at least 1 value.
33/13	Output value simulation active for at least 1 value.
33/14	Demo operation mode enabled.
33/15	User-triggered maintenance signal
33/32768	1 status message present.
35/1	EEPROM error detected.



Error code	Description
35/2	At least 1 persistent memory cannot be used.
40/996	Error on 1 or more partner device(s).
45/3	General error.
45/4	Incorrect büS status.
45/5	CANopen task command failed.
45/6	Incorrect parameter passed to function.
45/15	Message / data with incorrect length.
45/16	Message transfer failed.
45/17	Confirmation message timed out.
45/128	Mailbox overflowed.
45/129	büS mailbox overflowed.
45/130	CANopen mailbox overflowed.
45/131	CANopen response mailbox overflowed.
45/132	Event mailbox overflowed.
45/133	CSDO reply mailbox overflowed.
45/134	BDO reply mailbox overflowed.
45/176	CAN error counter overflow -Bus Off
45/177	Input buffer overflow.
45/178	Output buffer overflow.
45/256	büS event: büS is NOT operational.
45/257	büS event: initialisation of communication.
45/512	büS event: localisation.
45/768	büS event: a device is using the same address.
45/769	büS event: A device uses the same serial number.
45/1024	büS event: bus connection lost/not available.
45/1280	büS event: BDO message memory overflowed.
45/1792	büS event: partner search active.
45/1793	büS event: producer(s) not found.
45/1794	büS event: manually configured device without address. The search can take up to 1 minute.
45/1795	büS event: producer assignment faulty.
45/1796	büS event: removal of the producer failed.
45/1797	büS event: incorrectly configured CANopen device.
45/1798	büS event: GCV is configured on both büS interfaces.
45/1799	büS event: cyclical communication of the producer is not active.
45/2048	büS event: saving of persistent büS data (do not switch off device).
45/2049	büS event: deletion of persistent büS data (do not switch off device).
45/2304	büS event: router for acyclic data active.
45/2560	büS event: incorrect serial number.
45/2561	büS event: incorrect configuration of cyclical inputs (not enough filters).
45/2562	büS event: incorrect configuration of cyclical values.
45/2816	büS event: manager is active.



Error code	Description
45/3072	büS event: monitored device failed.
45/3584	Wait for addressing.
45/4096	Error when initialising the device parameters.
45/4097	Configured address is already being used.
51/1	No correct connection to the process control system.
51/2	The cyclical data traffic was slower than the set timeout parameters.
51/10	Initialisation of the industrial communication.
51/101	Error in the NetX configuration, e.g. when downloading the firmware.
51/102	The industrial communication is switched off.
51/103	No or incorrect mapping file present.
51/104	No protocol firmware available.
51/105	Please select a protocol and restart the device.
51/201	Protocol stack initialisation error.
51/202	Protocol stack configuration error.
51/203	Error sending the MAC address.
51/204	Error registering the object data.
51/205	Error registering the connections, more than 5 specified.
51/206	Incorrect PROFIBUS address, only addresses 1–126 possible.
51/207	Incorrect CC-Link address, only addresses 1–64 possible.
51/208	Incorrect CC-Link baud rate.
51/209	Incorrect IP parameters.
51/300	The fieldbus master is in "Stop" state.
51/303	Error during cyclical data exchange.
51/400	The master attempted to connect a faulty module/sub-module.
63/1	Firmware update is being carried out
63/2 63/7	Unit 1 Unit 6: Error on electronics module.
63/8	Reference measurement of the actuator switching time active.
63/9	Invalid limit values for the medium pressure at the left pressure sensor.
63/10	Invalid limit values for the medium pressure at the middle / right pressure sensor.
63/11	Invalid limit values for the medium pressure at the right pressure sensor.
63/12	At least one büS device is in the state: Maintenance.
63/13	At least one büS device is in the state: Out of specification.
63/14	At least one büS device is in the state: Functional test.
63/15	At least one büS device is in the state: Error.
63/16	SD card cannot be read! The data was created with firmware version A.02.XX.XX.
63/17 63/22	Unit 1 Unit 6: Reference measurement of the actuator switching time was aborted due to an actuator timeout.
63/23 63/28	Unit 1 Unit 6: Setting of upper/lower position feedback source incorrect.
63/2963/34	Unit 1 Unit 6: Setting of upper/lower position feedback source automatically changed.

Table 18: Description of the error code



# 27 DISASSEMBLY

# 27.1 Safety instructions



#### **DANGER**

Risk of injury due to high pressure and escaping medium.

▶ Secure the actuators against shifting before working on the device or plant.

Switch off the pressure before working on the device or plant. Vent or empty the lines.



#### WARNING

Risk of injury from electric shock.

- ▶ Switch off the power supply before working on the device or system. Secure against reactivation.
- ▶ Observe any applicable accident prevention and safety regulations for electrical devices.

Risk of injury due to improper removal!

- ▶ Disassembly should be performed only by trained personnel using suitable tools!
- $\rightarrow$  Loosen pneumatic connection.
- $\rightarrow$  Disconnect the electrical connection.



# 28 ACCESSORIES



# CAUTION

Risk of injury and/or damage to property due to incorrect parts!

Incorrect accessories and unsuitable spare parts may cause personal injuries and damage to the device and the area around it.

▶ Use only original accessories and original spare parts from Bürkert.

#### Electronic modules

Article	Order no.
Electronic module	384873
Electronic module with digital inputs	

#### Connection modules

Article	Size	Order no.
Connection module		384866
Connection module with compressed air supply	D6, D10	384863
	D1/4, D3/8	384864
Connection module with pressure sensor	D6, D10	384867
	D1/4, D3/8	384868

#### **Electrical accessories**

Article	Quantity [unit]	Order no.
Termination resistor, M12 male	1	772424
Termination resistor, M12 female	1	772425
Gender changer, M12, male-male	1	772867
Y-distributor	1	772420
Y-distributor with interrupt	1	772421

#### Attachment accessories

Article		Quantity [unit]	Order no.
Screw set M5x10 A2 DIN 6912 (for attaching the valve island to the base of the control cabinet)		10	308661
Holding plate (for control cabinet exterior)  4-fold		1	60005571
	8-fold	1	60005566
	12-fold	1	60005567
	16-fold	1	60005568
	20-fold	1	60005569
	24-fold	1	60005570



# büS accessories

Article	Quantity	Order no.
USB-büS-Interface set 1 (including power supply unit, büS stick, terminating resistor, Y-distributor, 0.7 m cable with M12 plug)		772426
USB-büS-Interface set 2 (including büS stick, terminating resistor, Y-distributor, 0.7 m cable with M12 plug	1)	772551
büS cable, angled M12 (stranded wire to female connector)	0.7 m	772626
büS cable (stranded wire to M12 female connector)	1.0 m	772409
	3.0 m	772410
	5.0 m	772411
	10.0 m	772412
büS cable drum	50.0 m	772413
	100.0 m	772414
büS extension cable	0.1 m	772492
	0.2 m	772402
	0.5 m	772403
	1.0 m	772404
	3.0 m	772405
	5.0 m	772406
	10.0 m	772407
	20.0 m	772408
büS service cable M12 to micro USB		773254
Adapter spring-loaded terminal to M12 (5-pole)	0,1 m	584765

# Pneumatic accessories

Article				Quantity	Order no.
Filter set for auxiliary pilot air				2 units	368590
Push-in connector, straight		M7	Ø 6 mm	1 unit	773459
	Brass,	M7	Ø 1/4"		773460
	nickel-plated	G1/4"	Ø 10mm		773461
		G1/4"	Ø 3/8"		773462
		M7	Ø 6 mm		773463
	Stainless	M7	Ø 1/4"	4	773464
	steel	G1/4"	Ø 10 mm	1 unit	773465
		G1/4"	Ø 3/8"		773466



Article			Quantity	Order no.
Plastic hoses for pneumatic system, polyamide (PA)	Ø 6/4 mm	Blue	50 m	780643
		Black		780644
		Natural		780645
	Ø 8/6 mm	Blue		780646
		Black		780647
		Natural		780648
	Ø 10/8 mm	Blue		780649
		Black		780650
		Natural		780651
	Ø 6/4 mm	Blue	100 m	771868
		Black		771295
		Natural		771296
	Ø 8/6 mm	Blue		771869
		Black		771873
		Natural		771297
	Ø 10/8 mm	Blue		771870
		Black		771877
		Natural		771874
Push-in silencer	Ø 6 mm	Sintered bronze,	iss nickel-	784306
	Ø 8 mm	brass nickel- plated body		784304
	Ø 10 mm		784305	
	Ø 6 mm	Polyethylene (PE)	1 unit	772571
	Ø 8 mm			773231
	Ø 10 mm			773522
	1/4"			773545
	3/8"			773546
Sealing plug	Brass, nickel-plated	08/06-08/06	1 unit	781666
		10/08-10/08		781667
	РОМ	06/04-06/04		782399
		08/06-08/06		782400
		10/08-10/08, red		782401
	РВТР	6 mm		771605
		8 mm		771606
		10 mm		771607

# Other accessories

Article	Quantity [unit]	Order no.
Device marker set	40 (4 rakes)	368588
Additional element "Lock Manual Override"	8	328082
Micro SD card		774087



# 29 PACKAGING AND TRANSPORT



#### **CAUTION**

Risk of injury due to heavy device.

During transportation or installation work, a heavy device may fall down and cause injuries.

- ► Heavy equipment must only be transported, assembled and disassembled with the help of a second person.
- ▶ Use suitable tools.

#### **CAUTION**

Damage in transit due to inadequately protected devices.

- ▶ Protect the device against moisture and dirt in shock-resistant packaging during transportation.
- ▶ Observe permitted storage temperature.

# 30 STORAGE

#### **CAUTION**

Incorrect storage may damage the device.

- ▶ Store the device in a dry and dust-free location.
- ► Storage temperature –10...+60 °C.

# 31 ENVIRONMENTALLY FRIENDLY DISPOSAL



- ► Follow national regulations regarding disposal and the environment.
- ► Collect electrical and electronic devices separately and dispose of them as special waste.

Further information country.burkert.com.